



Environmental  
Protection Agency

John R. Kasich, Governor  
Mary Taylor, Lt. Governor  
Scott J. Nally, Director

April 5, 2012

Mayor and Council  
City of Middletown  
One Donham Plaza  
Middletown, Ohio 45042

**RE: Middletown WWTP Compliance Evaluation Inspection (CEI)**

Ladies and Gentlemen:

On March 30, 2012, I conducted a Compliance Evaluation Inspection at the Middletown WWTP facility. A copy of my inspection report is enclosed. The inspection report contains no marginal or unsatisfactory ratings.

If you have any questions or comments concerning the contents of this letter, please feel free to contact me this office.

Sincerely,

Maureen M. Ware  
Environmental Specialist  
Division of Surface Water

MW/ca

Enclosures

ec: [paulf@cityofmiddletown.org](mailto:paulf@cityofmiddletown.org)  
[judyg@cityofmiddletown.org](mailto:judyg@cityofmiddletown.org)  
Butler County Health Dist.



State of Ohio Environmental Protection Agency  
Southwest District Office

NPDES Compliance Inspection Report

Section A: National Data System Coding					
Permit #	NPDES#	Month/Day/Year	Inspection Type	Inspector	Facility Type
1PE00003	OH0026522	03/30/12	C	S	1

Section B: Facility Data		
Name and Location of Facility Inspected	Entry Time	Permit Effective Date
Middletown WWTP 300 Oxford State Rd. Middletown, Ohio 45044	1:00PM	8/1/2009
	Exit Time	Permit Expiration Date
	3:30PM	1/31/2013
Name(s) and Title(s) of On-Site Representatives	Phone Number(s)	
Paul Fraley, ORC	513-425-7919	
Name, Address and Title of Responsible Official	Phone Number	
Mayor and Council, City of Middletown		

Section C: Areas Evaluated During Inspection					
(S = Satisfactory, M = Marginal, U = Unsatisfactory, N = Not Evaluated)					
S	Permit	S	Flow Measurement	N	Pretreatment
S	Records/Reports	N	Laboratory	N	Compliance Schedule
S	Operations & Maintenance	S	Effluent/Receiving Waters	S	Self-Monitoring Program
S	Facility Site Review	S	Sludge Storage/Disposal	N	Other
N	Collection System				

Section D: Summary of Findings (Attach additional sheets if necessary)	
See individual sections for comments.	
Inspector	Reviewer
 Maureen M. Ware Division of Surface Water Southwest District Office Date: 4/4/12	 Martyn G. Burt Environmental Supervisor Division of Surface Water Southwest District Office Date: 4/4/12

Sections E thru K: Complete on all inspections as appropriate  
**Y – Yes, N – No, N/A – Not Applicable, N/E – Not Evaluated**

**Section E: Permit Verification**

Inspection observations verify the permit

- (a) Correct name and mailing address of permittee ..... Y
- (b) Flows and loadings conform with NPDES permit..... Y
- (c) Treatment processes are as described in permit application... Y
- (d) All discharges are permitted..... Y
- (e) Number and location of discharge points are as described  
in permit..... Y
- (f) Storm water discharges properly permitted..... Y

Comments/Status:

**Section F: Compliance**

- (a) Any significant violations since the last inspection..... N
- (b) Appropriate Non-compliance notification of violations..... Y
- (c) Permittee is taking actions to resolve violations..... Y
- (d) Permittee has a compliance schedule..... Y
- (e) Compliance schedule contained in.....  
NPDES Permit Compliance Schedule
- (f) Permittee is in compliance with schedule..... Y
- (g) Has biomonitoring shown toxicity in discharge since last inspection N

Comments/Status:

Compliance for Middletown was evaluated for the period of 2/1/11 – 2/29/12. Two violations were noted:

Outfall	Code	Parameter	Type	Limit	Reported	Date
001	61942	pH, Minimum	1D Conc	6.5	6.	6/22/2011
001	61942	pH, Minimum	1D Conc	6.5	6.	6/23/2011

Section G: Operation & Maintenance

Treatment Works:

Treatment facility properly operated and maintained.....

(a) Standby power available:....generator  or dual feed ..... Y

i. What does the back-up power source operate.....

entire WWTP

ii. How often is the generator tested under load.....

N/A

(b) Which components have an alarm system available for power or equipment failures.....

all major WWTP components

(c) All treatment units in service other than backup units..... Y

(d) What method is used for scheduling routine & preventative maintenance (calendar, software, etc.).....

calendar

(e) Any major equipment breakdown since last inspection..... N

(f) Operation and maintenance manual provided and maintained..... Y

(g) Any plant bypasses since last inspection..... Y

(h) Any plant upsets since last inspection..... N

Comments/Status:

Section G: Operation & Maintenance con't

Record Keeping/Operator of Record:

- (a) Wastewater Treatment Works classification (OAC 3745-7)..... IV
- (b) Operator of Record holds unexpired license of class required by Permit..... N
- (c) Copy of certificate of Operator of Record displayed on-site..... Y
- (d) Has the Operator of Record submitted an ORC Notification form.. Y
- (e) Minimum operator staffing requirements fulfilled (OAC 3745-7).... Y
- (f) If a Staffing Reduction plan has been approved, are the stipulations of the plan being met..... N/A
- (g) Operator of Record log book provided..... Y
- (h) Format of log book (e.g. computer log, hard bound book)  

hard bound
------------
- (i) Log book kept onsite (in an area protected from weather)..... Y
- (j) Log book contains the following:
  - I. Identification of treatment works..... Y
  - II. Date/times of arrival/departure for Operator of Record and any other operator required by OAC 3745-7..... Y
  - iii. Daily record of operator and maintenance activities (including preventative maintenance, repairs and request for repairs, process control test results, etc.)..... Y
  - iv. Laboratory results (unless documented on bench sheets)... Y
  - v. Identification of person making entries..... Y
- (k) Has the Operator of Record submitted written notifications to the permittee, Ohio EPA and, if applicable, any local environmental agencies when a collection system overflow, treatment plant bypass or effluent limit violation has occurred..... Y

Comments/Status:

Paul Fraley is a Class III operator. He is to get his Class IV by December 24, 2012.

Section G: Operation & Maintenance con't

Collection System:

- (a) Are there pump stations in the collection system..... Y
  - i. How many publicly-owned pump stations equipped with permanent standby power or equivalent.....All
  - ii. How many pump stations have telemetered alarms.....All
  - iii. How many pump stations have operable alarms.....All
  
- (b) Any chronic collection system overflows since last inspection..... N
- (c) Regulatory agency notified of all overflows..... Y
- (d) Are there CSOs in the collection system..... Y  
if so, what is the LTCP status.....

Consent decree currently being negotiated with USEPA
  
- (e) How are CSOs monitored (chalk, block, level sensor, etc.).....

Each CSO is equipped with an ultrasonic level sensor that measures flow over the weirs and into the river. Software calculates the bypass flow rate based on the shape of the sewer at each weir. This information is transmitted to the WWTP by radio and is logged for later transfer to the MORs.
  
- (f) Portable pumps available for collection system maintenance..... Y
- (g) RDII Program established and active..... Y
- (h) Any WIB complaint received since last inspection..... Y
- (i) Is there a WIB response plan..... Y
- (j) Is any portion of the collection system at or near dry weather capacity..... N

Comments/Status:

I/I program exists but is not a formal plan based on an official I/I study.  
Middletown had 13 WIB incidents in 2011 (due to grease, roots, and debris in the sewers).



- (b) Has amount of sludge generated changed significantly since the last inspection..... N
- (c) How much sludge storage is provided at the plant.....
- (d) Records kept in accordance with State and Federal law (5 years according to OAC 3745-40-06)..... Y
- (e) Any complaints received in last year regarding sludge..... N
- (f) 5/8" screen at headworks for facilities that land apply sludge..... N
- (g) Are sludge application sites inspected to verify compliance with NPDES permit..... Y
- (h) Is a contractor used for sludge disposal..... Y  
 If so, what is the name of the contractor.....

**Comments/Status:**

Middletown lacks 5/8" or smaller barscreens on the WWTP influent. During the next WWTP upgrade, 5/8" barscreens should be included in the design.

**Section I: Self-Monitoring Program**

**Flow Measurement:**

- (a) Primary/Secondary flow measuring devices (e.g. weir with ultrasonic level sensor):
- (b) Flow meter calibrated annually ..... Y  
 (Date of last calibration: )
- (c) 24-hour recording instruments operated and maintained..... Y
- (d) Flow measurement equipment adequate to handle full range of flows..... Y
- (e) All discharged flow is measured..... Y

**Comments/Status:**

A new flow meter was installed last autumn. It will be calibrated one year after its installation.

**Section I: Self-Monitoring Program (con't)**

**Sampling:**

- (a) Sampling location(s) are as specified by permit..... Y
- (b) Parameters and sampling frequency agree with permit..... Y

- (c) Permittee uses required sampling method..... Y  
(see GLC page)
- (d) Monitoring records (i.e., flow, pH, DO) maintained for a minimum of three years including all original strip chart recordings (i.e, continuous monitoring instrumentation, calibration and maintenance records)..... Y

**Comments/Status:**

---

**Section I: Self-Monitoring Program (con't)**

**Laboratory:**

*General*

- (a) Does the Quality Assurance Manual contain written Standard Operating Procedures (SOP's) for all analysis performed onsite..... Y
- (b) Do SOP's include the following if applicable..... Y
  - Title
  - Procedure
  - Scope and Application
  - Calculations
  - Summary
  - Quality Control
  - Sample Handling and Preservation
  - Maintenance
  - Interferences
  - Corrective Action
  - Apparatus and Materials
  - Reference (Parent Method)
  - Reagents

*Note: Standard Methods 1020A establishes that "Quality assurance (QA) is the definitive program for laboratory operation that specifies the measure required to produce defensible data of known precision and accuracy. Standard operating procedures are to be used in the laboratory in sufficient detail that a competent analyst unfamiliar with the method can conduct a reliable review and/or obtain acceptable results." SOPs should be developed for each analytical procedure.*

- (c) EPA approved analytical testing procedures used (40 CFR 136.3).. Y
- (d) If alternate analytical procedures are used, proper approval has been obtained..... N/A
- (e) Analyses being performed more frequently than required by permit. Y
- (f) If (e) is yes, are results in permittee's self-monitoring report..... Y
- (g) Satisfactory calibration and maintenance of instruments/equipment. Y

(see score from GLC page)  
(h) Commercial laboratory used..... Y  
Parameters analyzed by commercial lab: toxicity, metals, Cn, nutrients,  
sludge.

Lab name: Belmont, Alloway, Sherry Labs, Enviroscience

*Discharge Monitoring Report Quality Assurance (DMRQA)*

- (a) Participation in latest USEPA quality assurance performance  
sampling..... Y  
Date: 6/11
- (b) Were any parameters "Unsatisfactory"..... N
- (c) Reasons for "Unsatisfactory" parameters.....

**Comments/Status:**

---

**Section J: Effluent/Receiving Water Observations**

Outfall # 001

Outfall Description: pipe

Receiving Stream: Great Miami River

Receiving Stream Description: Turbid

**Comments/Status:**

Slight foam near the outfall was noted, but it dissipated quickly.

---

**Section K: Multimedia Observations**

- (a) Are there indications of sloppy housekeeping or poor maintenance  
in work and storage areas or laboratories..... N
- (b) Do you notice staining or discoloration of soils, pavement or floors.. N
- (c) Do you notice distressed (unhealthy, discolored, dead) vegetation.. N
- (d) Do you see unidentified dark smoke or dust clouds coming from  
sources other than smokestacks..... N
- (e) Do you notice any unusual odors or strong chemical smells..... N
- (f) Do you see any open or unmarked drums, unsecured liquids, or

damaged containment facilities..... N

If any of the above are observed, ask the following questions:

- (1) What is the cause of the condition?
- (2) Is the observed condition or source a waste product?
- (3) Where is the suspected contaminant normally disposed?
- (4) Is this disposal permitted?
- (5) How long has the condition existed and when did it begin?

**Comments/Status:**

--





# General Lab Criteria

Criteria	Standard Methods Requirement	Acceptable?		Rating
<b>pH Meter</b>				
<ul style="list-style-type: none"> <li>• Calibration Frequency / Documentation</li> </ul>	<ul style="list-style-type: none"> <li>• Calibration verification required for testing over long period of time (e.g. 12 hrs.), or after a large number of samples (every 10 samples)<sup>3</sup></li> </ul>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	<ul style="list-style-type: none"> <li>• Logbook maintained<sup>2</sup></li> </ul>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
<ul style="list-style-type: none"> <li>• Minimum of 2 point calibration</li> </ul>	<ul style="list-style-type: none"> <li>• Calibration per manufacturer specification and calibration buffers must bracket anticipated result<sup>7</sup></li> </ul>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
<ul style="list-style-type: none"> <li>• Slope Documentation / Acceptability</li> </ul>	<ul style="list-style-type: none"> <li>• Slope acceptable range indicated on benchsheet<sup>2</sup></li> </ul>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
<ul style="list-style-type: none"> <li>• Buffer Expiration Date</li> </ul>	<ul style="list-style-type: none"> <li>• Buffers must not be expired</li> </ul>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
<ul style="list-style-type: none"> <li>• Other</li> </ul>	<ul style="list-style-type: none"> <li>• Instrument manual available</li> </ul>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	<ul style="list-style-type: none"> <li>• Teflon covered magnetic stirrer or equivalent for mixing<sup>8</sup></li> </ul>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments: :

Criteria	Standard Methods Requirement	Acceptable?		Rating
<b>Dissolved Oxygen Meter</b>				
<ul style="list-style-type: none"> <li>• Calibration Method</li> </ul>	<ul style="list-style-type: none"> <li>• Air or known DO calibration method<sup>10</sup></li> </ul>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	<ul style="list-style-type: none"> <li>• Calibration per manufacturer specification<sup>10</sup></li> </ul>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
<ul style="list-style-type: none"> <li>• Calibration Frequency / Documentation</li> </ul>	<ul style="list-style-type: none"> <li>• Logbook maintained<sup>2</sup></li> </ul>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	<ul style="list-style-type: none"> <li>• Calibration verification required at least once each day the meter is used.<sup>3</sup></li> </ul>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
<ul style="list-style-type: none"> <li>• Other</li> </ul>	<ul style="list-style-type: none"> <li>• Small to no bubble present under membrane (must be smaller than the lead in number 2 pencil)<sup>11</sup></li> </ul>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	<ul style="list-style-type: none"> <li>• Instrument manual available</li> </ul>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments:

# General Lab Criteria

Criteria	Standard Methods Requirement		Rating
Incubator (CBOD/ E-Coli)	Acceptable?		
<ul style="list-style-type: none"> <li>• Temperature Recordkeeping</li> </ul>	<ul style="list-style-type: none"> <li>• Temperature checked / recorded twice daily for each shelf in use<sup>1</sup>(E-Coli)</li> </ul>	<input type="checkbox"/> Yes <input type="checkbox"/> No	A
	<ul style="list-style-type: none"> <li>• Temperature checked / recorded daily<sup>2</sup> (CBOD)</li> </ul>	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	
	<ul style="list-style-type: none"> <li>• Acceptable temperature range (CBOD) is 20° C ±1.0 °<sup>12</sup></li> </ul>	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	
	<ul style="list-style-type: none"> <li>• Acceptable temperature range (E-Coli) is 35° C ±0.5 °<sup>22</sup></li> </ul>	<input type="checkbox"/> Yes <input type="checkbox"/> No	
	<ul style="list-style-type: none"> <li>• Logbook maintained<sup>2</sup></li> </ul>	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	
<ul style="list-style-type: none"> <li>• Temperature Calibration / Documentation</li> </ul>	<ul style="list-style-type: none"> <li>• Thermometer calibrated annually with NIST traceable thermometer<sup>1,2</sup></li> </ul>	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	
	<ul style="list-style-type: none"> <li>• Temperature correction information posted on incubator<sup>1</sup></li> </ul>	<input type="checkbox"/> Yes <input type="checkbox"/> No	
<ul style="list-style-type: none"> <li>• E-Coli can use multiple tubes (five 20 ml or ten 10 ml), or mfg's multi-well tray</li> </ul>	<ul style="list-style-type: none"> <li>• E-coli Ultraviolet lamp (365 nm wave length, 6 W bulb)<sup>23</sup></li> </ul>	<input type="checkbox"/> Yes <input type="checkbox"/> No	
	<ul style="list-style-type: none"> <li>• Instrument manual available</li> </ul>	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	
<ul style="list-style-type: none"> <li>• Other</li> </ul>	<ul style="list-style-type: none"> <li>• Temperature Log (thermometer accurate to 0.5 Celsius).<sup>1</sup></li> </ul>	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	

Comments: : If Middletown's thermometer does not provide the same reading as the NIST thermometer that it is calibrated to, Middletown purchases a new thermometer.

Criteria	Standard Methods Requirement		Rating
Refrigerator	Acceptable?		
<ul style="list-style-type: none"> <li>• Temperature Recordkeeping</li> </ul>	<ul style="list-style-type: none"> <li>• Temperature Log (thermometer accurate to 0.5 Celsius).<sup>5</sup></li> </ul>	<input type="checkbox"/> Yes <input type="checkbox"/> No	
<ul style="list-style-type: none"> <li>• Temperature Calibration / Documentation</li> </ul>	<ul style="list-style-type: none"> <li>• Thermometer calibrated annually with NIST traceable thermometer<sup>1,2</sup></li> </ul>	<input type="checkbox"/> Yes <input type="checkbox"/> No	
<ul style="list-style-type: none"> <li>• Other</li> </ul>	<ul style="list-style-type: none"> <li>• Thermometer held in water bath.<sup>1</sup></li> </ul>	<input type="checkbox"/> Yes <input type="checkbox"/> No	
	<ul style="list-style-type: none"> <li>• Refrigerator temperature ≤6° Celsius.<sup>13</sup></li> </ul>	<input type="checkbox"/> Yes <input type="checkbox"/> No	
	<ul style="list-style-type: none"> <li>• Do not store volatile solvents, food, or beverages.<sup>14</sup></li> </ul>	<input type="checkbox"/> Yes <input type="checkbox"/> No	

Comments:

# General Lab Criteria

Criteria	Standard Methods Requirement	Acceptable?		Rating
<b>Chlorine Meter</b>				
• Calibration Frequency / Documentation	• pH / millivolt meter read to 0.1 mV <sup>15</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Calibration verification required for testing over long period of time (e.g. 12 hrs.), or after a large number of samples (every 10 samples) <sup>3</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Calibration Method	• Calibration using three iodate solutions 0.2, 1.0, 5.0 milliliters or calibration per manufacturer specification <sup>16</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Standards used for calibration not expired	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Slope Documentation / Acceptability	• Calibration curve (acceptable slope)	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Other	• Electrode free of deposits and foreign material	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Log book being maintained. <sup>2</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Instrument manual available	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
Comments: :				
<hr/>				
Criteria	Standard Methods Requirement	Acceptable?		Rating
<b>Ammonia Meter</b>				
• Calibration Frequency / Documentation	• Calibration verification required for testing over long period of time (e.g. 12 hrs.), or after a large number of samples (every 10 samples) <sup>3</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Log book being maintained <sup>2</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Slope acceptability	• Verify calibration slope is acceptable (per mfg. spec.).	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Calibration Method	• Standards used for calibration (3 ammonia solutions of 10 mg/l, 1 mg/l, and 0.1 mg/l) or per mfg. spec. <sup>17</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Standards used for calibration not expired	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Other	• Electrode free of deposits and foreign material	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Teflon covered magnetic stirrer or equivalent for mixing <sup>18</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Instrument manual available	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
Comments: :				

# General Lab Criteria

Criteria	Standard Methods Requirement	Acceptable?		Rating
<b>Sample Collection/Handling</b>				
• Sample Labeling	• Samples container labeled (description, date, time, preservative added, initialed). <sup>19</sup>	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	<b>A</b>
• Chain of Custody	• Chain of custody (description, date, time, signature). <sup>19</sup>	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	
• Other	• Composite samples refrigerated during sample collection <sup>14</sup>	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Equipment blanks utilized <sup>14</sup>	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	
	• SOP for cleaning of sampling equipment	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Logbook being maintained <sup>2</sup>	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments: In addition to chain of custody forms used for the commercial labs., Middletown uses an internal chain of custody to track what parameters have been completed, who completed them, and when they were completed.

Criteria	Standard Methods Requirement	Acceptable?		Rating
<b>Desiccator</b>				
• General criteria	• Properly working seals.	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Desiccant fresh (blue color)	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Documentation	• Log book being maintained <sup>2</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments:

Criteria	Standard Methods Requirement	Acceptable?		Rating
<b>Bench sheets</b>				
• General criteria	• Date(s) <sup>2</sup>	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	<b>A</b>
	• Analyst initials <sup>2</sup>	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Blue or black ink pen <sup>2</sup>	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Calibration information <sup>2</sup>	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Equations, calculations, units for all measurements, notations, and results present <sup>2</sup>	<input type="checkbox"/> Yes	<input checked="" type="checkbox"/> No	
	• Corrections, single line through, initialed and dated <sup>2</sup>	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments: No units were noted for CBOD5 on the bench sheet.

# General Lab Criteria

# General Lab Criteria

Criteria	Standard Methods Requirement	Acceptable?		Rating
<b>Hot Water Bath (Fecal Coliform/E. Coli)</b>				
• Temperature Recordkeeping	• Temperature Log (thermometer accurate to 0.2° C) <sup>21</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Incubator temperature 44.5° C ± 0.2° <sup>21/24</sup>			
• Temperature Calibration / Documentation	• Thermometer calibrated annually with NIST traceable thermometer <sup>1,2</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Log book being maintained <sup>2</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Water Level	• Thermometer total immersion or partial (line on thermometer to ID immersion depth) <sup>1,5</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments:

Criteria	Standard Methods Requirement	Acceptable?		Rating
<b>Autoclaves/Steam Sterilizers</b>				
• All apparatus utilized is adequately sterilized before use	• Sterilizing temperature 121° C <sup>25</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• 10 to 30 minutes time based on material being sterilized <sup>26</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Documentation	• Verify the autoclave temperature weekly by using a maximum registering thermometer (MRT) to confirm that 121°C has been reached as measured in the exhaust. <sup>1</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Date, contents, sterilization time and temperature, total time in autoclave, and analyst's initials should be recorded each time the autoclave is used <sup>1</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Temperature Calibration / Documentation	• Thermometer calibrated annually with NIST traceable thermometer <sup>1,2</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Log book being maintained <sup>2</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Performance Checks	• Test monthly for efficacy using a biological such as commercially available <i>Geobacillus stearothermophilus</i> in spore strips, suspensions, or capsules <sup>1</sup>	<input type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments:

# General Lab Criteria

Criteria	Standard Methods Requirement	Acceptable?	Rating
<b>Final Effluent Temperature Monitoring</b>			
• General Criteria	• Thermometer calibrated annually with NIST traceable thermometer <sup>1,2</sup>	<input type="checkbox"/> Yes <input type="checkbox"/> No	
	• Thermometer accurate to 0.1° Celsius <sup>5</sup>	<input type="checkbox"/> Yes <input type="checkbox"/> No	
	• Log book being maintained <sup>2</sup>	<input type="checkbox"/> Yes <input type="checkbox"/> No	
Comments:			
<b>Number of Criteria Rated:</b>			
			Acceptable      3
			Marginal            0
			Unacceptable       0
			Total Number of Areas Rated      3
<p><b>Acceptable Ratings</b> – No action required (recommend SOP's written or updated, perform DMRQA's for all onsite analysis, recommend voluntary lab analyst certification, written response not required).</p>			
<p><b>Marginal Ratings</b> – Improvements required, written response required (recommend SOP's be written or updated, recommend they perform DMRQA's for all onsite analysis, recommend voluntary lab analyst certification, require deficiencies to be addressed in written response).</p>			
<p><b>Unsatisfactory Rating</b> - Improvements required, written response required, NOV issued (recommend SOP's be written or updated, recommend they perform DMRQA's for all onsite analysis, recommend voluntary lab analyst certification, require deficiencies to be addressed in written response to NOV).</p>			
Consider recommending PAI Audit from DES when:		>60% of ratings are Marginal >45% of ratings are a combination of Marginal or Unacceptable >30% of ratings are Unacceptable	

## Notation of Referenced Method

- |                            |                              |
|----------------------------|------------------------------|
| 1 Method 9020-B, Item 3    | 14 Method 1060A, Item 1      |
| 2 Method 1020-A, Item 1    | 15 Method 4500-CI I, Item 2  |
| 3 Method 1020-B, Item 10   | 16 Method 4500-CI I, Item 4  |
| 4 Method 2540-B, Item 2    | 17 Method 4500-NH3 D, Item 4 |
| 5 Method 2550-B, Item 1    | 18 Method 4500-NH3 D, Item 2 |
| 6 Method 1020-A, Item 1    | 19 Method 1060-B, Item 2     |
| 7 Method 4500-H B, Item 4  | 20 Method 1060-B, Item 1     |
| 8 Method 4500-H B, Item 2  | 21 Method 9222D, Item 1      |
| 9 Method 1020-B, Item 2    | 22 Method 9223 B, Item 2     |
| 10 Method 4500-O B, Item 3 | 23 Method 9223 B, Item 3     |
| 11 Method 4500-O G, Item 3 | 24 Method 1603, Item 2       |
| 12 Method 5210-B, Item 5   | 25 Method 9030-B, Item 3     |
| 13 CFR 136.3, Table II     | 26 Method 9020 B, Table IV   |

**Equipment Logbook Content** - all maintenance performed on a piece of equipment should be documented in the logbook. This should include parts replacement and routine maintenance activities. Entries should include date, maintenance performed and initials of person making entry.

# General Lab Criteria

<b>Preservation and Holding Times</b>						
Parameter	Container	Min. Sample Size (mL)	Sample Type	Preservation	Maximum Storage Time	
					Recommended	Regulatory
BOD / CBOD	P, G	1000	G, C	Refrigerate $\leq 6^{\circ}\text{C}$	6h	48h
TSS	P, G	200	G, C	Refrigerate $\leq 6^{\circ}\text{C}$	7 d	7 d
pH	P, G	50	G	Analyze immediately	0.25h	0.25 h
NH <sub>3</sub> -N	P, G	500	G, C	Analyze as soon as possible or add H <sub>2</sub> SO <sub>4</sub> to pH <2, Refrigerate $\leq 6^{\circ}\text{C}$	7 d	28 d
TRC	P, G	500	G	Analyze immediately	0.25h	0.25 h
DO (electrode)	G, BOD Bottle	300	G	Analyze immediately	0.25h	0.25 h
Temperature	P, G	--	G	Analyze immediately	0.25h	0.25 h
Metals, general	P, G	1000	G, C	For dissolved filter immediately and add HNO <sub>3</sub> to pH <2	6 months	6 months
Purgeables by purge and trap	G (PTFE lined lid)	40 (X2)	G	HCl to pH<2, Refrigerate $\leq 6^{\circ}\text{C}$	7 d	14 d
Base/Neutrals and acids	G (solvent rinsed or baked)	1000	C, G	Refrigerate $\leq 6^{\circ}\text{C}$	7 d	7 days until extraction 40 days after extraction
Pesticides	G (PTFE lined lid)	1000	C	Refrigerate $\leq 6^{\circ}\text{C}$	7 d	7 days until extraction 40 days after extraction
Fecal Coliform / E-Coli	G, P (Sterilized)	100	G	Refrigerate $\leq 10^{\circ}\text{C}$ If chlorine present, add sodium thiosulfate tablet	6 hrs transport Start analysis within 2 hrs of receipt in lab.	
Oil and Grease	G	1000	G	HCl or H <sub>2</sub> SO <sub>4</sub> to pH <2, Refrigerate $\leq 6^{\circ}\text{C}$	28 d	28 d

<b>Approved Standard Methods</b>	
CBOD / BOD 5 Day	Std Methods 5210-B
Ammonia, Selective Electrode Method	Std Methods 4500-NH <sub>3</sub> D
Total Residual Chlorine, DPD Colorimetric Method	Std Methods 4500-Cl G
Total Suspended Solids, Dried at 103-105 °C	Std Methods 2540-D
Dissolved Oxygen, Membrane Electrode Method	Std Method 4500-O G
pH, Electrometric Method	Std Methods 4500-H+ B
Fecal Coliform, Membrane Filter Procedure	Std Methods 9222D
Escherichia Coli, Enzyme Substrate Test	Std Method 9223B
Escherichia Coli Membrane Filtration Procedure	EPA Method 1603
Oil and Grease	USEPA 1664A or Std Methods 5520B
Metals, general	USEPA 200, Std Methods 3111B or C, or 3120B
Volatiles (Purgeables by purge and trap)	USEPA 6210, Std Methods 624
Semi-Volatiles (Base/Neutrals and acids)	USEPA 6410, Std Methods 625
Pesticides	USEPA 6410 and 6630, Std Methods 608