



Environmental
Protection Agency

John R. Kasich, Governor
Mary Taylor, Lt. Governor
Scott J. Nally, Director

April 4, 2012

Mr. John S. Jones
Preble County Facilities Manager
4239 US Route 127 South
Eaton, Ohio 45320

RE: Preble County Sewer District #3 Compliance Evaluation Inspection

Dear Mr. Jones:

On March 30, 2012, I conducted a Compliance Evaluation Inspection (CEI) at the Preble County Sewer District #3 WWTP facility. A copy of my inspection report is enclosed. The inspection report contains no negative ratings and two marginal ratings.

The compliance inspection included a more in-depth examination of laboratory issues than has been done previously. The intent is to assist Preble County Sewer District #3 in being able to document that the data produced is "true and accurate" and is therefore defensible. Please note that the NPDES permit in Part III states that the permittee shall "periodically calibrate and perform maintenance on all monitoring and instrumentation at intervals to ensure accuracy of measurements". Furthermore, the certification statement required with the submittal of discharge monitoring reports asks the signer to certify "I believe the submitted information true, accurate and complete."

Please indicate by April 30, 2012, what measures have or will be taken to address the marginal ratings, as well as deficiencies noted in the General Laboratory Criteria.

If you have any questions or comments concerning the contents of this letter, please feel free to contact me at this office.

Sincerely,

Maureen M. Ware
Environmental Specialist
Division of Surface Water

MMW/tf

Enclosures

ec: Preble County Health District



State of Ohio Environmental Protection Agency
Southwest District Office

NPDES Compliance Inspection Report

Section A: National Data System Coding					
Permit #	NPDES#	Month/Day/Year	Inspection Type	Inspector	Facility Type
1PL00005	OH0134082	3/30/2012	C	S	1

Section B: Facility Data		
Name and Location of Facility Inspected	Entry Time	Permit Effective Date
Preble County Sewer District #3 10031 SR 503 West Elkton, Ohio 45070	11:30AM	8/1/2009
	Exit Time	Permit Expiration Date
	12:05PM	7/31/2014
Name(s) and Title(s) of On-Site Representatives	Phone Number(s)	
John S. Jones (ORC)	(937) 456-2621	
Name, Address and Title of Responsible Official	Phone Number	
Preble County Board of Commissioners		

Section C: Areas Evaluated During Inspection					
(S = Satisfactory, M = Marginal, U = Unsatisfactory, N = Not Evaluated)					
S	Permit	S	Flow Measurement	N	Pretreatment
M	Records/Reports	*	Laboratory	N	Compliance Schedule
S	Operations & Maintenance	M	Effluent/Receiving Waters	S	Self-Monitoring Program
S	Facility Site Review	S	Sludge Storage/Disposal	N	Other
N	Collection System				

Section D: Summary of Findings (Attach additional sheets if necessary)

Records/Reports was rated marginal due to some violations not being reported via form 4498 or 4499, and other violations being reported only after Preliminary Compliance Reviews were sent out. Effluent/Receiving Waters was rated marginal due to the violations.

Inspector	Reviewer
 Maureen M. Ware Division of Surface Water Southwest District Office Date 4/4/12	 Martyn G. Burt Environmental Supervisor Division of Surface Water Southwest District Office Date 4/4/12

Sections E thru K: Complete on all inspections as appropriate
Y – Yes, N – No, N/A – Not Applicable, N/E – Not Evaluated

Section E: Permit Verification

Inspection observations verify the permit

- (a) Correct name and mailing address of permittee Y
- (b) Flows and loadings conform with NPDES permit..... Y
- (c) Treatment processes are as described in permit application... Y
- (d) All discharges are permitted..... Y
- (e) Number and location of discharge points are as described
in permit..... Y
- (f) Storm water discharges properly permitted..... N/A

Comments/Status:

Section F: Compliance

- (a) Any significant violations since the last inspection..... N
- (b) Appropriate Non-compliance notification of violations..... N
- (c) Permittee is taking actions to resolve violations..... Y
- (d) Permittee has a compliance schedule..... N
- (e) Compliance schedule contained in...N/A
- (f) Permittee is in compliance with schedule..... N/A
- (g) Has biomonitoring shown toxicity in discharge since last inspection N/A

Comments/Status:

See the last page for violation list. Appropriate violation reporting forms were submitted electronically after a Preliminary Compliance Review was sent to Preble SD3. However, not all violations had a PCR sent. I have informed the ORC that violation reporting is to be done within 24 hours of discovery of a violation, instead of after a PCR is received.

Section G: Operation & Maintenance

Treatment Works:

Treatment facility properly operated and maintained

- (a) Standby power available.....generator or dual feed N/E
- i. What does the back-up power source operate.....
entire WWTP
- ii. How often is the generator tested under load.....
once per month
- (b) Which components have an alarm system available for power or equipment failures.....
Entire plant has telemetry for power or equipment failure.
- (c) All treatment units in service other than backup units..... Y
- (d) What method is used for scheduling routine & preventative maintenance (calendar, software, etc.).....
calendar
- (e) Any major equipment breakdown since last inspection..... N
- (f) Operation and maintenance manual provided and maintained..... Y
- (g) Any plant bypasses since last inspection..... N
- (h) Any plant upsets since last inspection..... Y

Comments/Status:

High flows in April 2011 caused CBOD5 violations.

Section G: Operation & Maintenance con't

Record Keeping/Operator of Record:

- (a) Wastewater Treatment Works classification (OAC 3745-7)..... A
- (b) Operator of Record holds unexpired license of class required by Permit..... Y
- (c) Copy of certificate of Operator of Record displayed on-site..... Y
- (d) Has the Operator of Record submitted an ORC Notification form.. Y
- (e) Minimum operator staffing requirements fulfilled (OAC 3745-7).... Y
- (f) If a Staffing Reduction plan has been approved, are the stipulations of the plan being met..... N/A
- (g) Operator of Record log book provided..... Y
- (h) Format of log book (e.g. computer log, hard bound book)

hard bound
- (i) Log book kept onsite (in an area protected from weather)..... Y
- (j) Log book contains the following:
 - I. Identification of treatment works..... Y
 - II. Date/times of arrival/departure for Operator of Record and any other operator required by OAC 3745-7..... Y
 - iii. Daily record of operator and maintenance activities (including preventative maintenance, repairs and request for repairs, process control test results, etc.)..... Y
 - iv. Laboratory results (unless documented on bench sheets)... Y
 - v. Identification of person making entries..... Y
- (k) Has the Operator of Record submitted written notifications to the permittee, Ohio EPA and, if applicable, any local environmental agencies when a collection system overflow, treatment plant bypass or effluent limit violation has occurred..... Y

Comments/Status:

Section G: Operation & Maintenance con't

Collection System:

- (a) Are there pump stations in the collection system..... Y
 - i. How many publicly-owned pump stations equipped with permanent standby power or equivalent.....1
 - ii. How many pump stations have telemetered alarms.....1
 - iii. How many pump stations have operable alarms.....1
- (b) Any chronic collection system overflows since last inspection..... N
- (c) Regulatory agency notified of all overflows..... Y
- (d) Are there CSOs in the collection system..... N
if so, what is the LTCP status.....
- (e) How are CSOs monitored (chalk, block, level sensor, etc.).....
- (f) Portable pumps available for collection system maintenance..... Y
- (g) RDII Program established and active..... N
- (h) Any WIB complaint received since last inspection..... N
- (i) Is there a WIB response plan..... Y
- (j) Is any portion of the collection system at or near dry weather capacity..... N

Comments/Status:

Notification letters have now been sent to all West Elkton citizens indicating that clean water connections to the sanitary sewer system are illegal. An I/I plan is being created by Preble Sewer District 3. WIB are dealt with on a case by case basis.

Section I: Self-Monitoring Program (con't)

Sampling:

- (a) Sampling location(s) are as specified by permit..... Y
- (b) Parameters and sampling frequency agree with permit..... Y
- (c) Permittee uses required sampling method..... Y
(see GLC)
- (d) Monitoring records (i.e., flow, pH, DO) maintained for a minimum of three years including all original strip chart recordings (i.e, continuous monitoring instrumentation, calibration and maintenance records)..... Y

Comments/Status:

Section I: Self-Monitoring Program (con't)

Laboratory:

General

- (a) Does the Quality Assurance Manual contain written Standard Operating Procedures (SOP's) for all analysis performed onsite..... N
- (b) Do SOP's include the following if applicable..... N
 - Title
 - Scope and Application
 - Summary
 - Sample Handling and Preservation
 - Interferences
 - Apparatus and Materials
 - Reagents
 - Procedure
 - Calculations
 - Quality Control
 - Maintenance
 - Corrective Action
 - Reference (Parent Method)

Note: Standard Methods 1020A establishes that "Quality assurance (QA) is the definitive program for laboratory operation that specifies the measure required to produce defensible data of known precision and accuracy. Standard operating procedures are to be used in the laboratory in sufficient detail that a competent analyst unfamiliar with the method can conduct a reliable review and/or obtain acceptable results." SOPs should be developed for each analytical procedure.

- (c) EPA approved analytical testing procedures used (40 CFR 136.3).. Y

- (d) If alternate analytical procedures are used, proper approval has been obtained..... N/A
- (e) Analyses being performed more frequently than required by permit. Y
- (f) If (e) is yes, are results in permittee's self-monitoring report..... Y
- (g) Satisfactory calibration and maintenance of instruments/equipment. Y
(see score from GLC)
- (h) Commercial laboratory used..... Y
Parameters analyzed by commercial lab: everything except D.O. and temperature

Lab name: Belmont

Discharge Monitoring Report Quality Assurance (DMRQA)

- (a) Participation in latest USEPA quality assurance performance sampling..... N/A
Date:
- (b) Were any parameters "Unsatisfactory" N/A
- (c) Reasons for "Unsatisfactory" parameters.....

Comments/Status:

Section J: Effluent/Receiving Water Observations

Outfall # 001

Outfall Description: Pipe in headwall

Receiving Stream: unnamed tributary of Elk Creek

Receiving Stream Description: clear

Comments/Status:

Numerous frogs were noted near the outfall.

Section K: Multimedia Observations

- (a) Are there indications of sloppy housekeeping or poor maintenance in work and storage areas or laboratories..... N
- (b) Do you notice staining or discoloration of soils, pavement or floors.. N

- (c) Do you notice distressed (unhealthy, discolored, dead) vegetation.. N
- (d) Do you see unidentified dark smoke or dust clouds coming from sources other than smokestacks..... N
- (e) Do you notice any unusual odors or strong chemical smells..... N
- (f) Do you see any open or unmarked drums, unsecured liquids, or damaged containment facilities..... N

If any of the above are observed, ask the following questions:

- (1) What is the cause of the condition?
- (2) Is the observed condition or source a waste product?
- (3) Where is the suspected contaminant normally disposed?
- (4) Is this disposal permitted?
- (5) How long has the condition existed and when did it begin?

Comments/Status:

Violations reported 4/1/2009 – 2/29/2012

Station Code	Parameter	Type	Limit	Reported	Date	
001	00610	NH3	30D Conc	1.0	1.045	7/1/2010
001	00610	NH3	7D Conc	1.5	2.09	7/15/2010
001	00300	D.O.	1D Conc	6.0	5.91	9/30/2010
001	00300	D.O.	1D Conc	6.0	5.93	2/24/2011
001	80082	CBOD5	7D Conc	15	15.8	3/8/2011
001	80082	CBOD5	7D Conc	15	22.7	4/22/2011
001	80082	CBOD5	7D Qty	1.419	2.83534	4/22/2011
001	00400	pH	1D Conc	6.5	5.65	9/1/2011

General Lab Criteria

Criteria	Standard Methods Requirement	Acceptable?		Rating
pH Meter				
<ul style="list-style-type: none"> • Calibration Frequency / Documentation 	<ul style="list-style-type: none"> • Calibration verification required for testing over long period of time (e.g. 12 hrs.), or after a large number of samples (every 10 samples)³ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No	A
	<ul style="list-style-type: none"> • Logbook maintained² 	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
<ul style="list-style-type: none"> • Minimum of 2 point calibration 	<ul style="list-style-type: none"> • Calibration per manufacturer specification and calibration buffers must bracket anticipated result⁷ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
<ul style="list-style-type: none"> • Slope Documentation / Acceptability 	<ul style="list-style-type: none"> • Slope acceptable range indicated on benchsheet² 	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
<ul style="list-style-type: none"> • Buffer Expiration Date 	<ul style="list-style-type: none"> • Buffers must not be expired 	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
<ul style="list-style-type: none"> • Other 	<ul style="list-style-type: none"> • Instrument manual available 	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	<ul style="list-style-type: none"> • Teflon covered magnetic stirrer or equivalent for mixing⁸ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments:

Criteria	Standard Methods Requirement	Acceptable?		Rating
Dissolved Oxygen Meter				
<ul style="list-style-type: none"> • Calibration Method 	<ul style="list-style-type: none"> • Air or known DO calibration method¹⁰ 	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	A
	<ul style="list-style-type: none"> • Calibration per manufacturer specification¹⁰ 	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	
<ul style="list-style-type: none"> • Calibration Frequency / Documentation 	<ul style="list-style-type: none"> • Logbook maintained² 	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	<ul style="list-style-type: none"> • Calibration verification required at least once each day the meter is used.³ 	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	
<ul style="list-style-type: none"> • Other 	<ul style="list-style-type: none"> • Small to no bubble present under membrane (must be smaller than the lead in number 2 pencil)¹¹ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	<ul style="list-style-type: none"> • Instrument manual available 	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments: YSI 550A D.O. meter is used. It autocalibrates after being turned on. If it is not in calibration, an error reading is shown so corrective action can be taken. It does not use the typical fluid filled membrane.

General Lab Criteria

Criteria	Standard Methods Requirement		Rating
Incubator (CBOD/ E-Coli)	Acceptable?		
<ul style="list-style-type: none"> • Temperature Recordkeeping 	<ul style="list-style-type: none"> • Temperature checked / recorded twice daily for each shelf in use¹(E-Coli) 	<input type="checkbox"/> Yes	<input type="checkbox"/> No
	<ul style="list-style-type: none"> • Temperature checked / recorded daily² (CBOD) 	<input type="checkbox"/> Yes	<input type="checkbox"/> No
	<ul style="list-style-type: none"> • Acceptable temperature range (CBOD) is 20° C ±1.0 °¹² 	<input type="checkbox"/> Yes	<input type="checkbox"/> No
	<ul style="list-style-type: none"> • Acceptable temperature range (E-Coli) is 35° C ±0.5 °²² 	<input type="checkbox"/> Yes	<input type="checkbox"/> No
	<ul style="list-style-type: none"> • Logbook maintained ² 	<input type="checkbox"/> Yes	<input type="checkbox"/> No
<ul style="list-style-type: none"> • Temperature Calibration / Documentation 	<ul style="list-style-type: none"> • Thermometer calibrated annually with NIST traceable thermometer^{1,2} 	<input type="checkbox"/> Yes	<input type="checkbox"/> No
	<ul style="list-style-type: none"> • Temperature correction information posted on incubator¹ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No
<ul style="list-style-type: none"> • E-Coli can use multiple tubes (five 20 ml or ten 10 ml), or mfg's multi-well tray 	<ul style="list-style-type: none"> • E-coli Ultraviolet lamp (365 nm wave length, 6 W bulb) ²³ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No
	<ul style="list-style-type: none"> • Other 	<ul style="list-style-type: none"> • Instrument manual available 	<input type="checkbox"/> Yes
<ul style="list-style-type: none"> • Temperature Log (thermometer accurate to 0.5 Celsius).¹ 		<input type="checkbox"/> Yes	<input type="checkbox"/> No

Comments :

Criteria	Standard Methods Requirement		Rating
Refrigerator	Acceptable?		
<ul style="list-style-type: none"> • Temperature Recordkeeping 	<ul style="list-style-type: none"> • Temperature Log (thermometer accurate to 0.5 Celsius).⁵ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No
<ul style="list-style-type: none"> • Temperature Calibration / Documentation 	<ul style="list-style-type: none"> • Thermometer calibrated annually with NIST traceable thermometer^{1,2} 	<input type="checkbox"/> Yes	<input type="checkbox"/> No
<ul style="list-style-type: none"> • Other 	<ul style="list-style-type: none"> • Thermometer held in water bath. ¹ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No
	<ul style="list-style-type: none"> • Refrigerator temperature ≤6° Celsius.¹³ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No
	<ul style="list-style-type: none"> • Do not store volatile solvents, food, or beverages.¹⁴ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No

Comments:

General Lab Criteria

Criteria	Standard Methods Requirement	Acceptable?		Rating
Chlorine Meter				
• Calibration Frequency / Documentation	• pH / millivolt meter read to 0.1 mV ¹⁵	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Calibration verification required for testing over long period of time (e.g. 12 hrs.), or after a large number of samples (every 10 samples) ³	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Calibration Method	• Calibration using three iodate solutions 0.2, 1.0, 5.0 milliliters or calibration per manufacturer specification ¹⁶	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Standards used for calibration not expired	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Slope Documentation / Acceptability	• Calibration curve (acceptable slope)	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Other	• Electrode free of deposits and foreign material	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Log book being maintained. ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Instrument manual available	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
Comments: :				

Criteria	Standard Methods Requirement	Acceptable?		Rating
Ammonia Meter				
• Calibration Frequency / Documentation	• Calibration verification required for testing over long period of time (e.g. 12 hrs.), or after a large number of samples (every 10 samples) ³	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Log book being maintained ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Slope acceptability	• Verify calibration slope is acceptable (per mfg. spec.).	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Calibration Method	• Standards used for calibration (3 ammonia solutions of 10 mg/l, 1 mg/l, and 0.1 mg/l) or per mfg. spec. ¹⁷	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Standards used for calibration not expired	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Other	• Electrode free of deposits and foreign material	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Teflon covered magnetic stirrer or equivalent for mixing ¹⁸	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Instrument manual available	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
Comments: :				

General Lab Criteria

Criteria	Standard Methods Requirement	Acceptable?		Rating
Sample Collection/Handling				
• Sample Labeling	• Samples container labeled (description, date, time, preservative added, initialed). ¹⁹	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	M
• Chain of Custody	• Chain of custody (description, date, time, signature). ¹⁹	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	
• Other	• Composite samples refrigerated during sample collection ¹⁴	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Equipment blanks utilized ¹⁴	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• SOP for cleaning of sampling equipment	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Logbook being maintained ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments: Belmont bottles are pre-labeled. D.O. and temperature are taken in situ, so no sample bottles are required for those parameters. A Coleman cooler filled with ice is used for composite sampling. Standard operating procedures for sample collection and for analysis done on-site (D.O. and temperature) need to be developed.

Criteria	Standard Methods Requirement	Acceptable?		Rating
Desiccator				
• General criteria	• Properly working seals.	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Desiccant fresh (blue color)	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Documentation	• Log book being maintained ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments:

Criteria	Standard Methods Requirement	Acceptable?		Rating
Bench sheets				
• General criteria	• Date(s) ²	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	A
	• Analyst initials ²	<input type="checkbox"/> Yes	<input checked="" type="checkbox"/> No	
	• Blue or black ink pen ²	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Calibration information ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Equations, calculations, units for all measurements, notations, and results present ²	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Corrections, single line through, initialed and dated ²	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments: Blank 4500 forms are used for bench sheets. The log book indicates who took the samples. The bench sheets will be initialed in the future to show who took the samples.

General Lab Criteria

General Lab Criteria

Criteria	Standard Methods Requirement	Acceptable?		Rating
Hot Water Bath (Fecal Coliform/E. Coli)				
<ul style="list-style-type: none"> • Temperature Recordkeeping 	<ul style="list-style-type: none"> • Temperature Log (thermometer accurate to 0.2° C)²¹ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
		<ul style="list-style-type: none"> • Incubator temperature 44.5° C ± 0.2°^{21/24} 		
<ul style="list-style-type: none"> • Temperature Calibration / Documentation 	<ul style="list-style-type: none"> • Thermometer calibrated annually with NIST traceable thermometer^{1,2} 	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
		<ul style="list-style-type: none"> • Log book being maintained² 	<input type="checkbox"/> Yes	
<ul style="list-style-type: none"> • Water Level 	<ul style="list-style-type: none"> • Thermometer total immersion or partial (line on thermometer to ID immersion depth)^{1,5} 	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
Comments:				
Criteria	Standard Methods Requirement	Acceptable?		Rating
Autoclaves/Steam Sterilizers				
<ul style="list-style-type: none"> • All apparatus utilized is adequately sterilized before use 	<ul style="list-style-type: none"> • Sterilizing temperature 121° C²⁵ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
		<ul style="list-style-type: none"> • 10 to 30 minutes time based on material being sterilized²⁶ 	<input type="checkbox"/> Yes	
<ul style="list-style-type: none"> • Documentation 	<ul style="list-style-type: none"> • Verify the autoclave temperature weekly by using a maximum registering thermometer (MRT) to confirm that 121°C has been reached as measured in the exhaust.¹ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
		<ul style="list-style-type: none"> • Date, contents, sterilization time and temperature, total time in autoclave, and analyst's initials should be recorded each time the autoclave is used¹ 	<input type="checkbox"/> Yes	
<ul style="list-style-type: none"> • Temperature Calibration / Documentation 	<ul style="list-style-type: none"> • Thermometer calibrated annually with NIST traceable thermometer^{1,2} 	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
		<ul style="list-style-type: none"> • Log book being maintained² 	<input type="checkbox"/> Yes	
<ul style="list-style-type: none"> • Performance Checks 	<ul style="list-style-type: none"> • Test monthly for efficacy using a biological such as commercially available <i>Geobacillus stearothermophilus</i> in spore strips, suspensions, or capsules¹ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
Comments:				

General Lab Criteria

Criteria	Standard Methods Requirement	Acceptable?	Rating
Final Effluent Temperature Monitoring			
<ul style="list-style-type: none"> • General Criteria 	<ul style="list-style-type: none"> • Thermometer calibrated annually with NIST traceable thermometer ^{1,2} 	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	M
	<ul style="list-style-type: none"> • Thermometer accurate to 0.1° Celsius⁵ 	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No	
	<ul style="list-style-type: none"> • Log book being maintained ² 	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	
Comments: An NIST thermometer that measures in whole degrees is currently used. It will be replaced by one that measures in 0.1 degree Celsius.			
Number of Criteria Rated:			
			Acceptable 2
			Marginal 2
			Unacceptable 0
			Total Number of Areas Rated 4
Acceptable Ratings – No action required (recommend SOP's written or updated, perform DMRQA's for all onsite analysis, recommend voluntary lab analyst certification, written response not required).			
Marginal Ratings – Improvements required, written response required (recommend SOP's be written or updated, recommend they perform DMRQA's for all onsite analysis, recommend voluntary lab analyst certification, require deficiencies to be addressed in written response).			
Unsatisfactory Rating - Improvements required, written response required, NOV issued (recommend SOP's be written or updated, recommend they perform DMRQA's for all onsite analysis, recommend voluntary lab analyst certification, require deficiencies to be addressed in written response to NOV).			
Consider recommending PAI Audit from DES when:	>60% of ratings are Marginal >45% of ratings are a combination of Marginal or Unacceptable >30% of ratings are Unacceptable		

Notation of Referenced Method

- | | |
|----------------------------|------------------------------|
| 1 Method 9020-B, Item 3 | 14 Method 1060A, Item 1 |
| 2 Method 1020-A, Item 1 | 15 Method 4500-CI I, Item 2 |
| 3 Method 1020-B, Item 10 | 16 Method 4500-CI I, Item 4 |
| 4 Method 2540-B, Item 2 | 17 Method 4500-NH3 D, Item 4 |
| 5 Method 2550-B, Item 1 | 18 Method 4500-NH3 D, Item 2 |
| 6 Method 1020-A, Item 1 | 19 Method 1060-B, Item 2 |
| 7 Method 4500-H B, Item 4 | 20 Method 1060-B, Item 1 |
| 8 Method 4500-H B, Item 2 | 21 Method 9222D, Item 1 |
| 9 Method 1020-B, Item 2 | 22 Method 9223 B, Item 2 |
| 10 Method 4500-O B, Item 3 | 23 Method 9223 B, Item 3 |
| 11 Method 4500-O G, Item 3 | 24 Method 1603, Item 2 |
| 12 Method 5210-B, Item 5 | 25 Method 9030-B, Item 3 |
| 13 CFR 136.3, Table II | 26 Method 9020 B, Table IV |

General Lab Criteria

Equipment Logbook Content - all maintenance performed on a piece of equipment should be documented in the logbook. This should include parts replacement and routine maintenance activities. Entries should include date, maintenance performed and initials of person making entry.

Preservation and Holding Times						
Parameter	Container	Min. Sample Size (mL)	Sample Type	Preservation	Maximum Storage Time	
					Recommended	Regulatory
BOD / CBOD	P, G	1000	G, C	Refrigerate $\leq 6^{\circ}\text{C}$	6h	48h
TSS	P, G	200	G, C	Refrigerate $\leq 6^{\circ}\text{C}$	7 d	7 d
pH	P, G	50	G	Analyze immediately	0.25h	0.25 h
NH ₃ -N	P, G	500	G, C	Analyze as soon as possible or add H ₂ SO ₄ to pH <2, Refrigerate $\leq 6^{\circ}\text{C}$	7 d	28 d
TRC	P, G	500	G	Analyze immediately	0.25h	0.25 h
DO (electrode)	G, BOD Bottle	300	G	Analyze immediately	0.25h	0.25 h
Temperature	P, G	--	G	Analyze immediately	0.25h	0.25 h
Metals, general	P, G	1000	G, C	For dissolved filter immediately and add HNO ₃ to pH <2	6 months	6 months
Purgeables by purge and trap	G (PTFE lined lid)	40 (X2)	G	HCl to pH<2, Refrigerate $\leq 6^{\circ}\text{C}$	7 d	14 d
Base/Neutrals and acids	G (solvent rinsed or baked)	1000	C, G	Refrigerate $\leq 6^{\circ}\text{C}$	7 d	7 days until extraction 40 days after extraction
Pesticides	G (PTFE lined lid)	1000	C	Refrigerate $\leq 6^{\circ}\text{C}$	7 d	7 days until extraction 40 days after extraction
Fecal Coliform / E-Coli	G, P (Sterilized)	100	G	Refrigerate $\leq 10^{\circ}\text{C}$ If chlorine present, add sodium thiosulfate tablet	6 hrs transport Start analysis within 2 hrs of receipt in lab.	
Oil and Grease	G	1000	G	HCl or H ₂ SO ₄ to pH <2, Refrigerate $\leq 6^{\circ}\text{C}$	28 d	28 d

Approved Standard Methods	
CBOD / BOD 5 Day	Std Methods 5210-B
Ammonia, Selective Electrode Method	Std Methods 4500-NH ₃ D
Total Residual Chlorine, DPD Colorimetric Method	Std Methods 4500-Cl G
Total Suspended Solids, Dried at 103-105 °C	Std Methods 2540-D
Dissolved Oxygen, Membrane Electrode Method	Std Method 4500-O G
pH, Electrometric Method	Std Methods 4500-H+ B
Fecal Coliform, Membrane Filter Procedure	Std Methods 9222D
Escherichia Coli, Enzyme Substrate Test	Std Method 9223B
Escherichia Coli Membrane Filtration Procedure	EPA Method 1603
Oil and Grease	USEPA 1664A or Std Methods 5520B
Metals, general	USEPA 200, Std Methods 3111B or C, or 3120B
Volatiles (Purgeables by purge and trap)	USEPA 6210, Std Methods 624
Semi-Volatiles (Base/Neutrals and acids)	USEPA 6410, Std Methods 625
Pesticides	USEPA 6410 and 6630, Std Methods 608