



Environmental
Protection Agency

John R. Kasich, Governor
Mary Taylor, Lt. Governor
Scott J. Nally, Director

April 24, 2012

Mr. John Butler
Rumpke Sanitary Landfill, Inc.
10795 Hughes Road
Cincinnati, Ohio 45251

**RE: Compliance Evaluation Inspection
Rumpke Sanitary Landfill, Inc.
Permit Number 1IN00180**

Dear Mr. Butler:

On April 20, 2012, I conducted a Compliance Evaluation Inspection at Rumpke Sanitary Landfill. A copy of the inspection report is enclosed. The inspection report contains no marginal or unsatisfactory ratings.

If you have any questions or comments concerning the contents of this letter, please feel free to contact me at (937) 285-6103.

Sincerely,

Maureen M. Ware
Environmental Specialist
Division of Surface Water

enclosure

MMW/tf

ec: Hamilton County Health Department



State of Ohio Environmental Protection Agency
Southwest District Office

NPDES Compliance Inspection Report

Section A: National Data System Coding					
Permit #	NPDES#	Month/Day/Year	Inspection Type	Inspector	Facility Type
1IN00180	OH0112534	04/20/12	C	S	2

Section B: Facility Data		
Name and Location of Facility Inspected	Entry Time	Permit Effective Date
Rumpke Sanitary Landfill 10795 Hughes Rd. Cincinnati, Ohio	10:30AM	6/1/10
	Exit Time	Permit Expiration Date
	1:15 PM	5/31/15
Name(s) and Title(s) of On-Site Representatives	Phone Number(s)	
John Butler, Senior Site Engineer	513-851-0122 ext 3152	
Name, Address and Title of Responsible Official	Phone Number	
Rumpke Sanitary Landfill 10795 Hughes Rd. Cincinnati, Ohio		

Section C: Areas Evaluated During Inspection					
(S = Satisfactory, M = Marginal, U = Unsatisfactory, N = Not Evaluated)					
S	Permit	S	Flow Measurement	N	Pretreatment
S	Records/Reports	S	Laboratory	N	Compliance Schedule
S	Operations & Maintenance	S	Effluent/Receiving Waters	S	Self-Monitoring Program
S	Facility Site Review	N	Sludge Storage/Disposal	N	Other
N	Collection System				

Section D: Summary of Findings (Attach additional sheets if necessary)	
As noted in the General Laboratory Criteria, an NIST traceable thermometer should be used to calibrate the effluent thermometer annually.	
Inspector	Reviewer
 Maureen M. Ware Division of Surface Water Southwest District Office Date: 4/24/12	 Martyn G. Burt Environmental Supervisor Division of Surface Water Southwest District Office Date: 4/24/12

Sections E thru J: Complete on all inspections as appropriate
Y – Yes, N – No, N/A – Not Applicable, N/E – Not Evaluated

Section E: Permit Verification

Inspection observations verify the permit

- (a) Correct name and mailing address of permittee Y
- (b) Correct name and location of receiving waters..... Y
- (c) Do Categorical Standards apply?...If yes, list applicable standards.. Y

4953
- (d) Product(s) and production rates conform with permit application (Industries)..... N/A
- (e) Flows and loadings conform with NPDES permit..... Y
- (f) Treatment processes are as described in permit application... Y
- (g) All discharges are permitted..... Y
- (h) Number and location of discharge points are as described in permit..... Y
- (i) Storm water discharges properly permitted..... Y

Comments/Status:

Section F: Compliance

- (a) Any significant violations since the last inspection..... N
- (b) Appropriate Non-compliance notification of violations..... Y
- (c) Permittee is taking actions to resolve violations..... Y
- (d) Permittee has a compliance schedule..... N/A
- (e) Compliance schedule contained in..... N/A
- (f) Permittee is in compliance with schedule..... N/A
- (g) Has biomonitoring shown toxicity in discharge since last inspection N

Comments/Status:

Compliance evaluated from January 1, 2010 through February 29, 2012.

Violations reported:

Station Code	Parameter	Type	Limit	Reported	Date
001	00530 TSS	1D Conc	65	90	8/17/2010
001	00530 TSS	1D Conc	65	88	6/8/2011

Section H: Self-Monitoring Program

Flow Measurement:

- (a) Primary/Secondary flow measuring devices operated and maintained..... Y
Type of device (e.g. weir with ultrasonic level sensor):
- (b) Calibration frequency adequate Y
(Date of last calibration: 9/11/2011)
- (c) 24-hour recording instruments operated and maintained..... N/A
- (d) Flow measurement equipment adequate to handle full range of flows..... Y
- (e) Actual flow discharged is measured..... Y
- (f) Flow measuring equipment inspection frequency
Daily Weekly monthly other

Comments/Status:

Inspected when discharging.

Sampling:

- (a) Sampling location(s) are as specified by permit..... Y
- (b) Parameters and sampling frequency agree with permit..... Y
- (c) Permittee uses required sampling method..... Y
(see GLC page)
- (d) Monitoring records (i.e., flow, pH, DO) maintained for a minimum of three years including all original strip chart recordings (i.e, continuous monitoring instrumentation, calibration and maintenance records)..... Y

Comments/Status:

Section H: Self-Monitoring Program (con't)

Laboratory:

General

- (a) Does the Quality Assurance Manual contain written Standard Operating Procedures (SOP's) for all analysis performed onsite..... Y
- (b) Do SOP's include the following if applicable..... Y
 - Title
 - Scope and Application
 - Summary
 - Sample Handling and Preservation
 - Interferences
 - Apparatus and Materials
 - Reagents
 - Procedure
 - Calculations
 - Quality Control
 - Maintenance
 - Corrective Action
 - Reference (Parent Method)

Note: Standard Methods 1020A establishes that "Quality assurance (QA) is the definitive program for laboratory operation that specifies the measure required to produce defensible data of known precision and accuracy. Standard operating procedures are to be used in the laboratory in sufficient detail that a competent analyst unfamiliar with the method can conduct a reliable review and/or obtain acceptable results." SOPs should be developed for each analytical procedure.

- (c) EPA approved analytical testing procedures used (40 CFR 136.3).. Y
- (d) If alternate analytical procedures are used, proper approval has been obtained..... N/A
- (e) Analyses being performed more frequently than required by permit. N
- (f) If (e) is yes, are results in permittee's self-monitoring report..... N/A
- (g) Satisfactory calibration and maintenance of instruments/equipment. Y (see score from GLC page)
- (h) Commercial laboratory used..... Y
Parameters analyzed by commercial lab: everything except temperature, pH, and conductivity

Lab name: Test America and Belmont

Discharge Monitoring Report Quality Assurance (DMRQA)

- (a) Participation in latest USEPA quality assurance performance sampling..... N/A
Date:
- (b) Were any parameters "Unsatisfactory"..... N/A
- (c) Reasons for "Unsatisfactory" parameters.....

Comments/Status:

Section I: Effluent/Receiving Water Observations

Outfall # 004
Outfall Description: pipe
Receiving Stream: Banklick Creek
Receiving Stream Description: slightly cloudy

Comments/Status:

To make capacity in the pond for the rainfall expected Friday evening, the pond to outfall 004 was being pumped down. The discharge was slightly cloudy. The pond to outfall 001 was not being pumped at that time.

Section J: Multimedia Observations

- (a) Are there indications of sloppy housekeeping or poor maintenance in work and storage areas or laboratories..... N
- (b) Do you notice staining or discoloration of soils, pavement or floors.. N
- (c) Do you notice distressed (unhealthy, discolored, dead) vegetation.. N
- (d) Do you see unidentified dark smoke or dust clouds coming from sources other than smokestacks..... N
- (e) Do you notice any unusual odors or strong chemical smells..... N
- (f) Do you see any open or unmarked drums, unsecured liquids, or damaged containment facilities..... N

If any of the above are observed, ask the following questions:
(1) What is the cause of the condition?
(2) Is the observed condition or source a waste product?
(3) Where is the suspected contaminant normally disposed?
(4) Is this disposal permitted?
(5) How long has the condition existed and when did it begin?

Comments/Status:

General Lab Criteria

Criteria	Standard Methods Requirement	Acceptable?		Rating
Balance				
• Standard Weights	• Either NIST Class s or ASTM/ANSI Class 1 weights ^{1,2}	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Calibration Frequency / Documentation	• Calibration verification required at least once each day the balance is used. ³	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Cleanliness, air movement, vibration	• Cleanliness of balance is a must and air movement and vibration needs to be kept to a minimum ¹	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Other	• Service and recalibrate annually (manufacturer representative or comparable) ¹	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Must be able to measure to 0.1 grams ⁴	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Instrument manual available	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Log book maintained ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
Comments: :				
Criteria	Standard Methods Requirement	Acceptable?		Rating
Drying Oven (Suspended Solids)				
• Temperature Recordkeeping	• Temperature recorded with each use ⁴	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Log book maintained ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Calibration Frequency / Documentation	• Thermometer calibrated annually with NIST traceable thermometer ^{1,2} . Correction factor posted on thermometer / equipment ¹	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Other	• Thermometer temperature accurate to 0.5° Celsius ⁵	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Acceptable temperature range is 103° – 105° C ⁴	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Instrument manual available	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
Comments: :				

General Lab Criteria

Criteria	Standard Methods Requirement	Acceptable?		Rating	
pH Meter					
<ul style="list-style-type: none"> • Calibration Frequency / Documentation 	<ul style="list-style-type: none"> • Calibration verification required for testing over long period of time (e.g. 12 hrs.), or after a large number of samples (every 10 samples)³ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No		
	<ul style="list-style-type: none"> • Logbook maintained² 	<input type="checkbox"/> Yes	<input type="checkbox"/> No		
<ul style="list-style-type: none"> • Minimum of 2 point calibration 	<ul style="list-style-type: none"> • Calibration per manufacturer specification and calibration buffers must bracket anticipated result⁷ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No		
<ul style="list-style-type: none"> • Slope Documentation / Acceptability 	<ul style="list-style-type: none"> • Slope acceptable range indicated on benchsheet² 	<input type="checkbox"/> Yes	<input type="checkbox"/> No		
<ul style="list-style-type: none"> • Buffer Expiration Date 	<ul style="list-style-type: none"> • Buffers must not be expired 	<input type="checkbox"/> Yes	<input type="checkbox"/> No		
<ul style="list-style-type: none"> • Other 	<ul style="list-style-type: none"> • Instrument manual available 	<input type="checkbox"/> Yes	<input type="checkbox"/> No		
	<ul style="list-style-type: none"> • Teflon covered magnetic stirrer or equivalent for mixing⁸ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No		
Comments: : <div style="border: 1px solid black; height: 150px; margin-top: 5px;"></div>					
Dissolved Oxygen Meter					
Dissolved Oxygen Meter					
<ul style="list-style-type: none"> • Calibration Method 	<ul style="list-style-type: none"> • Air or known DO calibration method¹⁰ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No		
	<ul style="list-style-type: none"> • Calibration per manufacturer specification¹⁰ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No		
<ul style="list-style-type: none"> • Calibration Frequency / Documentation 	<ul style="list-style-type: none"> • Logbook maintained² 	<input type="checkbox"/> Yes	<input type="checkbox"/> No		
	<ul style="list-style-type: none"> • Calibration verification required at least once each day the meter is used.³ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No		
<ul style="list-style-type: none"> • Other 	<ul style="list-style-type: none"> • Small to no bubble present under membrane (must be smaller than the lead in number 2 pencil)¹¹ 	<input type="checkbox"/> Yes	<input type="checkbox"/> No		
	<ul style="list-style-type: none"> • Instrument manual available 	<input type="checkbox"/> Yes	<input type="checkbox"/> No		
Comments: <div style="border: 1px solid black; height: 150px; margin-top: 5px;"></div>					

General Lab Criteria

Criteria	Standard Methods Requirement		Rating
Incubator (CBOD/ E-Coli)		Acceptable?	
• Temperature Recordkeeping	• Temperature checked / recorded twice daily for each shelf in use ¹ (E-Coli)	<input type="checkbox"/> Yes	<input type="checkbox"/> No
	• Temperature checked / recorded daily ² (CBOD)	<input type="checkbox"/> Yes	<input type="checkbox"/> No
	• Acceptable temperature range (CBOD) is 20° C ±1.0° ¹²	<input type="checkbox"/> Yes	<input type="checkbox"/> No
	• Acceptable temperature range (E-Coli) is 35° C ±0.5° ²²	<input type="checkbox"/> Yes	<input type="checkbox"/> No
	• Logbook maintained ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No
• Temperature Calibration / Documentation	• Thermometer calibrated annually with NIST traceable thermometer ^{1,2}	<input type="checkbox"/> Yes	<input type="checkbox"/> No
	• Temperature correction information posted on incubator ¹	<input type="checkbox"/> Yes	<input type="checkbox"/> No
• E-Coli can use multiple tubes (five 20 ml or ten 10 ml), or mfg's multi-well tray	• E-coli Ultraviolet lamp (365 nm wave length, 6 W bulb) ²³	<input type="checkbox"/> Yes	<input type="checkbox"/> No
• Other	• Instrument manual available	<input type="checkbox"/> Yes	<input type="checkbox"/> No
	• Temperature Log (thermometer accurate to 0.5 Celsius). ¹	<input type="checkbox"/> Yes	<input type="checkbox"/> No

Comments :

Criteria	Standard Methods Requirement		Rating
Refrigerator		Acceptable?	
• Temperature Recordkeeping	• Temperature Log (thermometer accurate to 0.5 Celsius). ⁵	<input type="checkbox"/> Yes	<input type="checkbox"/> No
• Temperature Calibration / Documentation	• Thermometer calibrated annually with NIST traceable thermometer ^{1,2}	<input type="checkbox"/> Yes	<input type="checkbox"/> No
	• Thermometer held in water bath. ¹	<input type="checkbox"/> Yes	<input type="checkbox"/> No
• Other	• Refrigerator temperature ≤6° Celsius. ¹³	<input type="checkbox"/> Yes	<input type="checkbox"/> No
	• Do not store volatile solvents, food, or beverages. ¹⁴	<input type="checkbox"/> Yes	<input type="checkbox"/> No

Comments:

General Lab Criteria

Criteria	Standard Methods Requirement	Acceptable?		Rating
Chlorine Meter				
• Calibration Frequency / Documentation	• pH / millivolt meter read to 0.1 mV ¹⁵	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Calibration verification required for testing over long period of time (e.g. 12 hrs.), or after a large number of samples (every 10 samples) ³	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Calibration Method	• Calibration using three iodate solutions 0.2, 1.0, 5.0 milliliters or calibration per manufacturer specification ¹⁶	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Standards used for calibration not expired	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Slope Documentation / Acceptability	• Calibration curve (acceptable slope)	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Other	• Electrode free of deposits and foreign material	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Log book being maintained. ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Instrument manual available	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
Comments: :				

Criteria	Standard Methods Requirement	Acceptable?		Rating
Ammonia Meter				
• Calibration Frequency / Documentation	• Calibration verification required for testing over long period of time (e.g. 12 hrs.), or after a large number of samples (every 10 samples) ³	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Log book being maintained ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Slope acceptability	• Verify calibration slope is acceptable (per mfg. spec.).	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Calibration Method	• Standards used for calibration (3 ammonia solutions of 10 mg/l, 1 mg/l, and 0.1 mg/l) or per mfg. spec. ¹⁷	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Standards used for calibration not expired	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Other	• Electrode free of deposits and foreign material	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Teflon covered magnetic stirrer or equivalent for mixing ¹⁸	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Instrument manual available	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
Comments: :				

General Lab Criteria

Criteria	Standard Methods Requirement	Acceptable?		Rating
Sample Collection/Handling				A
• Sample Labeling	• Samples container labeled (description, date, time, preservative added, initialed). ¹⁹	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	
• Chain of Custody	• Chain of custody (description, date, time, signature). ¹⁹	<input checked="" type="checkbox"/> Yes	<input type="checkbox"/> No	
• Other	• Composite samples refrigerated during sample collection ¹⁴	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Equipment blanks utilized ¹⁴	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• SOP for cleaning of sampling equipment	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Logbook being maintained ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments:

Criteria	Standard Methods Requirement	Acceptable?		Rating
Desiccator				
• General criteria	• Properly working seals.	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Desiccant fresh (blue color)	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Documentation	• Log book being maintained ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments:

Criteria	Standard Methods Requirement	Acceptable?		Rating
Bench sheets				
• General criteria	• Date(s) ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Analyst initials ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Blue or black ink pen ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Calibration information ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Equations, calculations, units for all measurements, notations, and results present ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Corrections, single line through, initialed and dated ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments: Rumpke documents everything on chain of custody forms.

General Lab Criteria

Criteria	Standard Methods Requirement	Acceptable?		Rating
Hot Water Bath (Fecal Coliform/E. Coli)				
• Temperature Recordkeeping	• Temperature Log (thermometer accurate to 0.2° C) ²¹	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Incubator temperature 44.5° C ± 0.2° ^{21/24}			
• Temperature Calibration / Documentation	• Thermometer calibrated annually with NIST traceable thermometer ^{1,2}	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Log book being maintained ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Water Level	• Thermometer total immersion or partial (line on thermometer to ID immersion depth) ^{1,5}	<input type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments:

Criteria	Standard Methods Requirement	Acceptable?		Rating
Autoclaves/Steam Sterilizers				
• All apparatus utilized is adequately sterilized before use	• Sterilizing temperature 121° C ²⁵	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• 10 to 30 minutes time based on material being sterilized ²⁶	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Documentation	• Verify the autoclave temperature weekly by using a maximum registering thermometer (MRT) to confirm that 121°C has been reached as measured in the exhaust. ¹	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Date, contents, sterilization time and temperature, total time in autoclave, and analyst's initials should be recorded each time the autoclave is used ¹	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Temperature Calibration / Documentation	• Thermometer calibrated annually with NIST traceable thermometer ^{1,2}	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
	• Log book being maintained ²	<input type="checkbox"/> Yes	<input type="checkbox"/> No	
• Performance Checks	• Test monthly for efficacy using a biological such as commercially available <i>Geobacillus stearothermophilus</i> in spore strips, suspensions, or capsules ¹	<input type="checkbox"/> Yes	<input type="checkbox"/> No	

Comments:

General Lab Criteria

Criteria	Standard Methods Requirement		Rating
Final Effluent Temperature Monitoring	Acceptable?		
• General Criteria	• Thermometer calibrated annually with NIST traceable thermometer ^{1,2}	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No	M
	• Thermometer accurate to 0.1° Celsius ⁵	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	
	• Log book being maintained ²	<input type="checkbox"/> Yes <input type="checkbox"/> No	
Comments: Rumpke uses water of a known temperature to calibrate thermometer. A NIST thermometer should be used to calibrate the thermometer.			
Number of Criteria Rated:			Acceptable
			1
			Marginal
			1
			Unacceptable
			0
			Total Number of Areas Rated
			2
Acceptable Ratings – No action required (recommend SOP's written or updated, perform DMRQA's for all onsite analysis, recommend voluntary lab analyst certification, written response not required).			
Marginal Ratings – Improvements required, written response required (recommend SOP's be written or updated, recommend they perform DMRQA's for all onsite analysis, recommend voluntary lab analyst certification, require deficiencies to be addressed in written response).			
Unsatisfactory Rating - Improvements required, written response required, NOV issued (recommend SOP's be written or updated, recommend they perform DMRQA's for all onsite analysis, recommend voluntary lab analyst certification, require deficiencies to be addressed in written response to NOV).			
Consider recommending PAI Audit from DES when:	>60% of ratings are Marginal >45% of ratings are a combination of Marginal or Unacceptable >30% of ratings are Unacceptable		

Notation of Referenced Method

- | | |
|----------------------------|------------------------------|
| 1 Method 9020-B, Item 3 | 14 Method 1060A, Item 1 |
| 2 Method 1020-A, Item 1 | 15 Method 4500-CI I, Item 2 |
| 3 Method 1020-B, Item 10 | 16 Method 4500-CI I, Item 4 |
| 4 Method 2540-B, Item 2 | 17 Method 4500-NH3 D, Item 4 |
| 5 Method 2550-B, Item 1 | 18 Method 4500-NH3 D, Item 2 |
| 6 Method 1020-A, Item 1 | 19 Method 1060-B, Item 2 |
| 7 Method 4500-H B, Item 4 | 20 Method 1060-B, Item 1 |
| 8 Method 4500-H B, Item 2 | 21 Method 9222D, Item 1 |
| 9 Method 1020-B, Item 2 | 22 Method 9223 B, Item 2 |
| 10 Method 4500-O B, Item 3 | 23 Method 9223 B, Item 3 |
| 11 Method 4500-O G, Item 3 | 24 Method 1603, Item 2 |
| 12 Method 5210-B, Item 5 | 25 Method 9030-B, Item 3 |
| 13 CFR 136.3, Table II | 26 Method 9020 B, Table IV |

General Lab Criteria

Equipment Logbook Content - all maintenance performed on a piece of equipment should be documented in the logbook. This should include parts replacement and routine maintenance activities. Entries should include date, maintenance performed and initials of person making entry.

Preservation and Holding Times

Parameter	Container	Min. Sample Size (mL)	Sample Type	Preservation	Maximum Storage Time	
					Recommended	Regulatory
BOD / CBOD	P, G	1000	G, C	Refrigerate $\leq 6^{\circ}\text{C}$	6h	48h
TSS	P, G	200	G, C	Refrigerate $\leq 6^{\circ}\text{C}$	7 d	7 d
pH	P, G	50	G	Analyze immediately	0.25h	0.25 h
NH3-N	P, G	500	G, C	Analyze as soon as possible or add H_2SO_4 to pH <2, Refrigerate $\leq 6^{\circ}\text{C}$	7 d	28 d
TRC	P, G	500	G	Analyze immediately	0.25h	0.25 h
DO (electrode)	G, BOD Bottle	300	G	Analyze immediately	0.25h	0.25 h
Temperature	P, G	--	G	Analyze immediately	0.25h	0.25 h
Metals, general	P, G	1000	G, C	For dissolved filter immediately and add HNO_3 to pH <2	6 months	6 months
Purgeables by purge and trap	G (PTFE lined lid)	40 (X2)	G	HCl to pH<2, Refrigerate $\leq 6^{\circ}\text{C}$	7 d	14 d
Base/Neutrals and acids	G (solvent rinsed or baked)	1000	C, G	Refrigerate $\leq 6^{\circ}\text{C}$	7 d	7 days until extraction 40 days after extraction
Pesticides	G (PTFE lined lid)	1000	C	Refrigerate $\leq 6^{\circ}\text{C}$	7 d	7 days until extraction 40 days after extraction
Fecal Coliform / E-Coli	G, P (Sterilized)	100	G	Refrigerate $\leq 10^{\circ}\text{C}$ If chlorine present, add sodium thiosulfate tablet	6 hrs transport Start analysis within 2 hrs of receipt in lab.	
Oil and Grease	G	1000	G	HCl or H_2SO_4 to pH <2, Refrigerate $\leq 6^{\circ}\text{C}$	28 d	28 d

Approved Standard Methods

CBOD / BOD 5 Day	Std Methods 5210-B
Ammonia, Selective Electrode Method	Std Methods 4500-NH3 D
Total Residual Chlorine, DPD Colorimetric Method	Std Methods 4500-Cl G
Total Suspended Solids, Dried at 103-105 °C	Std Methods 2540-D
Dissolved Oxygen, Membrane Electrode Method	Std Method 4500-O G
pH, Electrometric Method	Std Methods 4500-H+ B
Fecal Coliform, Membrane Filter Procedure	Std Methods 9222D
Escherichia Coli, Enzyme Substrate Test	Std Method 9223B
Escherichia Coli Membrane Filtration Procedure	EPA Method 1603
Oil and Grease	USEPA 1664A or Std Methods 5520B
Metals, general	USEPA 200, Std Methods 3111B or C, or 3120B
Volatiles (Purgeables by purge and trap)	USEPA 6210, Std Methods 624
Semi-Volatiles (Base/Neutrals and acids)	USEPA 6410, Std Methods 625
Pesticides	USEPA 6410 and 6630, Std Methods 608