

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3800012      PWS NAME: BERLIN WATER COMPANY**

**PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: EP002**

**STU ID: 3860522      STU NAME: BERLIN WATER CO. STU 2**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3800012 PWS NAME: BERLIN WATER COMPANY**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP003**

**STU ID: 3860523 STU NAME: BERLIN WATER CO. STU 3**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3800012 PWS NAME: BERLIN WATER COMPANY**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP004**

**STU ID: 3860524 STU NAME: BERLIN WATER CO. STU 4**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3800012 PWS NAME: BERLIN WATER COMPANY**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP005**

**STU ID: 3861443 STU NAME: BERLIN WATER CO STU 5**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

*Date CCR sent to Ohio EPA:*



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3800112 PWS NAME: BIG PRAIRIE WATER CO.**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855116 STU NAME: BIG PRAIRIE MUTUAL WATER CO**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

*Date CCR sent to Ohio EPA:*



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3800312 PWS NAME: GLENMONT VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855117 STU NAME: GLENMONT WTP**

**Effective Date: 4/18/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>REVISED - VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 4/1/2008 and 6/30/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH3800412      PWS NAME: HILLTOP GROUP HOME INC. PWS

PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: EP001

STU ID: 3855118      STU NAME: HILLTOP GROUP HOME, INC

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals:    ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:    SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3800512 PWS NAME: HOLMES COUNTY JAIL**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855119 STU NAME: HOLMES COUNTY JAIL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**  
**PWS ID: OH3800712    PWS NAME: KILLBUCK VILLAGE PWS**  
**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**  
**STU ID: 3855120    STU NAME: KILLBUCK VILLAGE**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>ARSENIC Quarterly Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>Date CCR sent to Ohio EPA:</i>				

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH3800712      PWS NAME: KILLBUCK VILLAGE PWS

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: DS000

FACILITY NAME: KILLBUCK, VILLAGE OF DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	10 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH3800812    PWS NAME: BLOOMFIELD WATER COMPANY

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001

STU ID: 3855121    STU NAME: BLOOMFIELD WATER CO

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals:    ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:    SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3800912    PWS NAME: MILLERSBURG VILLAGE PWS**

**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 3855122    STU NAME: MILLERSBURG VILLAGE**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH3800912      PWS NAME: MILLERSBURG VILLAGE PWS

PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: MILLERSBURG, VILLAGE OF DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>ASBESTOS - 1094</b>	Not Required
<b>LEAD - 1030 &amp; COPPER - 1022</b>	20 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	4 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3801012 PWS NAME: NASHVILLE VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855123 STU NAME: NASHVILLE VILLAGE**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3801112 PWS NAME: CASTLE NURSING HOMES, INC PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855124 STU NAME: CASTLE NURSING HOMES INC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

*Date CCR sent to Ohio EPA:*



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3801412    PWS NAME: WINESBURG AREA DEVELOPMENT CORPORATION**

**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 3855125    STU NAME: WINESBURG AREA DEV CORP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3801512    PWS NAME: WALNUT CREEK WATER CO.**

**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 3855126    STU NAME: WALNUT CREEK WATER CO. STU 1**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

*Date CCR sent to Ohio EPA:*

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3801512 PWS NAME: WALNUT CREEK WATER CO.**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP003**

**STU ID: 3860526 STU NAME: WALNUT CREEK WATER CO. STU 3**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH3801512      PWS NAME: WALNUT CREEK WATER CO.

PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: WALNUT CREEK WATER CO. DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>ASBESTOS - 1094</b>	Not Required
<b>LEAD - 1030 &amp; COPPER - 1022</b>	10 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	2 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3830112 PWS NAME: GRANDMAS ALPINE HOMESTEAD PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855130 STU NAME: GRANDMAS ALPINE HOMESTEAD**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3830112 PWS NAME: GRANDMAS ALPINE HOMESTEAD PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: GRANDMAS ALPINE HOMESTEAD DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**LEAD - 1030 & COPPER - 1022**

5 Sample(s) between 6/1/2008 and 9/30/2008

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

---

**Use for Sample Tracking Purposes**

---

*Lead & Copper Sample Date(s):*

*TCR Quarterly Sample Date(s):*

*Jan - Mar Sample Date(s)*

*Apr - Jun Sample Date(s)*

*Jul - Sept Sample Date(s)*

*Oct - Dec Sample Date(s)*

---

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH3830212    PWS NAME: HOMESTEAD RESTAURANT**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 3855131    STU NAME: GRANDMAS HOMESTEAD RESTAURANT**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3830712 PWS NAME: BUNKERHILL CHEESE CO.**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855133 STU NAME: BUNKER HILL CHEESE CO INC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3830712 PWS NAME: BUNKERHILL CHEESE CO.**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: BUNKERHILL CHEESE CO. DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

<b>Use for Sample Tracking Purposes</b>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH3831012    PWS NAME: CAMP TODDIK PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 3855134    STU NAME: CAMP TODDIK-WORKSHOP STU 1**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH3831012    PWS NAME: CAMP TOODIK PWS  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 3855135    STU NAME: CAMP TOODIK-RIVERTAP STU 3  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP003</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP003 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH3831012    PWS NAME: CAMP TOODIK PWS  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 3855136    STU NAME: CAMP TOODIK-PUMP HOUSE STU 2  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) Quarterly	<i>Sample should be taken at EP002</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP002 is the first tap after the well.

**Use for Sample Tracking Purposes**

Nitrate Sample Date(s):

Nitrite Sample Date(s):

TCR Quarterly Sample Date(s):

Jan - Mar Sample Date(s)

Apr - Jun Sample Date(s)

Jul - Sept Sample Date(s)

Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3831112      PWS NAME: CLARK ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 3855137      STU NAME: CLARK ELEM SCH**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3831112      PWS NAME: CLARK ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: CLARK ELEMENTARY SCHOOL DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 5/31/2008 1 Sample(s) Quarterly between 8/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

*Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.*

If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH3831312    PWS NAME: IRON PONY SALOON PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 3855138    STU NAME: IRON PONY SALOON WELL 0001**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3832312      PWS NAME: ORSCHELN PRODUCTS PWS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 3855140      STU NAME: ORSCHEIN PRODUCTS**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3832312 PWS NAME: ORSCHELN PRODUCTS PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: ORSCHELN PRODUCTS DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**LEAD - 1030 & COPPER - 1022**

Not Required

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

*Jan - Mar Sample Date(s)*

*Apr - Jun Sample Date(s)*

*Jul - Sept Sample Date(s)*

*Oct - Dec Sample Date(s)*

*TCR Quarterly Sample Date(s):*

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3832412 PWS NAME: FLAT RIDGE ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855141 STU NAME: FLAT RIDGE ELEMENTARY SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3832412 PWS NAME: FLAT RIDGE ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: FLAT RIDGE ELEMENTARY SC DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 5/31/2008 1 Sample(s) Quarterly between 8/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

*Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.*

If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3833012 PWS NAME: HOLMES COUNTY GARAGE**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855142 STU NAME: HOLMES COUNTY GARAGE**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3833012 PWS NAME: HOLMES COUNTY GARAGE**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: HOLMES COUNTY GARAGE DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

---

**Chemical Name - Code**

**Monitoring Requirements**

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

---

	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3833212      PWS NAME: HOLMES LUMBER AND BUILDING**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 3855143      STU NAME: HOLMES LUMBER AND BLDG CENTER**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) Quarterly
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
<i>NITRATE Sample Date(s):</i>				
<i>VOC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3833212      PWS NAME: HOLMES LUMBER AND BUILDING**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: HOLMES LUMBER AND BLDG DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3833312    PWS NAME: HOLMES COUNTY TRAINING CENTER**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 3855144    STU NAME: HOLMES CO TRAINING CENTER**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 4 List Below	1 Sample(s) between 4/1/2008 and 6/30/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

SOC Group 4 Chemicals: BENEZO (A) PYRENE - 2306, ENDOTHALL - 2033, DI(2-ETHYLHEXYL) - ADIPATE - 2035, DI(2-ETHYLHEXYL) - PHTHALATE - 2039

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 4 Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3833312 PWS NAME: HOLMES COUNTY TRAINING CENTER**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: HOLMES CO. TRAIN. CENTER DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**LEAD - 1030 & COPPER - 1022**

Not Required

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

---

**Use for Sample Tracking Purposes**

*Jan - Mar Sample Date(s)*

*Apr - Jun Sample Date(s)*

*Jul - Sept Sample Date(s)*

*Oct - Dec Sample Date(s)*

*TCR Quarterly Sample Date(s):*

---

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3833512    PWS NAME: HOLMESVILLE CHURCH OF CHRIST**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855146    STU NAME: HOLMESVILLE CHURCH OF CHRIST**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3833912    PWS NAME: LAKEVILLE ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 3855148    STU NAME: LAKEVILLE ELEM SCH**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals:    ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:    SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3833912 PWS NAME: LAKEVILLE ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: LAKEVILLE ELEM. SCHOOL DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 6/30/2008 1 Sample(s) Quarterly between 9/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

*Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.*

If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
--------------------------------------	---------------------------------	---------------------------------	----------------------------------	---------------------------------

---

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH3834212    PWS NAME: LONG LAKE PARK & CAMPGROUND WEST

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 3855149    STU NAME: LONG LAKE PARK & CAMPGROUND W


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 10/31/2008	<i>Sample should be taken at DS000</i>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3834312    PWS NAME: LONG LAKE PARK & CAMPGROUND EAST**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855150    STU NAME: LONG LAKE PARK & CAMPGROUND E**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3834812    PWS NAME: MOORHEAD MENNONITE CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855152    STU NAME: MOORHEAD MENNONITE CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH3835312    PWS NAME: OCTOBER HILL CAMPLOT OWN**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 3855155    STU NAME: OCTOBER HILL CAMPLOT OWN ASSN**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3835412      PWS NAME: YODER LUMBER CO. - BUCKHORN DIVISION PWS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 3855156      STU NAME: YODER LUMBER CO - BUCKHORN DIVISION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals:   ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:   SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3835412      PWS NAME: YODER LUMBER CO. - BUCKHORN DIVISION PWS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: YODER LUMBER CO. - BUCKHORN DIVISION DIS**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

## 2008 CONTAMINANT MONITORING SCHEDULE


**PWS ID: OH3835612    PWS NAME: SMITHS PLEASANT VALLEY PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 3855157    STU NAME: SMITHS PLEASANT VALLEY CAMP STU 1**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 11/30/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH3835612    PWS NAME: SMITHS PLEASANT VALLEY PWS  
 PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
 STU ID: 3860527    STU NAME: SMITHS PLEASANT VALLEY CAMP STU 2  
 Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP002</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 11/30/2008	<i>Sample should be taken at DS000</i>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP002 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH3836812    PWS NAME: SKYVIEW BAPTIST RANCH**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 3855159    STU NAME: SKYVIEW BAPTIST RANCH**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3837312    PWS NAME: TROYERS TRAIL BOLOGNA PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855161    STU NAME: TROYERS TRAIL BOLOGNA INC**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Monitoring Requirements</b>	<b>Sample Monitoring Point</b>
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH3837712    PWS NAME: KORNER KITCHEN**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 3855162    STU NAME: KORNER KITCHEN**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH3838012    PWS NAME: WALLY WORLD RESORTS INC**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 3855163    STU NAME: WALLY WORLD RESORTS INC MIDDLE**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3838312      PWS NAME: WAYNE DALTON MAIN PLANT**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 3855164      STU NAME: WAYNE DALTON MAIN PLANT**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH3838312      PWS NAME: WAYNE DALTON MAIN PLANT

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: WAYNE DALTON MAIN PLANT DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	5 Sample(s) between 6/1/2008 and 9/30/2008
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** Not Required
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes				
Lead & Copper Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH3838612    PWS NAME: WHISPERING HILLS-SOUTH

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 3855165    STU NAME: WHISPERING HILLS CAMP


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3838712 PWS NAME: WEST HOLMES MIDDLE SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855166 STU NAME: WEST HOLMES MIDDLE SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3838712 PWS NAME: WEST HOLMES MIDDLE SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: WEST HOLMES MIDDLE SCHOOL DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 6/30/2008 1 Sample(s) Quarterly between 9/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

*Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.*

If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3838912 PWS NAME: WISE ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855167 STU NAME: WISE ELEMENTARY SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3838912 PWS NAME: WISE ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: WISE ELEMENTARY SCHOOL DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 5/31/2008 1 Sample(s) Quarterly between 8/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

*Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.*

If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

<b>Use for Sample Tracking Purposes</b>				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3839219      PWS NAME: YODER LUMBER COMPANY, INC. PWS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 3855168      STU NAME: YODER LUMBER CO INC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals:   ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:   SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3839219 PWS NAME: YODER LUMBER COMPANY, INC. PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: YODER LUMBER CO., INC. DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**LEAD - 1030 & COPPER - 1022**

Not Required

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

---

*Jan - Mar Sample Date(s)*

*Apr - Jun Sample Date(s)*

*Jul - Sept Sample Date(s)*

*Oct - Dec Sample Date(s)*

*TCR Quarterly Sample Date(s):*

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3839412 PWS NAME: ZION CHRISTIAN SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855169 STU NAME: ZION CHRISTIAN SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3839412 PWS NAME: ZION CHRISTIAN SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: ZION CHRISTIAN SCHOOL DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 5/31/2008 1 Sample(s) Quarterly between 9/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

*Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.*

If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

---

*Lead & Copper Sample Date(s):*

*Jan - Mar Sample Date(s)*

*Apr - Jun Sample Date(s)*

*Jul - Sept Sample Date(s)*

*Oct - Dec Sample Date(s)*

---

*TCR Quarterly Sample Date(s):*

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH3839712    PWS NAME: ALPINE RESORT  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 3855172    STU NAME: ALPINE RESORT  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH3840012    PWS NAME: COUNTRY SIDE CHAPEL**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 3855174    STU NAME: COUNTRYSIDE CHAPEL**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3840112 PWS NAME: FRYBURG BEACHY CHURCH**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 3855175 STU NAME: FRYBURG BEACHY CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH3840212    PWS NAME: GRAY RIDGE CHURCH PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 3855176    STU NAME: GRAY RIDGE CHURCH


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3840612    PWS NAME: HOPEWELL PRESBYTERIAN CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855179    STU NAME: HOPEWELL PRESBYTERIAN CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3840812    PWS NAME: LONGENECKER MENNONITE CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855180    STU NAME: LONGENECKER MENNONITE CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3841012    PWS NAME: MARTINS CREEK MENNONITE CHURCHPWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855181    STU NAME: MARTINS CREEK MENNONITE CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE


**PWS ID: OH3841212    PWS NAME: PLEASANT VIEW MENNONITE**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 3855182    STU NAME: PLEASANT VIEW MENNONITE CHURCH**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH3841312    PWS NAME: RIPLEY CHURCH OF CHRIST

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 3855183    STU NAME: RIPLEY CHURCH OF CHRIST


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH3841512    PWS NAME: LIVING WORD FELLOWSHIP PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 3855184    STU NAME: LIVING WORD FELLOWSHIP


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH3841712    PWS NAME: ZION MENNONITE CHURCH

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 3855186    STU NAME: ZION MENNONITE CHURCH


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH3841912    PWS NAME: LAKEVILLE UNITED METHODIST**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 3855187    STU NAME: LAKEVILLE UNITED METHODIST CHURCH**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3842012 PWS NAME: CHARM ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855188 STU NAME: CHARM ELEMENTARY SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3842012 PWS NAME: CHARM ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: CHARM ELEMENTARY SCHOOL DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 6/30/2008 1 Sample(s) Quarterly between 9/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

*Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.*

If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

---

**Use for Sample Tracking Purposes**

	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

---

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3842112    PWS NAME: PENIEL FELLOWSHIP CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855189    STU NAME: PENIEL FELLOWSHIP CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3842212      PWS NAME: HOLMESVILLE ELEMENTARY**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 3855190      STU NAME: HOLMESVILLE ELEMENTARY**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 3/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 4 List Below	1 Sample(s) between 4/1/2008 and 6/30/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

SOC Group 4 Chemicals: BENEZO (A) PYRENE - 2306, ENDOTHALL - 2033, DI(2-ETHYLHEXYL) - ADIPATE - 2035, DI(2-ETHYLHEXYL) - PHTHALATE - 2039

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

*SOC Group 4 Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3842212      PWS NAME: HOLMESVILLE ELEMENTARY**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: HOLMESVILLE ELEMENTARY DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 6/30/2008 1 Sample(s) Quarterly between 9/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

*Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.*

If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3842412    PWS NAME: IAC PWS**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 3855191    STU NAME: IAC PROD CO**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 10/1/2008 and 12/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals:    ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:    SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3842412 PWS NAME: IAC PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: IAC DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

<b>Use for Sample Tracking Purposes</b>				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

---

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3842512      PWS NAME: LIGHT IN THE VALLEY CHURCH**

**PWS TYPE: Transient Noncommunity      SOURCE: Ground Water**

**STU ID: 3855192      STU NAME: LIGHT IN THE VALLEY CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3842612    PWS NAME: MENNONITE INFORMATION CENTER**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855193    STU NAME: MENNONITE INFORMATION CENTER**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3842712 PWS NAME: BERLIN HOTEL AND SUITES**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855194 STU NAME: BERLIN HOTEL AND SUITES STU 1**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3842712 PWS NAME: BERLIN HOTEL AND SUITES**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP002**

**STU ID: 3860528 STU NAME: BERLIN HOTEL AND SUITES STU 2**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3842712 PWS NAME: BERLIN HOTEL AND SUITES**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP003**

**STU ID: 3860529 STU NAME: BERLIN HOTEL AND SUITES STU 3**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3842712 PWS NAME: BERLIN HOTEL AND SUITES**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: BERLIN HOTEL AND SUITES DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH3842812    PWS NAME: GOSPEL LIGHT CHAPEL  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 3855195    STU NAME: GOSPEL LIGHT CHAPEL  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3843212 PWS NAME: CHALET IN THE VALLEY**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855198 STU NAME: CHALET IN THE VALLEY**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH3843212      PWS NAME: CHALET IN THE VALLEY

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: CHALET IN THE VALLEY DISTRIBUTION

Effective Date: 1/1/08

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** Not Required
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

---

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

---

Use for Sample Tracking Purposes	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
TCR Quarterly Sample Date(s):				

---

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3843312    PWS NAME: FARMERSTOWN AUCTION, INC. PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855199    STU NAME: FARMERSTOWN AUCTION, INC**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Monitoring Requirements</b>	<b>Sample Monitoring Point</b>
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3843412 PWS NAME: EAST HOLMES INDUSTRIAL PARKWAY**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855200 STU NAME: EAST HOLMES IND PKWY**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3843412 PWS NAME: EAST HOLMES INDUSTRIAL PARKWAY**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: EAST HOLMES IND. PKWY. DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3843612      PWS NAME: WAYNE DALTON HEADQUARTER**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 3855201      STU NAME: WAYNE-DALTON CORP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3843612 PWS NAME: WAYNE DALTON HEADQUARTER**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: WAYNE DALTON HEADQUARTER DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**LEAD - 1030 & COPPER - 1022**

Not Required

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

*Jan - Mar Sample Date(s)*

*Apr - Jun Sample Date(s)*

*Jul - Sept Sample Date(s)*

*Oct - Dec Sample Date(s)*

*TCR Quarterly Sample Date(s):*

---

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH3843812    PWS NAME: CORNERSTONE COMMUNITY CHURCH

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 3855203    STU NAME: CORNERSTONE COMMUNITY CHURCH


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3843912 PWS NAME: INN AT HONEY RUN**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855204 STU NAME: INN AT HONEY RUN**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3843912      PWS NAME: INN AT HONEY RUN**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: INN AT HONEY RUN DISTRIBUTION**

**Effective Date: 2/19/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** Not Required
<b>REVISED - TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

---

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

---

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

## 2008 CONTAMINANT MONITORING SCHEDULE


**PWS ID: OH3844212    PWS NAME: GUGGISBERG SWISS INN**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 3855205    STU NAME: GUGGISBERG SWISS INN**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH3844412    PWS NAME: GRACE BRETHREN CHURCH

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 3855207    STU NAME: GRACE BRETHREN CHURCH


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3844512 PWS NAME: GRACE MENNONITE CHURCH**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 3855208 STU NAME: GRACE MENNONITE CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3844612    PWS NAME: BERLIN CHRISTIAN FELLOW**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855209    STU NAME: BERLIN CHRISTIAN FELLOWSHIP**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH3844712    PWS NAME: HORSE AND HARNESS PUB

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 3855210    STU NAME: HORSE AND HARNESS PUB


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3844812    PWS NAME: MILLERSBURG UNITED METHODIST CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855211    STU NAME: MILLERSBURG UNITED METH CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH3844912    PWS NAME: MOHICAN RIVER LODGE  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 3855212    STU NAME: MOHICAN RIVER INN  
Effective Date: 9/19/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
REVISED - NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3845012    PWS NAME: ARROWPOINT CAMPGROUND-EAST PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855213    STU NAME: ARROW POINT CAMPGROUND EAST**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

**PWS ID: OH3845112    PWS NAME: BAUERS CAMP NORTH WELL PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855214    STU NAME: BAUERS CAMP NORTH WELL**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3845212    PWS NAME: BAUERS CAMP SOUTH WELL PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855215    STU NAME: BAUERS CAMP SOUTH WELL**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH3845412    PWS NAME: CABIN CREEK GOLF**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 3855217    STU NAME: CABIN CREEK GOLF**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH3845512    PWS NAME: **CAMP BETHANY-MAIN**  
PWS TYPE: **Transient Noncommunity**    SOURCE: **Ground Water**  
STU ID: 3855218    STU NAME: **CAMP BETHANY**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 7/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH3845612    PWS NAME: CHARM COUNTRYVIEW INN

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 3855219    STU NAME: CHARM COUNTRYVIEW INN INC


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3845812 PWS NAME: FINNEYS MARATHON PWS**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 3855221 STU NAME: FINNEYS MARATHON**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE


**PWS ID: OH3846012    PWS NAME: HOLMESVILLE INN**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 3855222    STU NAME: HOLMESVILLE INN**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH3846112    PWS NAME: CROSSROADS FUEL COMPANY

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 3855223    STU NAME: CROSSROADS FUEL CO


Effective Date: 7/18/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
REVISED - NITRATE	1 Sample(s) Quarterly	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH3846212    PWS NAME: CAMP BETHANY - BATHHOUSE

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 3855224    STU NAME: CAMP BETHANY BATHHOUSE


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3846412    PWS NAME: KILLBUCK VALLEY CHRISTIAN CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855226    STU NAME: KILLBUCK VALLEY CHRISTIAN CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3846512 PWS NAME: RPI OF INDIANA, INC.**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3855227 STU NAME: RPI OF INDIANA INC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3846512 PWS NAME: RPI OF INDIANA, INC.**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: RPI OF INDIANA, INC. DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**LEAD - 1030 & COPPER - 1022**

Not Required

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

*Jan - Mar Sample Date(s)*

*Apr - Jun Sample Date(s)*

*Jul - Sept Sample Date(s)*

*Oct - Dec Sample Date(s)*

*TCR Quarterly Sample Date(s):*

---

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3846612    PWS NAME: POMERENE MEMORIAL HOSPITAL**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855228    STU NAME: POMERENE MEMORIAL HOSPITAL**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3846712    PWS NAME: ARROWPOINT CAMPGROUND-WEST PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3855229    STU NAME: ARROWPOINT CAMPGROUND WEST**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH3846812    PWS NAME: WHISPERING HILLS-NORTH

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 3855230    STU NAME: WHISPERING HILLS NORTH


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP002</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP002 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH3846812    PWS NAME: WHISPERING HILLS-NORTH  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 3861927    STU NAME: WHISPERING HILLS NORTH STU 2  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP003</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP003 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH3847012    PWS NAME: GRACE HAVEN FELLOWSHIP**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 3855232    STU NAME: GRACE HAVEN FELLOWSHIP CHURCH**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH3847212    PWS NAME: GUGGISBERG CHEESE  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 3855234    STU NAME: GUGGISBERG CHEESE  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3847612 PWS NAME: WEAVER LEATHER PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3860730 STU NAME: WEAVER LEATHER**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 3/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

*VOC Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH3847612      PWS NAME: WEAVER LEATHER PWS

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: WEAVER LEATHER DISTRIBUTION

Effective Date: 1/1/08

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

Use for Sample Tracking Purposes	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
TCR Quarterly Sample Date(s):				

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3847712    PWS NAME: HOLMES COUNTY TRAINING CENTER 2 PWS**  
**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**  
**STU ID: 3860729    STU NAME: HOLMES COUNTY TRAINING CENTER (2)**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 4 List Below	1 Sample(s) between 4/1/2008 and 6/30/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

SOC Group 4 Chemicals: BENEZO (A) PYRENE - 2306, ENDOTHALL - 2033, DI(2-ETHYLHEXYL) - ADIPATE - 2035, DI(2-ETHYLHEXYL) - PHTHALATE - 2039

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

*SOC Group 4 Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH3847712      PWS NAME: HOLMES COUNTY TRAINING CENTER 2 PWS

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: HOLMES COUNTY TRAINING CENTER (2) DISTRI

Effective Date: 1/1/08

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

Use for Sample Tracking Purposes				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
TCR Quarterly Sample Date(s):				

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3847812      PWS NAME: WEST HOLMES HIGH SCHOOL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 3860683      STU NAME: WEST HOLMES HIGH SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH3847812      PWS NAME: WEST HOLMES HIGH SCHOOL

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: WEST HOLMES HIGH SCHOOL DISTRIBUTION

Effective Date: 1/1/08

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** Not Required
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 6/30/2008 1 Sample(s) Quarterly between 9/1/2008 and 12/31/2008
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

---

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

---

Use for Sample Tracking Purposes				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
TCR Quarterly Sample Date(s):				

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3848012 PWS NAME: 3M ASSOCIATES LTD OFFICE PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP002**

**STU ID: 3861592 STU NAME: 3M ASSOCIATES LTD**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) Quarterly
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 4 List Below	1 Sample(s) between 4/1/2008 and 6/30/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

SOC Group 4 Chemicals: BENEZO (A) PYRENE - 2306, ENDOTHALL - 2033, DI(2-ETHYLHEXYL) - ADIPATE - 2035, DI(2-ETHYLHEXYL) - PHTHALATE - 2039

<b>Use for Sample Tracking Purposes</b>				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>NITRATE Quarterly Sample Date(s):</i>				
<i>SOC Group 4 Sample Date(s):</i>				

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3848012 PWS NAME: 3M ASSOCIATES LTD OFFICE PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: 3M ASSOCIATES LTD DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

---

**Chemical Name - Code**

**Monitoring Requirements**

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

---

*Lead & Copper Sample Date(s):*

*Jan - Mar Sample Date(s)*

*Apr - Jun Sample Date(s)*

*Jul - Sept Sample Date(s)*

*Oct - Dec Sample Date(s)*

*TCR Quarterly Sample Date(s):*

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3848112    PWS NAME: 3M ASSOCIATES, LTD. PLANT PWS**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 3860743    STU NAME: 3M ASSOCIATES LTD**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 7/1/2008 and 9/30/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 4 List Below	1 Sample(s) between 4/1/2008 and 6/30/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

SOC Group 4 Chemicals: BENEZO (A) PYRENE - 2306, ENDOTHALL - 2033, DI(2-ETHYLHEXYL) - ADIPATE - 2035, DI(2-ETHYLHEXYL) - PHTHALATE - 2039

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

*VOC Sample Date(s):*

*SOC Group 4 Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3848112 PWS NAME: 3M ASSOCIATES, LTD. PLANT PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: 3M ASSOCIATES, LTD. DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

---

*Lead & Copper Sample Date(s):*

*Jan - Mar Sample Date(s)*

*Apr - Jun Sample Date(s)*

*Jul - Sept Sample Date(s)*

*Oct - Dec Sample Date(s)*

---

*TCR Quarterly Sample Date(s):*

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3848212 PWS NAME: BLACK DIAMOND GOLF COURSE PWS**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 3860755 STU NAME: BLACK DIAMOND GOLF COURSE**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH3848312    PWS NAME: COMMUNITY BIBLE CHURCH PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 3860787    STU NAME: COMMUNITY BIBLE CHURCH


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3848712 PWS NAME: F D HARDWOODS PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 3861441 STU NAME: F D HARDWOODS**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3848712 PWS NAME: F D HARDWOODS PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: F D HARDWOODS DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

*Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.*

If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

---

*Lead & Copper Sample Date(s):*

*Jan - Mar Sample Date(s)*

*Apr - Jun Sample Date(s)*

*Jul - Sept Sample Date(s)*

*Oct - Dec Sample Date(s)*

*TCR Quarterly Sample Date(s):*

---

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH3848812    PWS NAME: SKYVIEW BAPTIST RANCH-DINING HALL PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 3861550    STU NAME: SKYVIEW BAPTIST RANCH-DINING HALL**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3849012      PWS NAME: HOLMES BY PRODUCTS PWS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 3861706      STU NAME: HOLMES BY-PRODUCTS**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) Quarterly
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
<i>NITRATE Sample Date(s):</i>				
<i>VOC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH3849012      PWS NAME: HOLMES BY PRODUCTS PWS

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: HOLMES BY PRODUCTS DISTRIBUTION

Effective Date: 1/1/08

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	5 Sample(s) between 6/1/2008 and 9/30/2008
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

Use for Sample Tracking Purposes				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3849112      PWS NAME: VALLEY VIEW OAK LLC PWS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 3861730      STU NAME: VALLEY VIEW OAK LLC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals:   ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:   SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH3849112      PWS NAME: VALLEY VIEW OAK LLC PWS

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: VALLEY VIEW OAK LLC DISTRIBUTION

Effective Date: 1/1/08

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	5 Sample(s) between 6/1/2008 and 9/30/2008
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

Use for Sample Tracking Purposes				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

---

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH3849312    PWS NAME: LOUDONVILLE BAPTIST TEMPLE PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 3861740    STU NAME: LOUDONVILLE BAPTIST TEMPLE


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3849512    PWS NAME: HOLMES-WAYNE ELECTRIC COOPERATIVE INC PW**  
**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**  
**STU ID: 3861962    STU NAME: HOLMES-WAYNE ELECTRIC COOPERATIVE INC**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 1/1/2008 and 5/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH3849512    PWS NAME: HOLMES-WAYNE ELECTRIC COOPERATIVE INC PW  
PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: DS000  
FACILITY NAME: HOLMES-WAYNE ELECTRIC COOPERATIVE DISTRI  
Effective Date: 1/1/08

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	5 Sample(s) between 6/1/2008 and 9/30/2008
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

Use for Sample Tracking Purposes				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3849712    PWS NAME: WAYNE DALTON DOOR & SYSTEMS INC**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 3862082    STU NAME: WAYNE DALTON DOOR & SYSTEMS INC**

**Effective Date: 3/17/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>REVISED - INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>REVISED - NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>REVISED - NITRITE</b>	NITRITE (AS N) - 1041	1 Sample(s) between 1/1/2008 and 5/31/2008
<b>REVISED - VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) Quarterly
<b>REVISED - SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
<i>INORGANIC Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>NITRITE Sample Date(s):</i>				
<i>VOC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3849712 PWS NAME: WAYNE DALTON DOOR & SYSTEMS INC**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: WAYNE DALTON DOOR & SYS INC DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

---

	<i>1st Half Sample Date(s)</i>	<i>2nd Half Sample Date(s)</i>		
<i>Lead &amp; Copper Initial Monitoring Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH3849812      PWS NAME: KEIM LUMBER INC PWS 2**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 3862118      STU NAME: KEIM LUMBER CO**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) Quarterly
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
<i>ARSENIC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>NITRATE Sample Date(s):</i>				
<i>VOC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH3849812 PWS NAME: KEIM LUMBER INC PWS 2**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: KEIM LUMBER INC DISTRIBUTION**

**Effective Date: 2/19/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**REVISED - TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

---

<i>Lead &amp; Copper Initial Monitoring Sample Date(s):</i>	<i>1st Half Sample Date(s)</i>	<i>2nd Half Sample Date(s)</i>		
<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>

---

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH3849912    PWS NAME: FAITH HAVEN FELLOWSHIP PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 3862128    STU NAME: FAITH HAVEN FELLOWSHIP


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	1 Sample(s) between 1/1/2008 and 5/31/2008	<i>Sample should be taken at EP001</i>
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)