

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH5000411      PWS NAME: CAMPBELL CITY PWS

PWS TYPE: Community    SOURCE: Surface Water    Sample Monitoring Point: EP001

STU ID: 5056004    STU NAME: CAMPBELL CITY

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) Monthly
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>TOTAL ORGANIC CARBON (TOC)</b>		1 Paired Sample Set Monthly *
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 7/1/2008 and 9/30/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 4/1/2008 and 6/30/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

Paired Sample Set: \* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes												
<i>INORGANIC Sample Date(s):</i>												
<i>NITRATE Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>TOC Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>VOC Sample Date(s):</i>												
<i>SOC Group 1 Sample Date(s):</i>												
<i>Date CCR sent to Ohio EPA:</i>												

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5000411      PWS NAME: CAMPBELL CITY PWS

PWS TYPE: Community    SOURCE: Surface Water    Sample Monitoring Point: DS000

FACILITY NAME: CAMPBELL, CITY OF DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	20 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) Quarterly
<b>TOTAL COLIFORM (TCR) - 3100</b>	10 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>HAA5 &amp; TTHM Quarterly Sample Date(s):</i>												
	<i>Jan - Mar Sample Date(s)</i>			<i>Apr - Jun Sample Date(s)</i>			<i>Jul - Sept Sample Date(s)</i>			<i>Oct - Dec Sample Date(s)</i>		
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5000503      PWS NAME: CANFIELD CITY PWS

PWS TYPE: Community    SOURCE: Purchased Surface Water    Sample Monitoring Point: DS000

FACILITY NAME: CANFIELD, CITY OF DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>ASBESTOS - 1094</b>	Not Required
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) Quarterly
<b>TOTAL COLIFORM (TCR) - 3100</b>	9 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>												
	Jan - Mar Sample Date(s)			Apr - Jun Sample Date(s)			Jul - Sept Sample Date(s)			Oct - Dec Sample Date(s)		
<i>HAA5 &amp; TTHM Quarterly Sample Date(s):</i>												
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5000612 PWS NAME: COLONIAL VILLA ESTATES**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5056006 STU NAME: COLONIAL VILLA ESTATES MHP STU 1**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5000612 PWS NAME: COLONIAL VILLA ESTATES**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP002**

**STU ID: 5060556 STU NAME: COLONIAL VILLA ESTATES STU 2**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 7/1/2008 and 9/30/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5000712 PWS NAME: J & H MOBILE HOME PARK**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5056007 STU NAME: J & H MHP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH5000912      PWS NAME: M & C MOBILE HOME PARK

PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: EP001

STU ID: 5056008      STU NAME: M & C MHP VILLAGE

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals:   ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:   SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5001212      PWS NAME: DEER MEADOW ESTATES**

**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 5056011    STU NAME: DEER MEADOWS MHP DBA EVERGREEN COMMUNITI**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**  
**PWS ID: OH5001611 PWS NAME: AQUA OHIO - STRUTHERS**  
**PWS TYPE: Community SOURCE: Surface Water Sample Monitoring Point: EP001**  
**STU ID: 5056013 STU NAME: AQUA OHIO-STRUTHERS WTP**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) Monthly
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>TOTAL ORGANIC CARBON (TOC)</b>		1 Paired Sample Set Monthly *
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 6/1/2008 and 10/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 4/1/2008 and 6/30/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

Paired Sample Set: \* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes												
<i>INORGANIC Sample Date(s):</i>												
<i>NITRATE Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>TOC Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>VOC Sample Date(s):</i>												
<i>SOC Group 1 Sample Date(s):</i>												
<i>Date CCR sent to Ohio EPA:</i>												

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5001611      PWS NAME: AQUA OHIO - STRUTHERS

PWS TYPE: Community    SOURCE: Surface Water    Sample Monitoring Point: DS000

FACILITY NAME: AQUA OHIO-STRUTHERS DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
ASBESTOS - 1094	Not Required
LEAD - 1030 & COPPER - 1022	30 Sample(s) between 6/1/2008 and 9/30/2008
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 8 Sample(s) Quarterly
TOTAL COLIFORM (TCR) - 3100	50 Sample(s) Monthly between 1/1/2008 and 12/31/2008
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes														
<i>Lead &amp; Copper Sample Date(s):</i>														
<i>HAA5 &amp; TTHM Quarterly Sample Date(s):</i>			<i>Jan - Mar Sample Date(s)</i>			<i>Apr - Jun Sample Date(s)</i>			<i>Jul - Sept Sample Date(s)</i>		<i>Oct - Dec Sample Date(s)</i>			
<i>TCR Monthly Sample Date(s):</i>			<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>														

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5001812 PWS NAME: ISLAND CREEK HOMEOWNERS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5056014 STU NAME: ISLAND CREEK HOMEOWNERS ASSOC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**  
**PWS ID: OH5001911 PWS NAME: SEBRING VILLAGE PWS**  
**PWS TYPE: Community SOURCE: Surface Water Sample Monitoring Point: EP001**  
**STU ID: 5056015 STU NAME: SEBRING WTP**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) Monthly
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>TOTAL ORGANIC CARBON (TOC)</b>		1 Paired Sample Set Monthly *
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 6/1/2008 and 10/31/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 1/1/2008 and 3/31/2008 1 Sample(s) between 4/1/2008 and 4/30/2008 1 Sample(s) between 5/1/2008 and 5/31/2008 1 Sample(s) between 6/1/2008 and 6/30/2008 1 Sample(s) between 7/1/2008 and 9/30/2008 1 Sample(s) between 10/1/2008 and 12/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

Paired Sample Set: \* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>												
<i>INORGANIC Sample Date(s):</i>												
<i>NITRATE Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>TOC Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>VOC Sample Date(s):</i>												
<i>SOC Group 1 Sample Date(s):</i>												
<i>Date CCR sent to Ohio EPA:</i>												



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5002112 PWS NAME: STATE LINE MHP 2 PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5056016 STU NAME: STATE LINE MHP-SYSTEM NO 2**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5002303 PWS NAME: YOUNGSTOWN CITY PWS**

**PWS TYPE: Community SOURCE: Purchased Surface Water Sample Monitoring Point: DS000**

**FACILITY NAME: YOUNGSTOWN, CITY OF DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>ASBESTOS - 1094</b>	Not Required
<b>LEAD - 1030 &amp; COPPER - 1022</b>	50 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	<b>**</b> 4 Sample(s) Quarterly
<b>TOTAL COLIFORM (TCR) - 3100</b>	120 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	<b>***</b> Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

**Use for Sample Tracking Purposes**

*Lead & Copper Sample Date(s):*

<i>HAA5 &amp; TTHM Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
--	---------------------------------	---------------------------------	----------------------------------	---------------------------------

<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
------------------------------------	------------	------------	------------	------------	------------	------------	------------	------------	-------------	------------	------------	------------

*Total Chlorine Sample Date(s):*

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5002812 PWS NAME: STATE LINE MHP 1 PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5056019 STU NAME: STATE LINE MHP-SYSTEM NO 1**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>
<i>Date CCR sent to Ohio EPA:</i>



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH5003012      PWS NAME: ST. MARYS ALZHEIMERS CENTER

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001

STU ID: 5056020    STU NAME: ST MARYS ALZHEIMERS CTR

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name - Code	Monitoring Requirements
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>RADIOLOGICALS</b>	GROSS ALPHA - 4002, RADIUM 228 - 4030	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

Use for Sample Tracking Purposes				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
ARSENIC Quarterly Sample Date(s):				
NITRATE Sample Date(s):				
SOC Group 1 Sample Date(s):				
Date CCR sent to Ohio EPA:				



**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH5030012    PWS NAME: ODOT-REST AREA 4-43 PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5056021    STU NAME: ODOT REST AREA 4-43


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5031212    PWS NAME: KINGS MOTEL  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5056025    STU NAME: KINGS MOTEL STU 1  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5031212    PWS NAME: KINGS MOTEL  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5060557    STU NAME: KINGS MOTEL STU 2  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP002</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP002 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5031812    PWS NAME: TIC TOC FOOD MART-CLEARWATER CAFE**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056026    STU NAME: TIC TOC FOOD MART**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5032512    PWS NAME: YOUNGS RESTAURANT PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056028    STU NAME: YOUNGS RESTAURANT**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Monitoring Requirements</b>	<b>Sample Monitoring Point</b>
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5033012    PWS NAME: BENS RESTAURANT & BAR INC PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056029    STU NAME: BENS LAKESIDE LOUNGE**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Monitoring Requirements</b>	<b>Sample Monitoring Point</b>
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE


**PWS ID: OH5033112    PWS NAME: CAMP STAMBAUGH BSA MAIN**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5056030    STU NAME: CAMP STAMBAUGH BOY SCOUTS STU 1**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5033112    PWS NAME: CAMP STAMBAUGH BSA MAIN  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5060558    STU NAME: CAMP STAMBAUGH BSA MAIN STU 2  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP002</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP002 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5033812    PWS NAME: BARBARAS COZY CORNER**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5056033    STU NAME: BARBARAS COZY CORNER**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5034112    PWS NAME: SHILLING MILL TAVERN**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5056036    STU NAME: SHILLING MILL TAVERN**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5034212 PWS NAME: ELLSWORTH ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5056037 STU NAME: ELLSWORTH ELEMENTARY SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5034212 PWS NAME: ELLSWORTH ELEMENTARY SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: ELLSWORTH ELEMENTARY SCH DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

---

	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5034712 PWS NAME: CHAPARRAL FAMILY CAMPGROUND PWS**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5056039 STU NAME: CHAPARRAL FAMILY CAMPGROUND**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 11/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5034912    PWS NAME: LAKE MILTON RV RESORT**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5056040    STU NAME: LAKE MILTON RV RESORT**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5035812    PWS NAME: LAKESIDE CAMPGROUND**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5056042    STU NAME: LAKESIDE CAMPGROUND**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5036212      PWS NAME: DIAMOND BACK GOLF COURSE**

**PWS TYPE: Transient Noncommunity      SOURCE: Ground Water**

**STU ID: 5056044      STU NAME: DIAMOND BACK GOLF COURSE**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5036612    PWS NAME: N.E. OH CHURCH OF GOD CAMP**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056046    STU NAME: NORTH EAST OHIO CHURCH OF GOD CAMPGROUND**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5037412    PWS NAME: PETERSBURG INN**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5056048    STU NAME: PETERSBURG INN**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5037812    PWS NAME: PONDEROSA PARK**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5056050    STU NAME: PONDEROSA PARK RESORTS INC STU 1**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5037812    PWS NAME: PONDEROSA PARK  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5060559    STU NAME: PONDEROSA PARK STU 2  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP002</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP002 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5037812    PWS NAME: PONDEROSA PARK  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5060560    STU NAME: PONDEROSA PARK STU 3  
Effective Date: 9/19/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
REVISED - NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP003</i>
REVISED - NITRITE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP003</i>
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP003 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5038012 PWS NAME: REAL LIFE DAY CARE**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5056051 STU NAME: REAL LIFE DAY CARE**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5038012      PWS NAME: REAL LIFE DAY CARE

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: REAL LIFE DAY CARE DISTRIBUTION

Effective Date: 1/1/08

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** Not Required
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

---

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

---

Use for Sample Tracking Purposes	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
TCR Quarterly Sample Date(s):				

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5038712 PWS NAME: SOUTH RANGE WEST SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5056054 STU NAME: SOUTH RANGE WEST SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5038712      PWS NAME: SOUTH RANGE WEST SCHOOL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: SOUTH RANGE WEST SCHOOL DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5039912      PWS NAME: WESTERN RESERVE MIDDLE SCHOOL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 5056060      STU NAME: WESTERN RESERVE MIDDLE SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) Quarterly
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals:   ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:   SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
<i>NITRATE Sample Date(s):</i>				
<i>VOC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>SOC Group 1 Sample Date(s):</i>				

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5039912 PWS NAME: WESTERN RESERVE MIDDLE SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: WESTERN RESERVE MIDDLE S DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5040012      PWS NAME: WESTERN RESERVE HIGH SCHOOL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 5056061      STU NAME: WESTERN RESERVE HIGH SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5040012 PWS NAME: WESTERN RESERVE HIGH SCHOOL**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: WESTERN RESERVE HIGH SCH DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5040112    PWS NAME: ARNOLDS LOUNGE  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5056062    STU NAME: ARNOLDS LOUNGE  
Effective Date: 2/19/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
REVISED - TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5040612    PWS NAME: USACE-BERLIN LAKE  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5056064    STU NAME: USACE BERLIN LAKE  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5040912    PWS NAME: BEDFORD TRAILS GOLF COURSE**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056065    STU NAME: BEDFORD TRAILS GOLF COURSE**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH5041012    PWS NAME: ODOT-REST AREA 4-44 PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5056066    STU NAME: ODOT REST AREA 4-44


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5042712    PWS NAME: WHITEHOUSE FRUIT FARM**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5056073    STU NAME: WHITEHOUSE FRUIT FARM AMLC**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5043012    PWS NAME: GREENFORD EVAN LUTHERAN CHURCH PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056075    STU NAME: GREENFORD EVAN LUTHERAN CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE


**PWS ID: OH5043112    PWS NAME: PETERSBURG PRESBYTERIAN**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5056076    STU NAME: PETERSBURG PRESBYTERIAN CHURCH**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5043212 PWS NAME: ST JOHNS LUTHERAN CHURCH - PETERSBURG PW**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5056077 STU NAME: SAINT JOHNS LUTHERAN CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5043312    PWS NAME: GREEN ACRES NORTH WELL PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056078    STU NAME: GREEN ACRES NORTH WELL**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

**PWS ID: OH5043322    PWS NAME: GREEN ACRES-SOUTH WELL PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056079    STU NAME: GREEN ACRES SOUTH WELL**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5043412    PWS NAME: WESTERN RESERVE PARK BATHHOUSE PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056080    STU NAME: WESTERN RESERVE PARK CAMPGROUNDS**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5043422    PWS NAME: WESTERN RESERVE PARK CAMP PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5056081    STU NAME: WESTERN RESERVE LAKE CAMP PARK


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5043512    PWS NAME: PARADISE COVE CAMPGROUND**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056082    STU NAME: PARADISE COVE CAMPGROUND LLC**


**Effective Date: 6/13/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>REVISED - TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 5/1/2008 and 10/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5043612    PWS NAME: PICOS CAMPGROUND  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5056083    STU NAME: PICOS CAMPGROUND  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5043912    PWS NAME: AUT MORI GROTTO (SHANGRI-LA)**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056085    STU NAME: AUT MORI GROTTO SHANGRI-LA**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5044112    PWS NAME: VFW POST 7600 PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5056087    STU NAME: VFW POST NO 7600**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH5044912    PWS NAME: DOGWOOD COUNTRY CLUB

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5056092    STU NAME: DOGWOOD COUNTRY CLUB


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5045012    PWS NAME: LAKESIDE GOLF COURSE**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5056093    STU NAME: LAKESIDE GOLF COURSE**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5045412    PWS NAME: HYDE-A-WAY GOLF CLUB**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5056097    STU NAME: HYDE-A-WAY GOLF CLUB**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 10/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5045512      PWS NAME: PINE MEADOWS GOLF COURSE**

**PWS TYPE: Transient Noncommunity      SOURCE: Ground Water**

**STU ID: 5056098      STU NAME: PINE MEADOWS GOLF COURSE**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5045612    PWS NAME: TJ BP & CARRY OUT  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5056099    STU NAME: GARYS BP & CARRY-OUT  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) Quarterly	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5045812    PWS NAME: BOARDMAN PARK-EDGEWOOD PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056101    STU NAME: BOARDMAN PARK EDGEWOOD PAVILIO**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Monitoring Requirements</b>	<b>Sample Monitoring Point</b>
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5045912    PWS NAME: BOARDMAN PARK-MAIN WELL PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5056102    STU NAME: BOARDMAN PARK MAIN WELL


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5046212    PWS NAME: FLYING B GOLF CLUB CLUBHOUSE

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5056105    STU NAME: FLYING B GOLF CLUB CLUBHOUSE


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 4/1/2008 and 11/30/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5046612    PWS NAME: LAKE MILTON BAPTIST TEMPLE**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056109    STU NAME: LAKE MILTON BAPTIST TEMPLE**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE


**PWS ID: OH5046712    PWS NAME: CANFIELD JEHOVAH WITNESS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5056110    STU NAME: CANFIELD JEHOVAH WITNESS CHURC**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5046812    PWS NAME: BAILEY RD BAPTIST CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056111    STU NAME: BAILEY RD BAPTIST CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5046912    PWS NAME: NORTH BENTON UNITED PRESBYTERIAN CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056112    STU NAME: N BENTON UN PRESBYTERIAN CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5047012    PWS NAME: BUNKER HILL METHODIST CHURCH

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5056113    STU NAME: BUNKER HILL METHODIST CHURCH


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5047112    PWS NAME: GREENFORD CHRISTIAN CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056114    STU NAME: GREENFORD CHRISTIAN CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5047712    PWS NAME: PARADISE UNITED CHURCH OF CHRIST**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056120    STU NAME: PARADISE UN CHURCH OF CHRIST**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Monitoring Requirements</b>	<b>Sample Monitoring Point</b>
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5047812 PWS NAME: LOCUST GROVE BAPTIST CHURCH**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5056121 STU NAME: LOCUST GROVE BAPTIST CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH5048012    PWS NAME: LAKE FRONT GOLF COURSE

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5056122    STU NAME: LAKE FRONT GOLF COURSE


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5048112    PWS NAME: ZION HILL CHURCH OF THE BRETHREN**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056123    STU NAME: ZION HILL CHURCH OF THE BRETHREN**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5048612    PWS NAME: EAST GOSHEN FRIENDS CHURCH

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5056127    STU NAME: EAST GOSHEN FRIENDS CHURCH


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5048812    PWS NAME: HERITAGE BAPTIST CHURCH**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5056129    STU NAME: HERITAGE BAPTIST CHURCH**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5049312    PWS NAME: BERLIN CENTER UNITED METHODIST CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056132    STU NAME: BERLIN CENTER UN METHODIST CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH5049912    PWS NAME: GREENFORD CHRISTIAN LIFE CENTER

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5056136    STU NAME: GREENFORD CHRISTIAN LIFE CNTR


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH5050012    PWS NAME: ELLSWORTH PRESBYTERIAN CHURCH

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5056137    STU NAME: ELLSWORTH PRESBYTERIAN CHURCH


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5050112      PWS NAME: LINDE HYDRAULICS, CORP.**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 5056138      STU NAME: LINDE HYDRAULICS CORP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 7/1/2008 and 9/30/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>ARSENIC Quarterly Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>VOC Sample Date(s):</i>				
<i>SOC Group 1 Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5050112      PWS NAME: LINDE HYDRAULICS, CORP.

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: LINDE HYDRAULICS, CORP. DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	5 Sample(s) between 6/1/2008 and 9/30/2008
TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950	** 1 Sample(s) between 7/1/2008 and 9/30/2008
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008
TOTAL CHLORINE - 1000	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes				
Lead & Copper Sample Date(s):				
HAA5 & TTHM Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
Total Chlorine Sample Date(s):				

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5050211    PWS NAME: SOCIETY OF ST PAUL  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5056139    STU NAME: PIOUS SOCIETY OF ST PAUL  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5050612    PWS NAME: OLD SPRINGFLD CHURCH OF CHRIST**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056142    STU NAME: OLD SPRINGFLD UN CHURCH OF CHRIST**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5051012    PWS NAME: BISTRO 62 PWS  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5056145    STU NAME: OLD FIRESIDE CAFE  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
NITRITE	Not Required	
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5051412    PWS NAME: SALEM HILLS GOLF & CC**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5056149    STU NAME: SALEM HILLS COUNTRY CLUB**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5051512 PWS NAME: CAMP STAMBAUGH BSA PARKING**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5056150 STU NAME: CAMP STAMBAUGH BSA PARKING LOT**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5051812 PWS NAME: NASHBAR DIRECT PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5056153 STU NAME: BIKE NASHBAR**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5051812 PWS NAME: NASHBAR DIRECT PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: NASHBAR DIRECT DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

---

**Chemical Name - Code**

**Monitoring Requirements**

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

---

	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5051912 PWS NAME: TIP PLUS CORP PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5056154 STU NAME: TIP PLUS CORP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>ARSENIC</b>	ARSENIC - 1005	1 Sample(s) Quarterly
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 7/1/2008 and 9/30/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>ARSENIC Quarterly Sample Date(s):</i>				
<i>NITRATE Sample Date(s):</i>				
<i>VOC Sample Date(s):</i>				
<i>SOC Group 1 Sample Date(s):</i>				

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5051912 PWS NAME: TIP PLUS CORP PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: TIP PLUS CORP DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5052012    PWS NAME: VICTORY CHRISTIAN CENTER ADMIN BLDG PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5056155    STU NAME: VICTORY ASSEMBLY ADMIN BLDG**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5052312 PWS NAME: COMMUNITY BIBLE CHURCH - BELOIT**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5056158 STU NAME: COMMUNITY BIBLE CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5052412 PWS NAME: MIDWAY MENNONITE CHURCH**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5056159 STU NAME: MIDWAY MENNONITE CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5052512      PWS NAME: BAIRD BROTHERS SAWMILL**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 5056160      STU NAME: BAIRD BROTHERS SAWMILL INC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		Not Required
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

*SOC Group 1 Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5052512      PWS NAME: BAIRD BROTHERS SAWMILL

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: BAIRD BROTHERS SAWMILL DISTRIBUTION

Effective Date: 1/1/08

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
LEAD - 1030 & COPPER - 1022	Not Required
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

Use for Sample Tracking Purposes				
	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5052712    PWS NAME: YOUNGSTOWN-ELSER AIRPORT

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5056162    STU NAME: YOUNGSTOWN-ELSER AIRPORT


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH5052812    PWS NAME: YNG AREA JEWISH FEDERATI

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5056163    STU NAME: YNG AREA JEWISH FEDERATION


Effective Date: 6/13/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
REVISED - NITRATE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
REVISED - NITRITE	1 Sample(s) between 6/1/2008 and 10/31/2008	<i>Sample should be taken at EP001</i>
TOTAL COLIFORM (TCR) - 3100	1 Sample(s) Quarterly between 6/1/2008 and 9/30/2008	<i>Sample should be taken at DS000</i>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5053012    PWS NAME: PJS COUNTRY CAFE PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5056165    STU NAME: PJS COUNTRY CAFE**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5053112 PWS NAME: BEEG-BRO LTD**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5056166 STU NAME: BEEG-BRO LTD**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) Quarterly
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
<i>NITRATE Sample Date(s):</i>				
<i>VOC Quarterly Sample Date(s):</i>	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
<i>SOC Group 1 Sample Date(s):</i>				

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5053112      PWS NAME: BEEG-BRO LTD**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: DS000**

**FACILITY NAME: BEEG-BRO LTD DISTRIBUTION**

**Effective Date: 1/1/08**

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>LEAD - 1030 &amp; COPPER - 1022</b>	Not Required
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

<b>Use for Sample Tracking Purposes</b>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5053312    PWS NAME: WENDYS RESTAURANT PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5060828    STU NAME: WENDYS RESTAURANT


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5053412    PWS NAME: CHRISTIAN LIFE CENTER PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5060925    STU NAME: CHRISTIAN LIFE CENTER**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5053612    PWS NAME: HOWARD HANNA BLDG PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5061145    STU NAME: HOWARD HANNA BLDG**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5053912 PWS NAME: HIGH POINTE ASSEMBLY OF GOD PWS**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5061633 STU NAME: HIGH POINTE ASSEMBLY OF GOD**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5054012    PWS NAME: MASTROPIETRO WINERY PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5061707    STU NAME: MASTROPIETRO WINERY


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>NITRITE</b>	Not Required	
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

Use for Sample Tracking Purposes				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5054112      PWS NAME: DAMASCUS ELEMENTARY PWS**  
**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**  
**STU ID: 5061899      STU NAME: DAMASCUS ELEMENTARY**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) between 7/1/2008 and 9/30/2008
<b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	1 Sample(s) between 6/1/2008 and 10/31/2008

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>
<i>NITRATE Sample Date(s):</i>
<i>VOC Sample Date(s):</i>
<i>SOC Group 1 Sample Date(s):</i>

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5054112      PWS NAME: DAMASCUS ELEMENTARY PWS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000**

**FACILITY NAME: DAMASCUS ELEM DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	5 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) between 7/1/2008 and 9/30/2008
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

<b>Use for Sample Tracking Purposes</b>				
<i>Lead &amp; Copper Sample Date(s):</i>				
<i>HAA5 &amp; TTHM Sample Date(s):</i>				
<i>TCR Quarterly Sample Date(s):</i>	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>Total Chlorine Sample Date(s):</i>				

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5054212      PWS NAME: JACKSON/MILTON SERVICE AREA PWS

PWS TYPE: Community    SOURCE: Purchased Surface Water    Sample Monitoring Point: DS000

FACILITY NAME: JACKSON/MILTON SERVICE AREA DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemical Name - Code	Monitoring Requirements
<b>LEAD - 1030 &amp; COPPER - 1022</b>	20 Sample(s) between 6/1/2008 and 9/30/2008
<b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and TOTAL TRIHALOMETHANES (TTHM) - 2950</b>	** 1 Sample(s) Quarterly
<b>TOTAL COLIFORM (TCR) - 3100</b>	4 Sample(s) Monthly between 1/1/2008 and 12/31/2008
<b>TOTAL CHLORINE - 1000</b>	*** Sample in the Distribution System

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

Use for Sample Tracking Purposes												
<i>Lead &amp; Copper Sample Date(s):</i>												
<i>HAA5 &amp; TTHM Quarterly Sample Date(s):</i>												
	<i>Jan - Mar Sample Date(s)</i>			<i>Apr - Jun Sample Date(s)</i>			<i>Jul - Sept Sample Date(s)</i>			<i>Oct - Dec Sample Date(s)</i>		
<i>TCR Monthly Sample Date(s):</i>	<i>Jan</i>	<i>Feb</i>	<i>Mar</i>	<i>Apr</i>	<i>May</i>	<i>Jun</i>	<i>Jul</i>	<i>Aug</i>	<i>Sept</i>	<i>Oct</i>	<i>Nov</i>	<i>Dec</i>
<i>Total Chlorine Sample Date(s):</i>												

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5054312    PWS NAME: SKYLINE DINER PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5062014    STU NAME: SKYLINE DINER**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Monitoring Point
<b>TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, NA is the first tap after the well.

**Use for Sample Tracking Purposes**

	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)
TCR Quarterly Sample Date(s):				

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5054412      PWS NAME: DAY HABILITATION CENTER PWS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 5062147      STU NAME: DAY HABILITATION CENTER**

**Effective Date: 10/17/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Chemical Name - Code</b>	<b>Monitoring Requirements</b>
<b>REVISED - INORGANICS</b>	See Inorganic Chemical List Below	Not Required
<b>REVISED - NITRATE</b>	NITRATE (AS N) - 1040	1 Sample(s) between 6/1/2008 and 10/31/2008
<b>REVISED - NITRITE</b>	NITRITE (AS N) - 1041	Not Required
<b>REVISED - VOLATILE ORGANIC CHEMICALS (VOC)</b>		1 Sample(s) Quarterly
<b>REVISED - SYNTHETIC ORGANIC CHEMICALS (SOC)</b>	See SOC Group 1 List Below	Not Required

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

<b>Use for Sample Tracking Purposes</b>				
<i>NITRATE Sample Date(s):</i>				
<i>VOC Quarterly Sample Date(s):</i>				
	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5054412 PWS NAME: DAY HABILITATION CENTER PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: DAY HABILITATION CENTER DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Northeast District Office - DDAGW representative immediately at 330-963-1200.

---

**Use for Sample Tracking Purposes**

---

	<i>Jan - Mar Sample Date(s)</i>	<i>Apr - Jun Sample Date(s)</i>	<i>Jul - Sept Sample Date(s)</i>	<i>Oct - Dec Sample Date(s)</i>
<i>TCR Quarterly Sample Date(s):</i>				

---

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5054512    PWS NAME: ELLSWORTH TOWNSHIP PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5062151    STU NAME: ELLSWORTH TOWNSHIP**


**Effective Date: 3/17/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Monitoring Requirements</b>	<b>Sample Monitoring Point</b>
<b>REVISED - NITRATE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>REVISED - NITRITE</b>	1 Sample(s) between 6/1/2008 and 10/31/2008	<b>Sample should be taken at EP001</b>
<b>REVISED - TOTAL COLIFORM (TCR) - 3100</b>	1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008	<b>Sample should be taken at DS000</b>

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

<b>Use for Sample Tracking Purposes</b>				
Nitrate Sample Date(s):				
Nitrite Sample Date(s):				
TCR Quarterly Sample Date(s):	Jan - Mar Sample Date(s)	Apr - Jun Sample Date(s)	Jul - Sept Sample Date(s)	Oct - Dec Sample Date(s)