

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5700203 PWS NAME: BROOKVILLE MUNICIPALITY PWS**

**PWS TYPE: Community SOURCE: Purchased Surface Water Sample Monitoring Point: DS000**

**FACILITY NAME: BROOKVILLE, MUNICIPALITY DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemical Name - Code</b>   | <b>Monitoring Requirements</b>                      |
|---|---|
| <b>LEAD - 1030 &amp; COPPER - 1022</b>  | Not Required  |
| <b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br/>TOTAL TRIHALOMETHANES (TTHM) - 2950</b> | ** 1 Sample(s) Quarterly                            |
| <b>TOTAL COLIFORM (TCR) - 3100</b>  | 6 Sample(s) Monthly between 1/1/2008 and 12/31/2008 |
| <b>TOTAL CHLORINE - 1000</b>  | *** Sample in the Distribution System               |

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| <b>Use for Sample Tracking Purposes</b>          |                                 |            |            |                                 |            |            |                                  |            |             |                                 |            |            |
|--|---------------------------------|------------|------------|---------------------------------|------------|------------|----------------------------------|------------|-------------|---------------------------------|------------|------------|
|  | <i>Jan - Mar Sample Date(s)</i> |            |            | <i>Apr - Jun Sample Date(s)</i> |            |            | <i>Jul - Sept Sample Date(s)</i> |            |             | <i>Oct - Dec Sample Date(s)</i> |            |            |
| <i>HAA5 &amp; TTHM Quarterly Sample Date(s):</i> |                                 |            |            |                                 |            |            |                                  |            |             |                                 |            |            |
| <i>TCR Monthly Sample Date(s):</i>               | <i>Jan</i>                      | <i>Feb</i> | <i>Mar</i> | <i>Apr</i>                      | <i>May</i> | <i>Jun</i> | <i>Jul</i>                       | <i>Aug</i> | <i>Sept</i> | <i>Oct</i>                      | <i>Nov</i> | <i>Dec</i> |
| <i>Total Chlorine Sample Date(s):</i>            |                                 |            |            |                                 |            |            |                                  |            |             |                                 |            |            |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5700412 PWS NAME: CAINS MOBILE HOME COURT**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5756615 STU NAME: CAINS MOBILE HOME COURT**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |
|---|
| <i>NITRATE Sample Date(s):</i>          |
| <i>SOC Group 1 Sample Date(s):</i>      |
| <i>Date CCR sent to Ohio EPA:</i>       |

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5700412      PWS NAME: CAINS MOBILE HOME COURT

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: DS000

FACILITY NAME: CAINS MOBILE HOME COURT DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements                             |
|---|---|
| <b>LEAD - 1030 &amp; COPPER - 1022</b>  | 5 Sample(s) between 6/1/2008 and 9/30/2008          |
| <b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br/>TOTAL TRIHALOMETHANES (TTHM) - 2950</b> | ** 1 Sample(s) between 7/1/2008 and 9/30/2008       |
| <b>TOTAL COLIFORM (TCR) - 3100</b>  | 1 Sample(s) Monthly between 1/1/2008 and 12/31/2008 |
| <b>TOTAL CHLORINE - 1000</b>  | *** Sample in the Distribution System               |

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| Use for Sample Tracking Purposes         |            |            |            |            |            |            |            |            |             |            |            |            |
|--|------------|------------|------------|------------|------------|------------|------------|------------|-------------|------------|------------|------------|
| <i>Lead &amp; Copper Sample Date(s):</i> |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>HAA5 &amp; TTHM Sample Date(s):</i>   |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>TCR Monthly Sample Date(s):</i>       | <i>Jan</i> | <i>Feb</i> | <i>Mar</i> | <i>Apr</i> | <i>May</i> | <i>Jun</i> | <i>Jul</i> | <i>Aug</i> | <i>Sept</i> | <i>Oct</i> | <i>Nov</i> | <i>Dec</i> |
| <i>Total Chlorine Sample Date(s):</i>    |            |            |            |            |            |            |            |            |             |            |            |            |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5700512      PWS NAME: CATALPA GROVE MHP**

**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 5756616    STU NAME: CATALPA GROVE MHP**

**Effective Date: 4/18/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>REVISED - RADIOLOGICALS</b>           | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |
|---|
| <i>NITRATE Sample Date(s):</i>          |
| <i>SOC Group 1 Sample Date(s):</i>      |
| <i>Date CCR sent to Ohio EPA:</i>       |



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5700612      PWS NAME: BROOKVILLE LAKE ESTATES**

**PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 5756617      STU NAME: BROOKVILLE LAKE ESTATES**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |
|---|
| <i>NITRATE Sample Date(s):</i>          |
| <i>SOC Group 1 Sample Date(s):</i>      |
| <i>Date CCR sent to Ohio EPA:</i>       |



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5700812 PWS NAME: ENGLEWOOD CITY PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5756620 STU NAME: ENGLEWOOD CITY**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |
|---|
| <i>NITRATE Sample Date(s):</i>          |
| <i>SOC Group 1 Sample Date(s):</i>      |
| <i>Date CCR sent to Ohio EPA:</i>       |

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5700812      PWS NAME: ENGLEWOOD CITY PWS

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: DS000

FACILITY NAME: ENGLEWOOD, CITY OF DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements                              |
|---|--|
| ASBESTOS - 1094   | Not Required   |
| LEAD - 1030 & COPPER - 1022   | Not Required   |
| TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br>TOTAL TRIHALOMETHANES (TTHM) - 2950 | ** 1 Sample(s) between 7/1/2008 and 9/30/2008        |
| TOTAL COLIFORM (TCR) - 3100   | 10 Sample(s) Monthly between 1/1/2008 and 12/31/2008 |
| TOTAL CHLORINE - 1000   | *** Sample in the Distribution System                |

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| Use for Sample Tracking Purposes       |            |            |            |            |            |            |            |            |             |            |            |            |
|--|------------|------------|------------|------------|------------|------------|------------|------------|-------------|------------|------------|------------|
| <i>HAA5 &amp; TTHM Sample Date(s):</i> |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>TCR Monthly Sample Date(s):</i>     | <i>Jan</i> | <i>Feb</i> | <i>Mar</i> | <i>Apr</i> | <i>May</i> | <i>Jun</i> | <i>Jul</i> | <i>Aug</i> | <i>Sept</i> | <i>Oct</i> | <i>Nov</i> | <i>Dec</i> |
| <i>Total Chlorine Sample Date(s):</i>  |            |            |            |            |            |            |            |            |             |            |            |            |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5700912      PWS NAME: FARMERSVILLE VILLAGE PWS**

**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 5756621    STU NAME: FARMERSVILLE WATER DEPARTMENT**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |
|---|
| <i>NITRATE Sample Date(s):</i>          |
| <i>SOC Group 1 Sample Date(s):</i>      |
| <i>Date CCR sent to Ohio EPA:</i>       |

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5700912      PWS NAME: FARMERSVILLE VILLAGE PWS

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: DS000

FACILITY NAME: FARMERSVILLE,VILLAGE OF DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements                             |
|---|---|
| <b>LEAD - 1030 &amp; COPPER - 1022</b>  | 10 Sample(s) between 6/1/2008 and 9/30/2008         |
| <b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br/>TOTAL TRIHALOMETHANES (TTHM) - 2950</b> | ** Not Required                                     |
| <b>TOTAL COLIFORM (TCR) - 3100</b>  | 1 Sample(s) Monthly between 1/1/2008 and 12/31/2008 |
| <b>TOTAL CHLORINE - 1000</b>  | *** Sample in the Distribution System               |

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| <b>Use for Sample Tracking Purposes</b>  |            |            |            |            |            |            |            |            |             |            |            |            |
|--|------------|------------|------------|------------|------------|------------|------------|------------|-------------|------------|------------|------------|
| <i>Lead &amp; Copper Sample Date(s):</i> |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>TCR Monthly Sample Date(s):</i>       | <i>Jan</i> | <i>Feb</i> | <i>Mar</i> | <i>Apr</i> | <i>May</i> | <i>Jun</i> | <i>Jul</i> | <i>Aug</i> | <i>Sept</i> | <i>Oct</i> | <i>Nov</i> | <i>Dec</i> |
| <i>Total Chlorine Sample Date(s):</i>    |            |            |            |            |            |            |            |            |             |            |            |            |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5701012 PWS NAME: GERMANTOWN VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5756622 STU NAME: GERMANTOWN VILLAGE**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 2 List Below            | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 4 List Below            | 1 Sample(s) between 4/1/2008 and 6/30/2008  |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

SOC Group 2 Chemicals: CARBOFURAN - 2046, OXAMYL (VYDATE) - 2036, PICLORAM - 2040, 2,4-D - 2105, PENTACHLOROPHENOL - 2326

SOC Group 4 Chemicals: BENEZO (A) PYRENE - 2306, ENDOTHALL - 2033, DI(2-ETHYLHEXYL) - ADIPATE - 2035, DI(2-ETHYLHEXYL) - PHTHALATE - 2039

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

*SOC Group 1 Sample Date(s):*

*SOC Group 4 Sample Date(s):*

*Date CCR sent to Ohio EPA:*

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5701012    PWS NAME: GERMANTOWN VILLAGE PWS

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: DS000

FACILITY NAME: GERMANTOWN, VILLAGE OF DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements                             |
|---|---|
| ASBESTOS - 1094   | Not Required  |
| LEAD - 1030 & COPPER - 1022   | 20 Sample(s) between 6/1/2008 and 9/30/2008         |
| TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br>TOTAL TRIHALOMETHANES (TTHM) - 2950 | ** Not Required                                     |
| TOTAL COLIFORM (TCR) - 3100   | 6 Sample(s) Monthly between 1/1/2008 and 12/31/2008 |
| TOTAL CHLORINE - 1000   | *** Sample in the Distribution System               |

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| Use for Sample Tracking Purposes         |            |            |            |            |            |            |            |            |             |            |            |            |
|--|------------|------------|------------|------------|------------|------------|------------|------------|-------------|------------|------------|------------|
| <i>Lead &amp; Copper Sample Date(s):</i> |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>TCR Monthly Sample Date(s):</i>       | <i>Jan</i> | <i>Feb</i> | <i>Mar</i> | <i>Apr</i> | <i>May</i> | <i>Jun</i> | <i>Jul</i> | <i>Aug</i> | <i>Sept</i> | <i>Oct</i> | <i>Nov</i> | <i>Dec</i> |
| <i>Total Chlorine Sample Date(s):</i>    |            |            |            |            |            |            |            |            |             |            |            |            |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**  
**PWS ID: OH5701212    PWS NAME: MIAMISBURG CITY PWS**  
**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**  
**STU ID: 5756623    STU NAME: MIAMISBURG WATER DEPARTMENT**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | 1 Sample(s) between 1/1/2008 and 3/31/2008  |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |
|---|
| <i>NITRATE Sample Date(s):</i>          |
| <i>VOC Sample Date(s):</i>              |
| <i>SOC Group 1 Sample Date(s):</i>      |
| <i>Date CCR sent to Ohio EPA:</i>       |

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5701212      PWS NAME: MIAMISBURG CITY PWS

PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: MIAMISBURG,CITY OF DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements                              |
|---|--|
| ASBESTOS - 1094   | Not Required   |
| LEAD - 1030 & COPPER - 1022   | 30 Sample(s) between 6/1/2008 and 9/30/2008          |
| TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br>TOTAL TRIHALOMETHANES (TTHM) - 2950 | ** 1 Sample(s) between 7/1/2008 and 9/30/2008        |
| TOTAL COLIFORM (TCR) - 3100   | 20 Sample(s) Monthly between 1/1/2008 and 12/31/2008 |
| TOTAL CHLORINE - 1000   | *** Sample in the Distribution System                |

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| Use for Sample Tracking Purposes         |            |            |            |            |            |            |            |            |             |            |            |            |
|--|------------|------------|------------|------------|------------|------------|------------|------------|-------------|------------|------------|------------|
| <i>Lead &amp; Copper Sample Date(s):</i> |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>HAA5 &amp; TTHM Sample Date(s):</i>   |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>TCR Monthly Sample Date(s):</i>       | <i>Jan</i> | <i>Feb</i> | <i>Mar</i> | <i>Apr</i> | <i>May</i> | <i>Jun</i> | <i>Jul</i> | <i>Aug</i> | <i>Sept</i> | <i>Oct</i> | <i>Nov</i> | <i>Dec</i> |
| <i>Total Chlorine Sample Date(s):</i>    |            |            |            |            |            |            |            |            |             |            |            |            |

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5701315      PWS NAME: MONTGOMERY COUNTY WATER SYSTEM 1 PWS**  
**PWS TYPE: Community    SOURCE: Purchased Surface Water    Sample Monitoring Point: DS000**  
**FACILITY NAME: MONTGOMERY CO:WATER SYSTEM 1 DISTRIBUTIO**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements                               |
|---|---|
| <b>ASBESTOS - 1094</b>  | Not Required  |
| <b>LEAD - 1030 &amp; COPPER - 1022</b>  | 50 Sample(s) between 6/1/2008 and 9/30/2008           |
| <b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br/>TOTAL TRIHALOMETHANES (TTHM) - 2950</b> | <b>**</b> 1 Sample(s) Quarterly                       |
| <b>TOTAL COLIFORM (TCR) - 3100</b>  | 120 Sample(s) Monthly between 1/1/2008 and 12/31/2008 |
| <b>TOTAL CHLORINE - 1000</b>  | <b>***</b> Sample in the Distribution System          |

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| <b>Use for Sample Tracking Purposes</b>          |            |            |                                 |            |            |                                 |            |            |                                  |            |            |                                 |  |  |
|--|------------|------------|---------------------------------|------------|------------|---------------------------------|------------|------------|----------------------------------|------------|------------|---------------------------------|--|--|
| <i>Lead &amp; Copper Sample Date(s):</i>         |            |            |                                 |            |            |                                 |            |            |                                  |            |            |                                 |  |  |
| <i>HAA5 &amp; TTHM Quarterly Sample Date(s):</i> |            |            | <i>Jan - Mar Sample Date(s)</i> |            |            | <i>Apr - Jun Sample Date(s)</i> |            |            | <i>Jul - Sept Sample Date(s)</i> |            |            | <i>Oct - Dec Sample Date(s)</i> |  |  |
| <i>TCR Monthly Sample Date(s):</i>               |            |            |                                 |            |            |                                 |            |            |                                  |            |            |                                 |  |  |
|  | <i>Jan</i> | <i>Feb</i> | <i>Mar</i>                      | <i>Apr</i> | <i>May</i> | <i>Jun</i>                      | <i>Jul</i> | <i>Aug</i> | <i>Sept</i>                      | <i>Oct</i> | <i>Nov</i> | <i>Dec</i>                      |  |  |
| <i>Total Chlorine Sample Date(s):</i>            |            |            |                                 |            |            |                                 |            |            |                                  |            |            |                                 |  |  |

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5701503      PWS NAME: MONTGOMERY COUNTY WATER SYSTEM 2 PWS**  
**PWS TYPE: Community    SOURCE: Purchased Surface Water    Sample Monitoring Point: DS000**  
**FACILITY NAME: MONTGOMERY CO:WATER SYSTEM 2 DISTRIBUTIO**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements                              |
|---|--|
| <b>ASBESTOS - 1094</b>  | Not Required   |
| <b>LEAD - 1030 &amp; COPPER - 1022</b>  | 30 Sample(s) between 6/1/2008 and 9/30/2008          |
| <b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br/>TOTAL TRIHALOMETHANES (TTHM) - 2950</b> | <b>**</b> 1 Sample(s) Quarterly                      |
| <b>TOTAL COLIFORM (TCR) - 3100</b>  | 80 Sample(s) Monthly between 1/1/2008 and 12/31/2008 |
| <b>TOTAL CHLORINE - 1000</b>  | <b>***</b> Sample in the Distribution System         |

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| <b>Use for Sample Tracking Purposes</b>          |            |            |                                 |            |            |                                 |            |            |                                  |            |            |                                 |  |  |
|--|------------|------------|---------------------------------|------------|------------|---------------------------------|------------|------------|----------------------------------|------------|------------|---------------------------------|--|--|
| <i>Lead &amp; Copper Sample Date(s):</i>         |            |            |                                 |            |            |                                 |            |            |                                  |            |            |                                 |  |  |
| <i>HAA5 &amp; TTHM Quarterly Sample Date(s):</i> |            |            | <i>Jan - Mar Sample Date(s)</i> |            |            | <i>Apr - Jun Sample Date(s)</i> |            |            | <i>Jul - Sept Sample Date(s)</i> |            |            | <i>Oct - Dec Sample Date(s)</i> |  |  |
| <i>TCR Monthly Sample Date(s):</i>               |            |            |                                 |            |            |                                 |            |            |                                  |            |            |                                 |  |  |
|  | <i>Jan</i> | <i>Feb</i> | <i>Mar</i>                      | <i>Apr</i> | <i>May</i> | <i>Jun</i>                      | <i>Jul</i> | <i>Aug</i> | <i>Sept</i>                      | <i>Oct</i> | <i>Nov</i> | <i>Dec</i>                      |  |  |
| <i>Total Chlorine Sample Date(s):</i>            |            |            |                                 |            |            |                                 |            |            |                                  |            |            |                                 |  |  |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5701812 PWS NAME: NEW LEBANON VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5756626 STU NAME: NEW LEBANON VILLAGE**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | DI(2-ETHYLHEXYL) - PHTHALATE - 2039   | 1 Sample(s) between 1/1/2008 and 3/31/2008  |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b>      |
|--|
| <i>NITRATE Sample Date(s):</i>               |
| <i>SOC Group 1 Sample Date(s):</i>           |
| <i>DI(2-ETHYLHEXYL) - PHTHALATE - 2039 :</i> |
| <i>Date CCR sent to Ohio EPA:</i>            |



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5701915 PWS NAME: OAKWOOD CITY PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5756627 STU NAME: OAKWOOD WATER SOFTENING PLANT NO 2**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |
|---|
| <i>NITRATE Sample Date(s):</i>          |
| <i>SOC Group 1 Sample Date(s):</i>      |
| <i>Date CCR sent to Ohio EPA:</i>       |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5701915 PWS NAME: OAKWOOD CITY PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP002**

**STU ID: 5760566 STU NAME: OAKWOOD SPRINGHOUSE PLANT**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

|   |
|---|
| <b>Use for Sample Tracking Purposes</b> |
| <i>NITRATE Sample Date(s):</i>          |
| <i>SOC Group 1 Sample Date(s):</i>      |
| <i>Date CCR sent to Ohio EPA:</i>       |



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5702112 PWS NAME: PHILLIPSBURG VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5756630 STU NAME: PHILLIPSBURG VILLAGE STU 1**

**Effective Date: 8/15/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                                   | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                                  | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                                     | NITRATE (AS N) - 1040                 | 1 Sample(s) between 4/1/2008 and 6/30/2008  |
| <b>NITRITE</b>                                     | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                               | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>            |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>           | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b>           | See SOC Group 2 List Below            | Not Required                                |
| <b>REVISED - SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | DI(2-ETHYLHEXYL) - PHTHALATE - 2039   | 1 Sample(s) Quarterly                       |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

SOC Group 2 Chemicals: CARBOFURAN - 2046, OXAMYL (VYDATE) - 2036, PICLORAM - 2040, 2,4-D - 2105, PENTACHLOROPHENOL - 2326

| <b>Use for Sample Tracking Purposes</b>      |                                 |                                 |                                  |                                 |
|--|---------------------------------|---------------------------------|----------------------------------|---------------------------------|
| <i>NITRATE Sample Date(s):</i>               |                                 |                                 |                                  |                                 |
| <i>SOC Group 1 Sample Date(s):</i>           |                                 |                                 |                                  |                                 |
| <i>SOC Group 4 Sample Date(s):</i>           |                                 |                                 |                                  |                                 |
| <i>DI(2-ETHYLHEXYL) - PHTHALATE - 2039 (</i> | <i>Jan - Mar Sample Date(s)</i> | <i>Apr - Jun Sample Date(s)</i> | <i>Jul - Sept Sample Date(s)</i> | <i>Oct - Dec Sample Date(s)</i> |
| <i>Date CCR sent to Ohio EPA:</i>            |                                 |                                 |                                  |                                 |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5702112 PWS NAME: PHILLIPSBURG VILLAGE PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP002**

**STU ID: 5760567 STU NAME: PHILLIPSBURG VILLAGE STU 2**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 7/1/2008 and 9/30/2008  |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 2 List Below            | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 4 List Below            | 1 Sample(s) between 4/1/2008 and 6/30/2008  |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

SOC Group 2 Chemicals: CARBOFURAN - 2046, OXAMYL (VYDATE) - 2036, PICLORAM - 2040, 2,4-D - 2105, PENTACHLOROPHENOL - 2326

SOC Group 4 Chemicals: BENEZO (A) PYRENE - 2306, ENDOTHALL - 2033, DI(2-ETHYLHEXYL) - ADIPATE - 2035, DI(2-ETHYLHEXYL) - PHTHALATE - 2039

| <b>Use for Sample Tracking Purposes</b> |
|---|
| <i>NITRATE Sample Date(s):</i>          |
| <i>SOC Group 1 Sample Date(s):</i>      |
| <i>SOC Group 4 Sample Date(s):</i>      |
| <i>Date CCR sent to Ohio EPA:</i>       |

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5702112    PWS NAME: PHILLIPSBURG VILLAGE PWS

PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: DS000

FACILITY NAME: PHILLIPSBURG, VILLAGE OF DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements                             |
|---|---|
| <b>ASBESTOS - 1094</b>  | Not Required  |
| <b>LEAD - 1030 &amp; COPPER - 1022</b>  | 10 Sample(s) between 6/1/2008 and 9/30/2008         |
| <b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br/>TOTAL TRIHALOMETHANES (TTHM) - 2950</b> | ** Not Required                                     |
| <b>TOTAL COLIFORM (TCR) - 3100</b>  | 1 Sample(s) Monthly between 1/1/2008 and 12/31/2008 |
| <b>TOTAL CHLORINE - 1000</b>  | *** Sample in the Distribution System               |

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| <b>Use for Sample Tracking Purposes</b>  |            |            |            |            |            |            |            |            |             |            |            |            |
|--|------------|------------|------------|------------|------------|------------|------------|------------|-------------|------------|------------|------------|
| <i>Lead &amp; Copper Sample Date(s):</i> |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>TCR Monthly Sample Date(s):</i>       | <i>Jan</i> | <i>Feb</i> | <i>Mar</i> | <i>Apr</i> | <i>May</i> | <i>Jun</i> | <i>Jul</i> | <i>Aug</i> | <i>Sept</i> | <i>Oct</i> | <i>Nov</i> | <i>Dec</i> |
| <i>Total Chlorine Sample Date(s):</i>    |            |            |            |            |            |            |            |            |             |            |            |            |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5702212 PWS NAME: PINEVIEW ESTATES MHP**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5756631 STU NAME: PINEVIEW ESTATES MHP**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |
|---|
| <i>NITRATE Sample Date(s):</i>          |
| <i>SOC Group 1 Sample Date(s):</i>      |
| <i>Date CCR sent to Ohio EPA:</i>       |



**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5702403      PWS NAME: TROTWOOD CITY PWS

PWS TYPE: Community    SOURCE: Purchased Surface Water    Sample Monitoring Point: DS000

FACILITY NAME: TROTWOOD, CITY OF DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements                              |
|---|--|
| <b>LEAD - 1030 &amp; COPPER - 1022</b>  | 30 Sample(s) between 6/1/2008 and 9/30/2008          |
| <b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br/>TOTAL TRIHALOMETHANES (TTHM) - 2950</b> | ** 1 Sample(s) Quarterly                             |
| <b>TOTAL COLIFORM (TCR) - 3100</b>  | 10 Sample(s) Monthly between 1/1/2008 and 12/31/2008 |
| <b>TOTAL CHLORINE - 1000</b>  | *** Sample in the Distribution System                |

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| <b>Use for Sample Tracking Purposes</b>          |                                 |            |            |                                 |            |            |                                  |            |             |                                 |            |            |
|--|---------------------------------|------------|------------|---------------------------------|------------|------------|----------------------------------|------------|-------------|---------------------------------|------------|------------|
| <i>Lead &amp; Copper Sample Date(s):</i>         |                                 |            |            |                                 |            |            |                                  |            |             |                                 |            |            |
| <i>HAA5 &amp; TTHM Quarterly Sample Date(s):</i> |                                 |            |            |                                 |            |            |                                  |            |             |                                 |            |            |
|  | <i>Jan - Mar Sample Date(s)</i> |            |            | <i>Apr - Jun Sample Date(s)</i> |            |            | <i>Jul - Sept Sample Date(s)</i> |            |             | <i>Oct - Dec Sample Date(s)</i> |            |            |
| <i>TCR Monthly Sample Date(s):</i>               | <i>Jan</i>                      | <i>Feb</i> | <i>Mar</i> | <i>Apr</i>                      | <i>May</i> | <i>Jun</i> | <i>Jul</i>                       | <i>Aug</i> | <i>Sept</i> | <i>Oct</i>                      | <i>Nov</i> | <i>Dec</i> |
| <i>Total Chlorine Sample Date(s):</i>            |                                 |            |            |                                 |            |            |                                  |            |             |                                 |            |            |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5702512    PWS NAME: UNION CITY PWS**

**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 5756633    STU NAME: UNION WATER DEPARTMENT STU 1**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 7/1/2008 and 9/30/2008  |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |
|---|
| <i>NITRATE Sample Date(s):</i>          |
| <i>SOC Group 1 Sample Date(s):</i>      |
| <i>Date CCR sent to Ohio EPA:</i>       |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH5702512      PWS NAME: UNION CITY PWS

PWS TYPE: Community      SOURCE: Ground Water      Sample Monitoring Point: EP002

STU ID: 5760568      STU NAME: UNION CITY STU 2

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                                | Chemical Name - Code                  | Monitoring Requirements                     |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals:    ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:    SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

|   |
|---|
| <b>Use for Sample Tracking Purposes</b> |
| <i>NITRATE Sample Date(s):</i>          |
| <i>SOC Group 1 Sample Date(s):</i>      |
| <i>Date CCR sent to Ohio EPA:</i>       |



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**  
**PWS ID: OH5702712 PWS NAME: VOYAGER VILLAGE MHP**  
**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**  
**STU ID: 5756635 STU NAME: VOYAGER VILLAGE MHP**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                                | Chemical Name - Code                  | Monitoring Requirements                     |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>ARSENIC</b>                           | ARSENIC - 1005                        | 1 Sample(s) Quarterly                       |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| Use for Sample Tracking Purposes         |                          |                          |                           |                          |
|--|--------------------------|--------------------------|---------------------------|--------------------------|
|  | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |
| <i>ARSENIC Quarterly Sample Date(s):</i> |                          |                          |                           |                          |
| <i>NITRATE Sample Date(s):</i>           |                          |                          |                           |                          |
| <i>SOC Group 1 Sample Date(s):</i>       |                          |                          |                           |                          |
| <i>Date CCR sent to Ohio EPA:</i>        |                          |                          |                           |                          |



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5702812 PWS NAME: WEST CARROLLTON CITY PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5756636 STU NAME: WEST CARROLLTON CITY OF**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |
|---|
| <i>NITRATE Sample Date(s):</i>          |
| <i>SOC Group 1 Sample Date(s):</i>      |
| <i>Date CCR sent to Ohio EPA:</i>       |

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5702812 PWS NAME: WEST CARROLLTON CITY PWS**

**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: WEST CARROLLTON,CITY OF DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements                              |
|---|--|
| <b>ASBESTOS - 1094</b>  | Not Required   |
| <b>LEAD - 1030 &amp; COPPER - 1022</b>  | Not Required   |
| <b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br/>TOTAL TRIHALOMETHANES (TTHM) - 2950</b> | ** 1 Sample(s) between 7/1/2008 and 9/30/2008        |
| <b>TOTAL COLIFORM (TCR) - 3100</b>  | 10 Sample(s) Monthly between 1/1/2008 and 12/31/2008 |
| <b>TOTAL CHLORINE - 1000</b>  | *** Sample in the Distribution System                |

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| <b>Use for Sample Tracking Purposes</b> |            |            |            |            |            |            |            |            |             |            |            |            |
|---|------------|------------|------------|------------|------------|------------|------------|------------|-------------|------------|------------|------------|
| <i>HAA5 &amp; TTHM Sample Date(s):</i>  |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>TCR Monthly Sample Date(s):</i>      | <i>Jan</i> | <i>Feb</i> | <i>Mar</i> | <i>Apr</i> | <i>May</i> | <i>Jun</i> | <i>Jul</i> | <i>Aug</i> | <i>Sept</i> | <i>Oct</i> | <i>Nov</i> | <i>Dec</i> |
| <i>Total Chlorine Sample Date(s):</i>   |            |            |            |            |            |            |            |            |             |            |            |            |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH5703012    PWS NAME: JEFFERSON REGIONAL WATER AUTHORITY  
PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001  
STU ID: 5756637    STU NAME: JEFFERSON REGIONAL WATER AUTH  
Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                                | Chemical Name - Code                  | Monitoring Requirements                     |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| Use for Sample Tracking Purposes   |
|------------------------------------|
| <i>NITRATE Sample Date(s):</i>     |
| <i>SOC Group 1 Sample Date(s):</i> |
| <i>Date CCR sent to Ohio EPA:</i>  |



**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5703312    PWS NAME: CRAINS RUN WATER AND SEWER DISTRICT PWS**  
**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**  
**STU ID: 5760800    STU NAME: CRAINS RUN WATER AND SEWER**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |
|---|
| <i>NITRATE Sample Date(s):</i>          |
| <i>SOC Group 1 Sample Date(s):</i>      |
| <i>Date CCR sent to Ohio EPA:</i>       |

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5703312    PWS NAME: CRAINS RUN WATER AND SEWER DISTRICT PWS**  
**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: DS000**  
**FACILITY NAME: CRAINS RUN WATER AND SEWER DISTRIBUTION**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements                             |
|---|---|
| <b>LEAD - 1030 &amp; COPPER - 1022</b>  | 10 Sample(s) between 6/1/2008 and 9/30/2008         |
| <b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br/>TOTAL TRIHALOMETHANES (TTHM) - 2950</b> | ** 1 Sample(s) between 7/1/2008 and 9/30/2008       |
| <b>TOTAL COLIFORM (TCR) - 3100</b>  | 2 Sample(s) Monthly between 1/1/2008 and 12/31/2008 |
| <b>TOTAL CHLORINE - 1000</b>  | *** Sample in the Distribution System               |

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| <b>Use for Sample Tracking Purposes</b>  |            |            |            |            |            |            |            |            |             |            |            |            |
|--|------------|------------|------------|------------|------------|------------|------------|------------|-------------|------------|------------|------------|
| <i>Lead &amp; Copper Sample Date(s):</i> |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>HAA5 &amp; TTHM Sample Date(s):</i>   |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>TCR Monthly Sample Date(s):</i>       | <i>Jan</i> | <i>Feb</i> | <i>Mar</i> | <i>Apr</i> | <i>May</i> | <i>Jun</i> | <i>Jul</i> | <i>Aug</i> | <i>Sept</i> | <i>Oct</i> | <i>Nov</i> | <i>Dec</i> |
| <i>Total Chlorine Sample Date(s):</i>    |            |            |            |            |            |            |            |            |             |            |            |            |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5703512      PWS NAME: DAYTON PUBLIC WATER SYSTEM**

**PWS TYPE: Community      SOURCE: Surface Water      Sample Monitoring Point: EP001**

**STU ID: 5756618      STU NAME: DAYTON PWS MIAMI PLANT**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>   |
|--|---------------------------------------|--|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | 1 Sample(s) between 6/1/2008 and 10/31/2008  |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) Monthly  |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required   |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required   |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | 1 Sample(s) between 10/1/2008 and 12/31/2008   |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 4/1/2008 and 4/30/2008<br>1 Sample(s) between 5/1/2008 and 5/31/2008<br>1 Sample(s) between 6/1/2008 and 6/30/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |            |            |            |            |            |            |            |            |             |            |            |            |
|---|------------|------------|------------|------------|------------|------------|------------|------------|-------------|------------|------------|------------|
| <i>INORGANIC Sample Date(s):</i>        |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>NITRATE Monthly Sample Date(s):</i>  | <i>Jan</i> | <i>Feb</i> | <i>Mar</i> | <i>Apr</i> | <i>May</i> | <i>Jun</i> | <i>Jul</i> | <i>Aug</i> | <i>Sept</i> | <i>Oct</i> | <i>Nov</i> | <i>Dec</i> |
| <i>TOC Monthly Sample Date(s):</i>      | <i>Jan</i> | <i>Feb</i> | <i>Mar</i> | <i>Apr</i> | <i>May</i> | <i>Jun</i> | <i>Jul</i> | <i>Aug</i> | <i>Sept</i> | <i>Oct</i> | <i>Nov</i> | <i>Dec</i> |
| <i>VOC Sample Date(s):</i>              |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>SOC Group 1 Sample Date(s):</i>      |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>Date CCR sent to Ohio EPA:</i>       |            |            |            |            |            |            |            |            |             |            |            |            |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5703512    PWS NAME: DAYTON PUBLIC WATER SYSTEM**

**PWS TYPE: Community    SOURCE: Surface Water    Sample Monitoring Point: EP002**

**STU ID: 5756619    STU NAME: DAYTON PWS OTTAWA PLANT**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>   |
|--|---------------------------------------|--|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | 1 Sample(s) between 6/1/2008 and 10/31/2008  |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) Monthly  |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required   |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required   |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | 1 Sample(s) between 10/1/2008 and 12/31/2008   |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 4/1/2008 and 4/30/2008<br>1 Sample(s) between 5/1/2008 and 5/31/2008<br>1 Sample(s) between 6/1/2008 and 6/30/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |            |            |            |            |            |            |            |            |             |            |            |            |
|---|------------|------------|------------|------------|------------|------------|------------|------------|-------------|------------|------------|------------|
| <i>INORGANIC Sample Date(s):</i>        |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>NITRATE Monthly Sample Date(s):</i>  | <i>Jan</i> | <i>Feb</i> | <i>Mar</i> | <i>Apr</i> | <i>May</i> | <i>Jun</i> | <i>Jul</i> | <i>Aug</i> | <i>Sept</i> | <i>Oct</i> | <i>Nov</i> | <i>Dec</i> |
| <i>TOC Monthly Sample Date(s):</i>      | <i>Jan</i> | <i>Feb</i> | <i>Mar</i> | <i>Apr</i> | <i>May</i> | <i>Jun</i> | <i>Jul</i> | <i>Aug</i> | <i>Sept</i> | <i>Oct</i> | <i>Nov</i> | <i>Dec</i> |
| <i>VOC Sample Date(s):</i>              |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>SOC Group 1 Sample Date(s):</i>      |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>Date CCR sent to Ohio EPA:</i>       |            |            |            |            |            |            |            |            |             |            |            |            |

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5703512 PWS NAME: DAYTON PUBLIC WATER SYSTEM**

**PWS TYPE: Community SOURCE: Surface Water Sample Monitoring Point: DS000**

**FACILITY NAME: DAYTON PWS DISTRIBUTION**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements                               |
|---|---|
| <b>LEAD - 1030 &amp; COPPER - 1022</b>  | 50 Sample(s) between 6/1/2008 and 9/30/2008           |
| <b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br/>TOTAL TRIHALOMETHANES (TTHM) - 2950</b> | ** 2 Sample(s) Quarterly                              |
| <b>TOTAL COLIFORM (TCR) - 3100</b>  | 120 Sample(s) Monthly between 1/1/2008 and 12/31/2008 |
| <b>TOTAL CHLORINE - 1000</b>  | *** Sample in the Distribution System                 |

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| <b>Use for Sample Tracking Purposes</b>          |                                 |            |            |                                 |            |            |                                  |            |             |                                 |            |            |
|--|---------------------------------|------------|------------|---------------------------------|------------|------------|----------------------------------|------------|-------------|---------------------------------|------------|------------|
| <i>Lead &amp; Copper Sample Date(s):</i>         |                                 |            |            |                                 |            |            |                                  |            |             |                                 |            |            |
| <i>HAA5 &amp; TTHM Quarterly Sample Date(s):</i> |                                 |            |            |                                 |            |            |                                  |            |             |                                 |            |            |
|  | <i>Jan - Mar Sample Date(s)</i> |            |            | <i>Apr - Jun Sample Date(s)</i> |            |            | <i>Jul - Sept Sample Date(s)</i> |            |             | <i>Oct - Dec Sample Date(s)</i> |            |            |
| <i>TCR Monthly Sample Date(s):</i>               | <i>Jan</i>                      | <i>Feb</i> | <i>Mar</i> | <i>Apr</i>                      | <i>May</i> | <i>Jun</i> | <i>Jul</i>                       | <i>Aug</i> | <i>Sept</i> | <i>Oct</i>                      | <i>Nov</i> | <i>Dec</i> |
| <i>Total Chlorine Sample Date(s):</i>            |                                 |            |            |                                 |            |            |                                  |            |             |                                 |            |            |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5703612    PWS NAME: HUBER HEIGHTS PUBLIC WATER SYSTEM**  
**PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP001**  
**STU ID: 5756628    STU NAME: HUBER HEIGHTS PWS PLANT 1**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>           | <b>Monitoring Requirements</b>              |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | 1 Sample(s) Quarterly                       |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |                          |                          |                           |                          |
|---|--------------------------|--------------------------|---------------------------|--------------------------|
| <i>NITRATE Sample Date(s):</i>          |                          |                          |                           |                          |
| <i>VOC Quarterly Sample Date(s):</i>    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |
| <i>SOC Group 1 Sample Date(s):</i>      |                          |                          |                           |                          |
| <i>Date CCR sent to Ohio EPA:</i>       |                          |                          |                           |                          |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH5703612    PWS NAME: HUBER HEIGHTS PUBLIC WATER SYSTEM  
PWS TYPE: Community    SOURCE: Ground Water    Sample Monitoring Point: EP002  
STU ID: 5756629    STU NAME: HUBER HEIGHTS PWS PLANT 2  
Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                                | Chemical Name - Code                  | Monitoring Requirements                     |
|--|---------------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below     | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040                 | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041                 | Not Required                                |
| <b>RADIOLOGICALS</b>                     | GROSS ALPHA - 4002, RADIUM 228 - 4030 | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                       | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below            | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

**REMINDER: Consumer Confidence Report (CCR) is due July 1, 2008**

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

|   |
|---|
| <b>Use for Sample Tracking Purposes</b> |
| <i>NITRATE Sample Date(s):</i>          |
| <i>SOC Group 1 Sample Date(s):</i>      |
| <i>Date CCR sent to Ohio EPA:</i>       |

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**  
**PWS ID: OH5703612 PWS NAME: HUBER HEIGHTS PUBLIC WATER SYSTEM**  
**PWS TYPE: Community SOURCE: Ground Water Sample Monitoring Point: DS000**  
**FACILITY NAME: HUBER HEIGHTS-PLANT 1 DISTRIBUTION**  
**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements                              |
|---|--|
| LEAD - 1030 & COPPER - 1022   | 30 Sample(s) between 6/1/2008 and 9/30/2008          |
| TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br>TOTAL TRIHALOMETHANES (TTHM) - 2950 | ** 2 Sample(s) between 7/1/2008 and 9/30/2008        |
| TOTAL COLIFORM (TCR) - 3100   | 40 Sample(s) Monthly between 1/1/2008 and 12/31/2008 |
| TOTAL CHLORINE - 1000   | *** Sample in the Distribution System                |

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately. You should also continue to take Routine Samples according to this schedule.* If you have any questions, please contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| Use for Sample Tracking Purposes         |            |            |            |            |            |            |            |            |             |            |            |            |
|--|------------|------------|------------|------------|------------|------------|------------|------------|-------------|------------|------------|------------|
| <i>Lead &amp; Copper Sample Date(s):</i> |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>HAA5 &amp; TTHM Sample Date(s):</i>   |            |            |            |            |            |            |            |            |             |            |            |            |
| <i>TCR Monthly Sample Date(s):</i>       | <i>Jan</i> | <i>Feb</i> | <i>Mar</i> | <i>Apr</i> | <i>May</i> | <i>Jun</i> | <i>Jul</i> | <i>Aug</i> | <i>Sept</i> | <i>Oct</i> | <i>Nov</i> | <i>Dec</i> |
| <i>Total Chlorine Sample Date(s):</i>    |            |            |            |            |            |            |            |            |             |            |            |            |

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5703715 PWS NAME: OAKWOOD VILLAGE MHP**

**PWS TYPE: Community SOURCE: Purchased Surface Water Sample Monitoring Point: DS000**

**FACILITY NAME: OAKWOOD VILLAGE DISTRIBUTION**

**Effective Date: 6/13/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements                             |
|---|---|
| <b>REVISED - LEAD - 1030 &amp; COPPER - 1022</b>  | Not Required  |
| <b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br/>TOTAL TRIHALOMETHANES (TTHM) - 2950</b> | ** 1 Sample(s) between 7/1/2008 and 9/30/2008       |
| <b>REVISED - TOTAL COLIFORM (TCR) - 3100</b>  | 2 Sample(s) Monthly between 1/1/2008 and 12/31/2008 |
| <b>TOTAL CHLORINE - 1000</b>  | *** Sample in the Distribution System               |

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

**Use for Sample Tracking Purposes**

*HAA5 & TTHM Sample Date(s):*

*TCR Monthly Sample Date(s):*

*Jan      Feb      Mar      Apr      May      Jun      Jul      Aug      Sept      Oct      Nov      Dec*

*Total Chlorine Sample Date(s):*

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5730312 PWS NAME: AULLWOOD AUDUBON NATURE CENTER PWS**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5756640 STU NAME: AULLWOOD AUDUBON NATURE CENTER**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5730912    PWS NAME: BUCKHORN TAVERN**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5756641    STU NAME: BUCKHORN TAVERN**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH5731012    PWS NAME: BUTLER ASPHALT CO., INC.

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5756642    STU NAME: BUTLER ASPHALT CO INC


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                   | Monitoring Requirements                               | Sample Monitoring Point                |
|-----------------------------|---|--|
| NITRATE                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <i>Sample should be taken at EP001</i> |
| NITRITE                     | Not Required  |  |
| TOTAL COLIFORM (TCR) - 3100 | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <i>Sample should be taken at DS000</i> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5731412    PWS NAME: CARLISLE INTERMEDIATE SCHOOL**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 5756645    STU NAME: CARLISLE INTERMEDIATE SCHOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>       | <b>Monitoring Requirements</b>              |
|--|-----------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040             | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041             | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                   | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below        | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |
|---|
| <i>NITRATE Sample Date(s):</i>          |
| <i>SOC Group 1 Sample Date(s):</i>      |

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5731412    PWS NAME: CARLISLE INTERMEDIATE SCHOOL

PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: DS000

FACILITY NAME: CARLISLE INTERMEDIATE SC DISTRIBUTION

Effective Date: 1/1/08

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements   |
|---|---|
| LEAD - 1030 & COPPER - 1022   | Not Required  |
| TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br>TOTAL TRIHALOMETHANES (TTHM) - 2950 | ** Not Required   |
| TOTAL COLIFORM (TCR) - 3100   | 1 Sample(s) Quarterly between 1/1/2008 and 6/30/2008<br>1 Sample(s) Quarterly between 8/1/2008 and 12/31/2008 |
| TOTAL CHLORINE - 1000   | *** Sample in the Distribution System   |

---

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

---

| Use for Sample Tracking Purposes | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| TCR Quarterly Sample Date(s):    |                          |                          |                           |                          |

---

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5732612    PWS NAME: DAYTON TALL TIMBERS KOA PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5756647    STU NAME: DAYTON TALL TIMBERS KOA


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 4/1/2008 and 11/30/2008 | <b>Sample should be taken at DS000</b> |

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5734212    PWS NAME: ROUTE 4 HOLINESS PENTECOSTAL**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5756650    STU NAME: ROUTE 4 HOLINESS PENTECOSTAL**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH5734812    PWS NAME: OLD TROY PIKE COMMUNITY CHURCH

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5756653    STU NAME: OLD TROY PIKE COMMUNITY CHURCH


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                   | Monitoring Requirements                               | Sample Monitoring Point                |
|-----------------------------|---|--|
| NITRATE                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <i>Sample should be taken at EP001</i> |
| NITRITE                     | Not Required  |  |
| TOTAL COLIFORM (TCR) - 3100 | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <i>Sample should be taken at DS000</i> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5735512    PWS NAME: LAKE OF THE WOODS 1 HILL**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5756656    STU NAME: LAKE OF THE WOODS NO 1 HILLBROOK**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                              | Sample Monitoring Point                |
|------------------------------------|--|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008          | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required   |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5735612    PWS NAME: LAKE OF THE WOODS 2 LAKE**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5756657    STU NAME: LAKE OF THE WOODS NO 2 LAKE**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5735712    PWS NAME: LAKE OF THE WOODS 3 CLUB**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5756658    STU NAME: LAKE OF THE WOODS NO 3 CLUBHOUSE**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                              | Sample Monitoring Point                |
|------------------------------------|--|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008          | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required   |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5735812 PWS NAME: LAKE OF THE WOODS 4 HARMONY**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5756659 STU NAME: LAKE OF THE WOODS NO 4 HARMONY C**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                              | Sample Monitoring Point                |
|------------------------------------|--|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008          | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required   |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

## 2008 CONTAMINANT MONITORING SCHEDULE


**PWS ID: OH5735912    PWS NAME: LAKE OF THE WOODS 5 OFFICE**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5756660    STU NAME: LAKE OF THE WOODS NO 5**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5736012    PWS NAME: MILE HIGH CLUB**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5756661    STU NAME: ORBIT INN**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5736512    PWS NAME: JACKASS FLATS PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5756662    STU NAME: JACKASS FLATS**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 10/1/2008 and 12/31/2008          | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5737112    PWS NAME: VOITURE 40-8, 34  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5756664    STU NAME: VOITURE 40 8 34  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                   | Monitoring Requirements                               | Sample Monitoring Point                |
|-----------------------------|---|--|
| NITRATE                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <i>Sample should be taken at EP001</i> |
| NITRITE                     | Not Required  |  |
| TOTAL COLIFORM (TCR) - 3100 | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <i>Sample should be taken at DS000</i> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5738512 PWS NAME: PLAINVIEW OPEN BIBLE CHURCH**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5756669 STU NAME: PLAINVIEW OPEN BIBLE CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5738612 PWS NAME: POLK GROVE UNITED CHURCH OF CHRIST**

**PWS TYPE: Transient Noncommunity SOURCE: Purchased Ground Water**

**STU ID: 5756670 STU NAME: POLK GROVE CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, NA is the first tap after the well.

| Use for Sample Tracking Purposes | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| TCR Quarterly Sample Date(s):    |                          |                          |                           |                          |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5739112    PWS NAME: PYRMONT UNITED METHODIST CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5756674    STU NAME: PYRMONT U METHODIST CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5739412 PWS NAME: SALEM CHURCH OF THE BRETHREN PWS**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5756675 STU NAME: SALEM CHURCH OF BRETHREN**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 10/1/2008 and 12/31/2008          | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5740212    PWS NAME: FIRST GRACE BRETHREN CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5756679    STU NAME: FIRST GRACE BRETHREN CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5740412 PWS NAME: TEMPLE BAPTIST CHURCH CARLISLE**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5756680 STU NAME: TEMPLE BAPTIST**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 0/0/2008 and 0/0/2008             | <i>Sample should be taken at EP001</i> |
| <b>NITRITE</b>                     | CONTACT OHIO EPA                                      | <i>CONTACT OHIO EPA</i>                |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <i>Sample should be taken at DS000</i> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5740812    PWS NAME: TIMBER LANES PWS**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5756682    STU NAME: TIMBER LANES**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5740912    PWS NAME: HIGH SPIRITS  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5756683    STU NAME: HIGH SPIRITS  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                   | Monitoring Requirements                               | Sample Monitoring Point                |
|-----------------------------|---|--|
| NITRATE                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <i>Sample should be taken at EP001</i> |
| NITRITE                     | Not Required  |  |
| TOTAL COLIFORM (TCR) - 3100 | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <i>Sample should be taken at DS000</i> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5741412    PWS NAME: SPITFIRE**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5756684    STU NAME: SPITFIRE**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5741612    PWS NAME: PRO-BUILD  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5756685    STU NAME: PRO-BUILD  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                   | Monitoring Requirements                               | Sample Monitoring Point                |
|-----------------------------|---|--|
| NITRATE                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <i>Sample should be taken at EP001</i> |
| NITRITE                     | Not Required  |  |
| TOTAL COLIFORM (TCR) - 3100 | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <i>Sample should be taken at DS000</i> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5742012 PWS NAME: ANCHOR FABRICATORS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5756687 STU NAME: ANCHOR FABRICATORS INC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>       | <b>Monitoring Requirements</b>               |
|--|-----------------------------------|--|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below | Not Required                                 |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040             | 1 Sample(s) between 6/1/2008 and 10/31/2008  |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041             | Not Required                                 |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                   | 1 Sample(s) between 10/1/2008 and 12/31/2008 |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below        | 1 Sample(s) between 6/1/2008 and 10/31/2008  |

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |
|---|
| <i>NITRATE Sample Date(s):</i>          |
| <i>VOC Sample Date(s):</i>              |
| <i>SOC Group 1 Sample Date(s):</i>      |

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5742012      PWS NAME: ANCHOR FABRICATORS

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: ANCHOR FABRICATORS DISTRIBUTION

Effective Date: 1/1/08

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code        | Monitoring Requirements                               |
|-----------------------------|---|
| LEAD - 1030 & COPPER - 1022 | 5 Sample(s) between 7/1/2008 and 12/31/2008           |
| TOTAL COLIFORM (TCR) - 3100 | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 |

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month. If you receive a Total Coliform Positive result, contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

---

| Use for Sample Tracking Purposes                 |                          |                          |                           |                          |
|--|--------------------------|--------------------------|---------------------------|--------------------------|
| Lead & Copper Initial Monitoring Sample Date(s): | 1st Half Sample Date(s)  |                          | 2nd Half Sample Date(s)   |                          |
|  |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):                    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |
|  |                          |                          |                           |                          |

---

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5742412    PWS NAME: GRACE BIBLE CHURCH-CLAYTON

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5756689    STU NAME: GRACE BIBLE CHURCH-CLAYTON


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5742612    PWS NAME: CLAYTON PARK  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5756690    STU NAME: CLAYTON PARK  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                   | Monitoring Requirements                              | Sample Monitoring Point                |
|-----------------------------|--|--|
| NITRATE                     | 1 Sample(s) between 6/1/2008 and 10/31/2008          | <i>Sample should be taken at EP001</i> |
| NITRITE                     | Not Required   |  |
| TOTAL COLIFORM (TCR) - 3100 | 1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008 | <i>Sample should be taken at DS000</i> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5742712 PWS NAME: FARMERSVILLE/JACKSON TWP RECREATION**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5756691 STU NAME: COMMUNITY CENTER**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5743012    PWS NAME: GERMANTOWN METROPARK NATURE CENTER PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5756693    STU NAME: GERMANTOWN METROPARK NATURE CENTER**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5743512    PWS NAME: MELODY POOL**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5756694    STU NAME: MELODY POOL**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                              | Sample Monitoring Point                |
|------------------------------------|--|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008          | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required   |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5744112    PWS NAME: CRICKET HOLLER SCOUT RESERVE**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5756695    STU NAME: CRICKET HOLLER SCT RESV NE MOT**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5744312    PWS NAME: FAIR VALLEY COUNTRY CLUB**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5756696    STU NAME: FAIR VALLEY COUNTRY CLUB**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                              | Sample Monitoring Point                |
|------------------------------------|--|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008          | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required   |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 5/1/2008 and 9/30/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5745112    PWS NAME: TAYLORSVILLE RESERVE SOUTH DAM PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5761643    STU NAME: TAYLORSVILLE RESERVE SDAM MOT**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                   | <b>Monitoring Requirements</b>                        | <b>Sample Monitoring Point</b>         |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| <b>Use for Sample Tracking Purposes</b> |                          |                          |                           |                          |
|---|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):                 |                          |                          |                           |                          |
| Nitrite Sample Date(s):                 |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):           | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5745612    PWS NAME: BLESSED HOPE BAPTIST CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5756700    STU NAME: BLESSED HOPE BAPTIST CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5745912    PWS NAME: DEER RUN LODGE**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5756701    STU NAME: DEER RUN LODGE**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5746012    PWS NAME: FIRST FREE WILL BAPTIST**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5756702    STU NAME: FIRST FREE WILL BAPTIST CHURCH**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5746512    PWS NAME: DAYTON POWER & LIGHT - O. H. HUTCHINGS S**

**PWS TYPE: Nontransient Noncommunity    SOURCE: Ground Water    Sample Monitoring Point: EP001**

**STU ID: 5756705    STU NAME: DAYTON POWER & LIGHT CO OH HUTCHINGS STA**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>       | <b>Monitoring Requirements</b>              |
|--|-----------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040             | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041             | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                   | 1 Sample(s) between 1/1/2008 and 3/31/2008  |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below        | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

INORGANIC Chemicals:    ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals:    SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |
|---|
| <i>NITRATE Sample Date(s):</i>          |
| <i>VOC Sample Date(s):</i>              |
| <i>SOC Group 1 Sample Date(s):</i>      |

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5746512 PWS NAME: DAYTON POWER & LIGHT - O. H. HUTCHINGS S**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: DAYTON POWER & LIGHT-OHH DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemical Name - Code</b>   | <b>Monitoring Requirements</b>                        |
|---|---|
| <b>LEAD - 1030 &amp; COPPER - 1022</b>  | Not Required  |
| <b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br/>TOTAL TRIHALOMETHANES (TTHM) - 2950</b> | ** Not Required                                       |
| <b>TOTAL COLIFORM (TCR) - 3100</b>  | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 |
| <b>TOTAL CHLORINE - 1000</b>  | *** Sample in the Distribution System                 |

---

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule.

*Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.*

If you receive a Total Coliform Positive result, contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

---

| <b>Use for Sample Tracking Purposes</b> | <i>Jan - Mar Sample Date(s)</i> | <i>Apr - Jun Sample Date(s)</i> | <i>Jul - Sept Sample Date(s)</i> | <i>Oct - Dec Sample Date(s)</i> |
|---|---------------------------------|---------------------------------|----------------------------------|---------------------------------|
| <i>TCR Quarterly Sample Date(s):</i>    |                                 |                                 |                                  |                                 |

---

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5746812    PWS NAME: AULLWOOD AUDUBON FARM PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5756707    STU NAME: AULLWOOD AUDUBON FARM**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

## 2008 CONTAMINANT MONITORING SCHEDULE


**PWS ID: OH5746912    PWS NAME: MIAMI VALLEY HUNT & POLO**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5756708    STU NAME: MIAMI VALLEY HUNT & POLO CLUB**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5747012    PWS NAME: MELODY 49 DRIVE-IN  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5756709    STU NAME: MELODY 49 DRIVE IN THEATER  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                   | Monitoring Requirements                               | Sample Monitoring Point                |
|-----------------------------|---|--|
| NITRATE                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <i>Sample should be taken at EP001</i> |
| NITRITE                     | Not Required  |  |
| TOTAL COLIFORM (TCR) - 3100 | 1 Sample(s) Quarterly between 4/1/2008 and 10/31/2008 | <i>Sample should be taken at DS000</i> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5747112    PWS NAME: NORTHMONT COMMUNITY CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5756710    STU NAME: NORTHMONT COMMUNITY CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

## 2008 CONTAMINANT MONITORING SCHEDULE

PWS ID: OH5747312    PWS NAME: UNITED CHRISTIAN CHURCH PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5761855    STU NAME: UNITED CHRISTIAN CHURCH


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

### Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5747412    PWS NAME: ODNR-SYCAMORE STATE PARK**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5756711    STU NAME: ODNR SYCAMORE STATE PARK OVERLOOK**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5747512      PWS NAME: K&B MOLDED PRODUCTS**

**PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: EP001**

**STU ID: 5756712      STU NAME: KUHNS MOLD & TOOL**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>       | <b>Monitoring Requirements</b>              |
|--|-----------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040             | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041             | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                   | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below        | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

**Use for Sample Tracking Purposes**

*NITRATE Sample Date(s):*

*SOC Group 1 Sample Date(s):*

---

---

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5747512 PWS NAME: K&B MOLDED PRODUCTS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: K&B MOLDED PRODUCTS DISTRIBUTION**

**Effective Date: 1/1/08**

---

---

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemical Name - Code**

**Monitoring Requirements**

---

**LEAD - 1030 & COPPER - 1022**

Not Required

---

**TOTAL COLIFORM (TCR) - 3100**

1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008

---

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

---

**Use for Sample Tracking Purposes**

*Jan - Mar Sample Date(s)*

*Apr - Jun Sample Date(s)*

*Jul - Sept Sample Date(s)*

*Oct - Dec Sample Date(s)*

*TCR Quarterly Sample Date(s):*

---

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5747612 PWS NAME: DOMINION MINISTRIES INTERNATIONAL**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5756713 STU NAME: DOMINION MINISTRIES INTERNATIONAL**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5747712 PWS NAME: GERMANTOWN METRO PARK**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5756714 STU NAME: GERMANTOWN METROPARK**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5747812 PWS NAME: JAMAICA RUN GOLF CLUB**

**PWS TYPE: Transient Noncommunity SOURCE: Ground Water**

**STU ID: 5756715 STU NAME: JAMAICA RUN GOLF CLUB**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 3/1/2008 and 11/30/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


**PWS ID: OH5748012    PWS NAME: NNCK MARATHON**  
**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**  
**STU ID: 5756716    STU NAME: NNCK MARATHON**  
**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

**PWS ID: OH5748312 PWS NAME: ABUNDANT LIFE TABERNACLE PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Purchased Ground Water Sample Monitoring Point: DS000**

**FACILITY NAME: ABUNDANT LIFE TABERNACLE DISTRIBUTION**

**Effective Date: 4/18/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemical Name - Code</b>   | <b>Monitoring Requirements</b>                        |
|---|---|
| <b>REVISED - LEAD - 1030 &amp; COPPER - 1022</b>  | 5 Sample(s) between 6/1/2008 and 9/30/2008            |
| <b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br/>TOTAL TRIHALOMETHANES (TTHM) - 2950</b> | ** 1 Sample(s) between 7/1/2008 and 9/30/2008         |
| <b>TOTAL COLIFORM (TCR) - 3100</b>  | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 |
| <b>TOTAL CHLORINE - 1000</b>  | *** Sample in the Distribution System                 |

**\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)**

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

**TOTAL COLIFORM (TCR) Sampling Information**

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

**\*\*\* TOTAL CHLORINE Sampling Information**

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| <b>Use for Sample Tracking Purposes</b>  |                                 |                                 |                                  |                                 |
|--|---------------------------------|---------------------------------|----------------------------------|---------------------------------|
| <i>Lead &amp; Copper Sample Date(s):</i> |                                 |                                 |                                  |                                 |
| <i>HAA5 &amp; TTHM Sample Date(s):</i>   |                                 |                                 |                                  |                                 |
| <i>TCR Quarterly Sample Date(s):</i>     | <i>Jan - Mar Sample Date(s)</i> | <i>Apr - Jun Sample Date(s)</i> | <i>Jul - Sept Sample Date(s)</i> | <i>Oct - Dec Sample Date(s)</i> |
| <i>Total Chlorine Sample Date(s):</i>    |                                 |                                 |                                  |                                 |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5748512      PWS NAME: SECOND COVENANT APOSTOLIC CHURCH PWS**

**PWS TYPE: Transient Noncommunity      SOURCE: Ground Water**

**STU ID: 5760758      STU NAME: SECOND COVENANT APOSTOLIC CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                   | <b>Monitoring Requirements</b>                        | <b>Sample Monitoring Point</b>         |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| <b>Use for Sample Tracking Purposes</b> |                          |                          |                           |                          |
|---|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):                 |                          |                          |                           |                          |
| Nitrite Sample Date(s):                 |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):           | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**


PWS ID: OH5748612    PWS NAME: SHAEFER SUNOCO  
PWS TYPE: Transient Noncommunity    SOURCE: Ground Water  
STU ID: 5756719    STU NAME: CLAYTON SUNOCO  
Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                   | Monitoring Requirements                               | Sample Monitoring Point                |
|-----------------------------|---|--|
| NITRATE                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <i>Sample should be taken at EP001</i> |
| NITRITE                     | Not Required  |  |
| TOTAL COLIFORM (TCR) - 3100 | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <i>Sample should be taken at DS000</i> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5748812    PWS NAME: GODS WAY TRIUNE MINISTRIES**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5760957    STU NAME: GODS WAY TRIUNE MINISTRIES**


**Effective Date: 1/22/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                   | <b>Monitoring Requirements</b>                        | <b>Sample Monitoring Point</b>         |
|------------------------------------|---|--|
| <b>REVISED - NITRATE</b>           | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>REVISED - NITRITE</b>           | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| <b>Use for Sample Tracking Purposes</b> |                          |                          |                           |                          |
|---|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):                 |                          |                          |                           |                          |
| Nitrite Sample Date(s):                 |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):           | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

**PWS ID: OH5749012 PWS NAME: USA TRUCK, INC. PWS**

**PWS TYPE: Nontransient Noncommunity SOURCE: Ground Water Sample Monitoring Point: EP001**

**STU ID: 5760963 STU NAME: USA TRUCK INC**

**Effective Date: 1/1/08**

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                         | <b>Chemical Name - Code</b>       | <b>Monitoring Requirements</b>              |
|--|-----------------------------------|---|
| <b>INORGANICS</b>                        | See Inorganic Chemical List Below | Not Required                                |
| <b>NITRATE</b>                           | NITRATE (AS N) - 1040             | 1 Sample(s) between 6/1/2008 and 10/31/2008 |
| <b>NITRITE</b>                           | NITRITE (AS N) - 1041             | Not Required                                |
| <b>VOLATILE ORGANIC CHEMICALS (VOC)</b>  |                                   | Not Required                                |
| <b>SYNTHETIC ORGANIC CHEMICALS (SOC)</b> | See SOC Group 1 List Below        | 1 Sample(s) between 6/1/2008 and 10/31/2008 |

INORGANIC Chemicals: ANTIMONY - 1074, ARSENIC - 1005, BARIUM - 1010, BERYLLIUM - 1075, CADMIUM - 1015, CHROMIUM - 1020, CYANIDE - 1024, FLUORIDE - 1025, MERCURY - 1035, NICKEL - 1036, SELENIUM - 1045, THALLIUM - 1085

SOC Group 1 Chemicals: SIMAZINE - 2037, ATRAZINE - 2050, ALACHLOR (LASSO) - 2051

| <b>Use for Sample Tracking Purposes</b> |
|---|
| <i>NITRATE Sample Date(s):</i>          |
| <i>SOC Group 1 Sample Date(s):</i>      |

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5749012      PWS NAME: USA TRUCK, INC. PWS

PWS TYPE: Nontransient Noncommunity      SOURCE: Ground Water      Sample Monitoring Point: DS000

FACILITY NAME: USA TRUCK DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements                               |
|---|---|
| LEAD - 1030 & COPPER - 1022   | 5 Sample(s) between 6/1/2008 and 9/30/2008            |
| TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br>TOTAL TRIHALOMETHANES (TTHM) - 2950 | ** Not Required                                       |
| TOTAL COLIFORM (TCR) - 3100   | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 |
| TOTAL CHLORINE - 1000   | *** Sample in the Distribution System                 |

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Lead & Copper Sample Date(s):    |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    |                          |                          |                           |                          |
|                                  | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5749112    PWS NAME: BRANTWOOD BAPTIST CHURCH PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5761074    STU NAME: BRANTWOOD BAPTIST CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                   | <b>Monitoring Requirements</b>                        | <b>Sample Monitoring Point</b>         |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| <b>Use for Sample Tracking Purposes</b> |                          |                          |                           |                          |
|---|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):                 |                          |                          |                           |                          |
| Nitrite Sample Date(s):                 |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):           | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5749212    PWS NAME: ART VAN ATTA PARK PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5761179    STU NAME: ART VAN ATTA PARK**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                              | Sample Monitoring Point                |
|------------------------------------|--|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008          | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required   |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 4/1/2008 and 9/30/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5749312    PWS NAME: NEW HOPE OPEN BIBLE CHURCH**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5761264    STU NAME: NEW HOPE OPEN BIBLE CHURCH**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                          | Monitoring Requirements                               | Sample Monitoring Point                |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | Not Required  |  |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

PWS ID: OH5749512    PWS NAME: UPPER DECK TAVERN PWS

PWS TYPE: Transient Noncommunity    SOURCE: Ground Water

STU ID: 5761798    STU NAME: UPPER DECK TAVERN


Effective Date: 1/1/08

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemicals                   | Monitoring Requirements                               | Sample Monitoring Point                |
|-----------------------------|---|--|
| NITRATE                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <i>Sample should be taken at EP001</i> |
| NITRITE                     | Not Required  |  |
| TOTAL COLIFORM (TCR) - 3100 | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <i>Sample should be taken at DS000</i> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| Use for Sample Tracking Purposes |                          |                          |                           |                          |
|----------------------------------|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):          |                          |                          |                           |                          |
| Nitrite Sample Date(s):          |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):    | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING SCHEDULE**

**PWS ID: OH5749612    PWS NAME: SYCAMORE RIDGE COMMUNITY CHURCH PWS**

**PWS TYPE: Transient Noncommunity    SOURCE: Ground Water**

**STU ID: 5761817    STU NAME: SYCAMORE RIDGE COMMUNITY CHURCH-TP**


**Effective Date: 1/1/08**

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| <b>Chemicals</b>                   | <b>Monitoring Requirements</b>                        | <b>Sample Monitoring Point</b>         |
|------------------------------------|---|--|
| <b>NITRATE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>NITRITE</b>                     | 1 Sample(s) between 6/1/2008 and 10/31/2008           | <b>Sample should be taken at EP001</b> |
| <b>TOTAL COLIFORM (TCR) - 3100</b> | 1 Sample(s) Quarterly between 1/1/2008 and 12/31/2008 | <b>Sample should be taken at DS000</b> |

## Where to Collect Samples For a Small Public Water System



\* If system does not have treatment, EP001 is the first tap after the well.

| <b>Use for Sample Tracking Purposes</b> |                          |                          |                           |                          |
|---|--------------------------|--------------------------|---------------------------|--------------------------|
| Nitrate Sample Date(s):                 |                          |                          |                           |                          |
| Nitrite Sample Date(s):                 |                          |                          |                           |                          |
| TCR Quarterly Sample Date(s):           | Jan - Mar Sample Date(s) | Apr - Jun Sample Date(s) | Jul - Sept Sample Date(s) | Oct - Dec Sample Date(s) |

**2008 CONTAMINANT MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH5749812      PWS NAME: CLAYTON WTP PWS

PWS TYPE: Community    SOURCE: Purchased Surface Water    Sample Monitoring Point: DS000

FACILITY NAME: CLAYTON DISTRIBUTION

Effective Date: 1/1/08

**THIS SCHEDULE MAY NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

| Chemical Name - Code  | Monitoring Requirements                             |
|---|---|
| <b>REVISED - LEAD - 1030 &amp; COPPER - 1022</b>  | 5 Sample(s) between 6/1/2008 and 9/30/2008          |
| <b>TOTAL HALOACETIC ACIDS (HAA5) - 2456 and<br/>TOTAL TRIHALOMETHANES (TTHM) - 2950</b> | ** 1 Sample(s) Quarterly                            |
| <b>TOTAL COLIFORM (TCR) - 3100</b>  | 1 Sample(s) Monthly between 1/1/2008 and 12/31/2008 |
| <b>TOTAL CHLORINE - 1000</b>  | *** Sample in the Distribution System               |

\*\* Total Haloacetic Acids (HAA5) and Total Trihalomethanes (TTHM) Sampling Information (Disinfection Byproducts)

HAA5 and TTHM are part of a large group of chemicals known as disinfection byproducts. These samples should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect HAA5 and TTHM samples from other locations in your distribution system, use RD000 as the sample monitoring point.

Questions concerning HAA5 and TTHM monitoring can be directed to Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

TOTAL COLIFORM (TCR) Sampling Information

PLEASE NOTE: Total Coliform Positive samples will increase your Total Coliform monitoring requirements beyond what is included in this schedule. *Monitoring will be at least temporarily increased to include 4 Repeat Samples to be taken immediately and 5 Routine Samples the next month.* If you receive a Total Coliform Positive result, contact your Southwest District Office - DDAGW representative immediately at 937-285-6357.

\*\*\* TOTAL CHLORINE Sampling Information

Total Chlorine samples are collected in the distribution system at the same time and place as Total Coliforms are sampled.

| Use for Sample Tracking Purposes                 |                                 |            |            |                                 |            |            |                                  |            |             |                                 |            |            |
|--|---------------------------------|------------|------------|---------------------------------|------------|------------|----------------------------------|------------|-------------|---------------------------------|------------|------------|
| <i>Lead &amp; Copper Sample Date(s):</i>         |                                 |            |            |                                 |            |            |                                  |            |             |                                 |            |            |
| <i>HAA5 &amp; TTHM Quarterly Sample Date(s):</i> |                                 |            |            |                                 |            |            |                                  |            |             |                                 |            |            |
|  | <i>Jan - Mar Sample Date(s)</i> |            |            | <i>Apr - Jun Sample Date(s)</i> |            |            | <i>Jul - Sept Sample Date(s)</i> |            |             | <i>Oct - Dec Sample Date(s)</i> |            |            |
| <i>TCR Monthly Sample Date(s):</i>               | <i>Jan</i>                      | <i>Feb</i> | <i>Mar</i> | <i>Apr</i>                      | <i>May</i> | <i>Jun</i> | <i>Jul</i>                       | <i>Aug</i> | <i>Sept</i> | <i>Oct</i>                      | <i>Nov</i> | <i>Dec</i> |
| <i>Total Chlorine Sample Date(s):</i>            |                                 |            |            |                                 |            |            |                                  |            |             |                                 |            |            |